WORK INSTRUCTION

Document ID: DOC-0002536
Project: PRJ-017
Uploaded on: 2026-02-18
Uploaded by: user066
Export class: EAR99

Assembly of P-103622 at plant PLT03

Part Number: P-103622
Revision: A.1
Plant: PLT03
Station: ST-86
Torque (Nm): 20
Cycle time (s): 260

Step 1: Move to next station

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Inspect incoming part

Step 7: Visual check

Assembly of P-103894 at plant PLT03

Part Number: P-103894
Revision: A.1
Plant: PLT03
Station: ST-88
Torque (Nm): 2.5
Cycle time (s): 41

Step 1: Move to next station

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Record result

Step 6: Move to next station

Step 7: Visual check

Step 8: Record result

Assembly of P-102720 at plant PLT03

Part Number: P-102720
Revision: A.1
Plant: PLT03
Station: ST-62

Torque (Nm):	2.5
Cycle time (s):	231

Step 1: Fit fasteners

Step 2: Torque to specification

Step 3: Clean mating surface

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Record result