EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002569
Project: PRJ-025
Uploaded on: 2026-03-07
Uploaded by: user038
Export class: ECCN-3A001

Assembly of P-102994 at plant PLT02

Part Number: P-102994
Revision: A.1
Plant: PLT02
Station: ST-41
Torque (Nm): 2.5
Cycle time (s): 256

Step 1: Torque to specification

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Clean mating surface

Step 5: Clean mating surface

Step 6: Clean mating surface

Step 7: Record result

Assembly of P-103843 at plant PLT03

Part Number: P-103843
Revision: A.1
Plant: PLT03
Station: ST-92
Torque (Nm): 12
Cycle time (s): 128

Step 1: Visual check

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Apply thread locker

Step 6: Fit fasteners

Step 7: Move to next station

Assembly of P-103520 at plant PLT02

Part Number: P-103520
Revision: A.1
Plant: PLT02

Station:	ST-30
Torque (Nm):	2.5
Cycle time (s):	297

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Visual check

Step 6: Inspect incoming part