WORK INSTRUCTION

Document ID: DOC-0000314
Project: PRJ-011
Uploaded on: 2023-03-30
Uploaded by: user014
Export class: EAR99

Assembly of P-100496 at plant PLT01

Part Number: P-100496
Revision: A.1
Plant: PLT01
Station: ST-89
Torque (Nm): 20
Cycle time (s): 129

Step 1: Apply thread locker

Step 2: Apply thread locker

Step 3: Clean mating surface

Step 4: Record result

Step 5: Move to next station

Assembly of P-100139 at plant PLT02

Part Number: P-100139
Revision: B.1
Plant: PLT02
Station: ST-37
Torque (Nm): 8
Cycle time (s): 198

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Visual check

Step 4: Apply thread locker

Step 5: Inspect incoming part

Assembly of P-100017 at plant PLT02

Part Number: P-100017
Revision: B.1
Plant: PLT02
Station: ST-92
Torque (Nm): 2.5
Cycle time (s): 44

Step 1: Record result

Step 2: Apply thread locker

Step 3: Clean mating surface

Step 4: Move to next station

Step 5: Apply thread locker

Step 6: Torque to specification