WORK INSTRUCTION

Document ID: DOC-0000654
Project: PRJ-003
Uploaded on: 2023-09-05
Uploaded by: user008
Export class: EAR99

Assembly of P-100738 at plant PLT04

Part Number: P-100738
Revision: A.1
Plant: PLT04
Station: ST-92
Torque (Nm): 2.5
Cycle time (s): 133

Step 1: Fit fasteners

Step 2: Clean mating surface

Step 3: Visual check

Step 4: Move to next station

Step 5: Torque to specification

Step 6: Torque to specification

Assembly of P-100718 at plant PLT02

Part Number: P-100718
Revision: A.1
Plant: PLT02
Station: ST-91
Torque (Nm): 12
Cycle time (s): 241

Step 1: Apply thread locker

Step 2: Move to next station

Step 3: Clean mating surface

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Inspect incoming part

Assembly of P-100604 at plant PLT03

Part Number: P-100604
Revision: A.1
Plant: PLT03
Station: ST-58
Torque (Nm): 5
Cycle time (s): 205

Step 1: Record result

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Record result

Step 5: Visual check

Step 6: Apply thread locker