WORK INSTRUCTION

Document ID: DOC-0000697
Project: PRJ-003
Uploaded on: 2023-10-01
Uploaded by: user008
Export class: EAR99

Assembly of P-101095 at plant PLT02

Part Number: P-101095
Revision: A.1
Plant: PLT02
Station: ST-55
Torque (Nm): 12
Cycle time (s): 111

Step 1: Torque to specification

Step 2: Clean mating surface

Step 3: Move to next station

Step 4: Torque to specification

Step 5: Clean mating surface

Assembly of P-100079 at plant PLT01

Part Number: P-100079
Revision: B.1
Plant: PLT01
Station: ST-34
Torque (Nm): 12
Cycle time (s): 186

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Record result