# WORK INSTRUCTION

**Document ID:** DOC-0001030
**Project:** PRJ-030
**Uploaded on:** 2024-03-23
**Uploaded by:** user014
**Export class:** EAR99

## Assembly of P-101488 at plant PLT02

**Part Number:** P-101488
**Revision:** A.1
**Plant:** PLT02
**Station:** ST-56
**Torque (Nm):** 2.5
**Cycle time (s):** 31

Step 1: Move to next station

Step 2: Apply thread locker

Step 3: Clean mating surface

Step 4: Inspect incoming part

Step 5: Torque to specification

Step 6: Clean mating surface

Step 7: Inspect incoming part

Step 8: Apply thread locker

## Assembly of P-101296 at plant PLT03

**Part Number:** P-101296
**Revision:** A.1
**Plant:** PLT03
**Station:** ST-98
**Torque (Nm):** 5
**Cycle time (s):** 74

Step 1: Fit fasteners

Step 2: Move to next station

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Clean mating surface

Step 6: Record result

Step 7: Move to next station

Step 8: Fit fasteners

## Assembly of P-101696 at plant PLT04

**Part Number:** P-101696
**Revision:** A.1
**Plant:** PLT04

| | |
|---|---|
| **Station:** | ST-77 |
| **Torque (Nm):** | 8 |
| **Cycle time (s):** | 238 |

Step 1: Inspect incoming part

Step 2: Record result

Step 3: Inspect incoming part

Step 4: Fit fasteners

Step 5: Torque to specification