EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001035
Project: PRJ-023
Uploaded on: 2024-03-28
Uploaded by: user002
Export class: ECCN-3A001

Assembly of P-101672 at plant PLT01

Part Number: P-101672
Revision: A.1
Plant: PLT01
Station: ST-10
Torque (Nm): 12
Cycle time (s): 176

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Record result

Step 4: Visual check

Step 5: Visual check

Assembly of P-101676 at plant PLT02

Part Number: P-101676
Revision: A.1
Plant: PLT02
Station: ST-45
Torque (Nm): 2.5
Cycle time (s): 271

Step 1: Move to next station

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Fit fasteners

Step 7: Visual check

Step 8: Fit fasteners