WORK INSTRUCTION

Document ID: DOC-0001070
Project: PRJ-020
Uploaded on: 2024-04-14
Uploaded by: user011
Export class: EAR99

Assembly of P-101312 at plant PLT01

Part Number: P-101312
Revision: A.1
Plant: PLT01
Station: ST-50
Torque (Nm): 20
Cycle time (s): 187

Step 1: Clean mating surface

Step 2: Clean mating surface

Step 3: Apply thread locker

Step 4: Inspect incoming part

Step 5: Fit fasteners

Step 6: Fit fasteners