EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0001880
Project: PRJ-036
Uploaded on: 2025-04-23
Uploaded by: user184
Export class: ECCN-3A001

Assembly of P-100868 at plant PLT04

Part Number: P-100868
Revision: B.1
Plant: PLT04
Station: ST-54
Torque (Nm): 12
Cycle time (s): 160

Step 1: Clean mating surface

Step 2: Record result

Step 3: Visual check

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Torque to specification

Step 8: Clean mating surface

Assembly of P-102439 at plant PLT03

Part Number: P-102439
Revision: A.1
Plant: PLT03
Station: ST-41
Torque (Nm): 2.5
Cycle time (s): 258

Step 1: Fit fasteners

Step 2: Fit fasteners

Step 3: Torque to specification

Step 4: Clean mating surface

Step 5: Move to next station

Step 6: Clean mating surface

Step 7: Apply thread locker

Step 8: Apply thread locker

Assembly of P-102004 at plant PLT03

Part Number: P-102004

Revision:	A.1
Plant:	PLT03
Station:	ST-34
Torque (Nm):	5
Cycle time (s):	177

Step 1: Apply thread locker

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Visual check

Step 5: Clean mating surface

Step 6: Torque to specification

Step 7: Fit fasteners