WORK INSTRUCTION

Document ID: DOC-0001895
Project: PRJ-040
Uploaded on: 2025-04-30
Uploaded by: user026
Export class: EAR99

Assembly of P-100570 at plant PLT03

Part Number: P-100570
Revision: A.1
Plant: PLT03
Station: ST-59
Torque (Nm): 20
Cycle time (s): 129

Step 1: Fit fasteners

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Record result

Step 6: Record result

Step 7: Clean mating surface

Step 8: Torque to specification