WORK INSTRUCTION

Document ID: DOC-0002237
Project: PRJ-039
Uploaded on: 2025-10-01
Uploaded by: user123
Export class: EAR99

Assembly of P-103549 at plant PLT03

Part Number: P-103549
Revision: A.1
Plant: PLT03
Station: ST-18
Torque (Nm): 12
Cycle time (s): 49

Step 1: Visual check

Step 2: Visual check

Step 3: Move to next station

Step 4: Torque to specification

Step 5: Move to next station

Step 6: Inspect incoming part

Step 7: Inspect incoming part

Step 8: Record result

Assembly of P-102916 at plant PLT04

Part Number: P-102916
Revision: A.1
Plant: PLT04
Station: ST-61
Torque (Nm): 8
Cycle time (s): 214

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Clean mating surface

Step 6: Inspect incoming part

Step 7: Visual check

Step 8: Apply thread locker