WORK INSTRUCTION

Document ID: DOC-0002275
Project: PRJ-003
Uploaded on: 2025-10-24
Uploaded by: user159
Export class: EAR99

Assembly of P-100022 at plant PLT03

Part Number: P-100022
Revision: B.1
Plant: PLT03
Station: ST-70
Torque (Nm): 2.5
Cycle time (s): 83

Step 1: Visual check

Step 2: Inspect incoming part

Step 3: Apply thread locker

Step 4: Move to next station

Step 5: Visual check

Step 6: Move to next station

Assembly of P-100226 at plant PLT04

Part Number: P-100226
Revision: B.1
Plant: PLT04
Station: ST-64
Torque (Nm): 5
Cycle time (s): 191

Step 1: Inspect incoming part

Step 2: Visual check

Step 3: Torque to specification

Step 4: Record result

Step 5: Torque to specification

Step 6: Move to next station

Step 7: Move to next station