WORK INSTRUCTION

Document ID: DOC-0002283
Project: PRJ-009
Uploaded on: 2025-10-25
Uploaded by: user177
Export class: EAR99

Assembly of P-102366 at plant PLT03

Part Number: P-102366
Revision: A.1
Plant: PLT03
Station: ST-32
Torque (Nm): 5
Cycle time (s): 105

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Fit fasteners

Step 6: Inspect incoming part

Step 7: Fit fasteners

Assembly of P-102707 at plant PLT03

Part Number: P-102707
Revision: B.1
Plant: PLT03
Station: ST-93
Torque (Nm): 12
Cycle time (s): 148

Step 1: Visual check

Step 2: Apply thread locker

Step 3: Fit fasteners

Step 4: Torque to specification

Step 5: Torque to specification

Step 6: Record result

Step 7: Clean mating surface

Step 8: Inspect incoming part

Assembly of P-101569 at plant PLT03

Part Number: P-101569
Revision: B.1
Plant: PLT03
Station: ST-13

Torque (Nm):	12
Cycle time (s):	107

Step 1: Visual check

Step 2: Move to next station

Step 3: Record result

Step 4: Visual check

Step 5: Inspect incoming part

Step 6: Record result

Step 7: Record result

Step 8: Torque to specification