EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0002286
Project: PRJ-039
Uploaded on: 2025-10-27
Uploaded by: user038
Export class: ECCN-3A001

Assembly of P-102707 at plant PLT03

Part Number: P-102707
Revision: B.1
Plant: PLT03
Station: ST-99
Torque (Nm): 2.5
Cycle time (s): 187

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Inspect incoming part

Step 4: Clean mating surface

Step 5: Torque to specification

Step 6: Visual check

Step 7: Record result

Assembly of P-100198 at plant PLT01

Part Number: P-100198
Revision: B.1
Plant: PLT01
Station: ST-83
Torque (Nm): 12
Cycle time (s): 129

Step 1: Apply thread locker

Step 2: Apply thread locker

Step 3: Record result

Step 4: Torque to specification

Step 5: Inspect incoming part

Step 6: Fit fasteners

Step 7: Torque to specification

Assembly of P-102418 at plant PLT02

Part Number: P-102418
Revision: A.1
Plant: PLT02

Station:	ST-81
Torque (Nm):	2.5
Cycle time (s):	128

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Record result

Step 6: Fit fasteners

Step 7: Record result

Step 8: Visual check