WORK INSTRUCTION

Document ID: DOC-0002289
Project: PRJ-019
Uploaded on: 2025-10-30
Uploaded by: user019
Export class: EAR99

Assembly of P-102224 at plant PLT02

Part Number: P-102224
Revision: B.1
Plant: PLT02
Station: ST-71
Torque (Nm): 8
Cycle time (s): 251

Step 1: Fit fasteners

Step 2: Apply thread locker

Step 3: Apply thread locker

Step 4: Fit fasteners

Step 5: Torque to specification

Assembly of P-101174 at plant PLT03

Part Number: P-101174
Revision: A.1
Plant: PLT03
Station: ST-58
Torque (Nm): 8
Cycle time (s): 92

Step 1: Move to next station

Step 2: Move to next station

Step 3: Move to next station

Step 4: Clean mating surface

Step 5: Record result

Step 6: Torque to specification

Step 7: Move to next station

Assembly of P-101487 at plant PLT02

Part Number: P-101487
Revision: A.1
Plant: PLT02
Station: ST-84
Torque (Nm): 2.5
Cycle time (s): 272

Step 1: Record result

Step 2: Torque to specification

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Apply thread locker

Step 6: Record result

Step 7: Fit fasteners