WORK INSTRUCTION

Document ID: DOC-0002002
Project: PRJ-032
Uploaded on: 2025-06-13
Uploaded by: user129
Export class: EAR99

Assembly of P-101995 at plant PLT03

Part Number: P-101995
Revision: A.1
Plant: PLT03
Station: ST-26
Torque (Nm): 12
Cycle time (s): 212

Step 1: Apply thread locker

Step 2: Record result

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Record result

Assembly of P-101596 at plant PLT01

Part Number: P-101596
Revision: A.1
Plant: PLT01
Station: ST-68
Torque (Nm): 8
Cycle time (s): 187

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Inspect incoming part

Step 4: Torque to specification

Step 5: Record result

Step 6: Clean mating surface