EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000810
Project: PRJ-036
Uploaded on: 2023-11-28
Uploaded by: user081
Export class: ECCN-3A001

Assembly of P-100036 at plant PLT02

Part Number: P-100036
Revision: A.1
Plant: PLT02
Station: ST-92
Torque (Nm): 20
Cycle time (s): 139

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Record result

Step 5: Fit fasteners

Step 6: Visual check

Step 7: Inspect incoming part

Step 8: Move to next station

Assembly of P-100957 at plant PLT02

Part Number: P-100957
Revision: A.1
Plant: PLT02
Station: ST-29
Torque (Nm): 2.5
Cycle time (s): 55

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Inspect incoming part

Step 4: Apply thread locker

Step 5: Apply thread locker

Step 6: Move to next station