

All personnel entering the cleanroom must wear appropriate gowning including gloves, mask, and coverall.

Hand sanitization is required immediately before gowning and after any interruption in cleanroom work.

Environmental monitoring samples are collected weekly by the quality control team.

Any excursion from the established alert limits must be reported to the Quality Assurance Manager within 24 hours.