





# Accelerometer, Gyro and IMU Buying Guide

Accelerometers and gyros are becoming increasingly popular in consumer electronics, so maybe it's time you added them to your project! Scrolling through SparkFun's sensors category reveals a huge list of these sensors that might be perfect for your next project, if only you knew what they did, and which one best fit your project. The goal of this buying guide is to get you speaking the same language as these sensors' datasheets and to help you select the one that is best-suited for your needs.

#### **Accelerometers**

What's an accelerometer measure? Well, acceleration. You know...how fast something is speeding up or slowing down. You'll see acceleration displayed either in units of meters per second squared (m/s²), or G-force (g), which is about 9.8m/s² (the exact value depends on your elevation and the mass of the planet you're on).

Accelerometers are used to sense both static (e.g. gravity) and dynamic (e.g. sudden starts/stops) acceleration. One of the more widely used applications for accelerometers is tilt-sensing. Because they are affected by the acceleration of gravity, an accelerometer can tell you how it's oriented with respect to the Earth's surface. For example, Apple's iPhone has an accelerometer, which lets it know whether it's being held in portrait or landscape mode. An accelerometer can also be used to sense motion. For instance, an accelerometer in Nintendo's WiiMote can be used to sense emulated forehands and backhands of a tennis racket, or rolls of a bowling ball. Finally, an accelerometer can also be used to sense if a device is in a state of free fall. This feature is implemented in several hard drives: if a drop is sensed, the hard drive is quickly switched off to protect against data loss.

Now that you know what they do, let's consider what characteristics you should be looking for when selecting your accelerometer:

- Range The upper and lower limits of what the accelerometer can measure is also known as its range. In most cases, a smaller full-scale range means a more sensitive output; so you can get a more precise reading out of an accelerometer with a low full-scale range.
  - You want to select a sensing range that will best fit your project, if your project will only be subjected to accelerations between +2g and -2g, a ±250g-ranged accelerometer won't give you much, if any, precision.
  - We have a good assortment of accelerometers, with maximum ranges stretching from  $\pm 1g$  to  $\pm 250g$ . Most of our accelerometers are set to a hard maximum/minimum range, however some of the fancier accelerometers feature selectable ranges.
- Interface This is another one of the more important specifications. Accelerometers will have either an analog, pulse-width modulated (PWM), or digital interface.
  - Accelerometers with an analog output will produce a voltage that is directly proportional to the sensed acceleration. At 0g, the analog output will usually reside at about the middle of the supplied voltage (e.g. 1.65V for a 3.3V sensor). Generally this interface is the easiest to work with, as analog-to-digital converters (ADCs) are implemented in most microcontrollers.
  - Accelerometers with a PWM interface will produce a square wave with a fixed frequency,

- but the duty cycle of the pulse will vary with the sensed acceleration. These are pretty rare; we've only got one in our catalog.
- Digital accelerometers usually feature a serial interface be it SPI or I<sup>2</sup>C. Depending on your experience, these may be the most difficult to get integrated with your microcontroller. That said, digital accelerometers are popular because they usually have more features, and are less susceptible to noise than their analog counterparts.
- **Number of axes measured** This one's very straightforward: out of the three axes possible (x, y, and z), how many can the accelerometer sense? Three-axis accelerometers are usually the way to go; they are the most common and they are really no more expensive than equivalently sensitive one or two axis accelerometers.
- Power Usage If your project is battery powered, you might want to consider how much power
  the accelerometer will consume. The required current consumption will usually be in the 100s of
  μA range. Some sensors also feature sleep functionality to conserve energy when the
  accelerometer isn't needed.
- Bonus Features Many more recently developed accelerometers may have a few nifty features, beyond just producing acceleration data. These newer accelerometers may include features like selectable measurement ranges, sleep control, 0-g detection, and tap sensing.

Device	Range	InterfaceAxo	Power es Requirement	Bonus Features
ADXL193	±250g	Analog 1	3.5-6V, 1.5- 2mA	Self test
ADAL193				
	±3g	Analog 3	1.8-3.6V, 350μΑ	Self test
ADXL335				
ADVI 0.45	±2, 4, 8, 16g	SPI and 3	2.0-3.6V, 40- 145µA	Selectable measuring range, free-fall detection, tap/double-tap detection, bandwidth selectable, programmable power modes
ADXL345				
COCCOO.	±1, 1.5, 2, 3, 4, 8, 16g	SPI and 3	2-3.6V, 650- 975µA	Selectable ranges, programmable digital filters, interrupt features, programmable power modes, free-fall detection, tap/double-tap detection, slope



£6, 12, SPI and 12C

2.16-3.6V, 250µA

detection

Self test, ultra low-power operational modes

**LIS331** 



±1.5, 6g Analog

600µA

2.2-3.6V, 400- sleep mode, signal conditioning, a 1-pole low pass filter, temperature compensation, self test, 0g-detect

MMA7361



±2, 4, 8a I2C

1.95-3.6V, 165µA

Embedded interrupt functions, low power mode, High Pass Filter Data available real-time, Orientation (Portrait/Landscape) detection with set hysteresis

MMA8452Q

# **Gyros**

Gyroscopes measure angular velocity, how fast something is spinning about an axis. If you're trying to monitor the orientation of an object in motion, an accelerometer may not give you enough information to know exactly how it's oriented. Unlike accelerometers gyros are not affected by gravity, so they make a great complement to each other. You'll usually see angular velocity represented in units of rotations per minute (RPM), or degrees per second (°/s). The three axes of rotation are either referenced as x, y, and z, or roll, pitch, and yaw.

In the past, gyros have been used for space navigation, missile control, under-water guidance, and flight guidance. Now they are starting to be used alongside accelerometers for applications like motioncapture and vehicle navigation.

A lot of what was considered when selecting an accelerometer still applies to selecting the perfect gyro:

- Range Make sure the maximum angular velocity you're expecting to measure doesn't exceed the maximum range of the gyro. But also, in order to get the best possible sensitivity, make sure your gyro's range isn't much greater than what you're expecting.
- Interface There's actually not much diversity in this section, 95% of the gyros we have feature an analog output. There are a few that have a digital interface - either SPI or I<sup>2</sup>C.
- Number of axes measured Compared to accelerometers, gyros are a little behind the curve. Only recently have inexpensive, 3-axis gyros begun to appear on the market. Most of our gyros

are either 1- or 2-axis. When selecting those, you need to pay attention to which of the three axes the gyro will measure; for example, some two axis gyros will measure pitch and roll, while others measure pitch and yaw.

- **Power Usage** If your project is battery powered, you might want to consider how much power the gyro will consume. The required current consumption will usually be in the 100s of μA range. Some sensors also feature sleep functionality to conserve energy when the gyro isn't needed.
- **Bonus Features** Not much in this section is going to blow you away. Many gyros feature a temperature output, which is very useful when compensating for drift.

Device	Range	Interface	eAxes	Power Requirements	Bonus Features
IDG500 (retired)	±110°/s and/or ±500°/s	Analog	2 (x/y)	2.7-3.3V, 7mA	Temperature sensor, auto-zero, 1x and 4.5x outputs
IXZ500 (retired)	±110°/s and/or ±500°/s	Analog	2 (x/z)	2.7-3.3V, 7mA	Temperature sensor, auto-zero, 1x and 4.5x outputs
LPY503AL	±30°/s (4x output) or ±120°/s	Analog	2 (x/z)	2.7-3.6V, 6.8mA	Self-test, power-down, 1x and 4x outputs
MLX90609 150 (retired)	±150°/s	Analog and SPI	1(z)	4.75-5.25V, 16-20mA	Analog temperature output, self test
Add to the state of the state o	±250°/s, ±500°/s or ±2000°/s	SPI and I2C	3	2.4-3.6V, 6.1mA	power-down and sleep mode, temperature sensor, High shock survivability



±2000°/s

I2C

3 2.1-3.6V, 6.5mA Programmable low pass filter, optional external clock input, interrupt outputs, temperature sensor

ITG-3200

### **IMUs**

Gyroscopes and accelerometers are great, but alone they don't give you quite enough information to be able to comfortably calculate things like orientation, position, and velocity. To measure those and other variables many people combine the two sensors, to create an inertial measurement unit (IMU) which provides two to six degrees of freedom (DOF). IMUs are widely used in devices that require knowledge of their exact position, for example robotic arms, guided missiles, and tools used in the study of body motion.

SparkFun's IMUs can really be broken down into two classes: simple IMU combo boards, which just mount an accelerometer and gyro onto a single PCB, and more complex units that interface a microcontroller with the sensors to produce a serial output. If you've glanced over the previous sections, you should know what kind of specifications to be looking for in IMUs: the number of axes (both for the accelerometer and gyro), the measuring range of the sensors, and the interface.

Device	Range	Interface	Axes	Requirements	<sub>1</sub> Bonus Features
9 Degrees of Freedom - Razor IMU	Accel:±16g Gyro:±300°/s	Serial	Accel 3 Gyro: 3	3 3-16VDC	Arduino-compatible, optional AHRS code, 3-axis magnetometer
9 Degrees of Freedom - Sensor Stick	Accel:±2, 4, 8, 16g Gyro: ±2000°/s	I2C	Accel 3 Gyro: 3	3 3-16VDC	3-axis magnetometer



Accel: ±1.5, 6g Serial Gyro:±300°/s

Accel:3.4V to 10V, 24mA(wired) Gyro: 75mA(xbee)

XBee Header on-board

Atomic IMU 6 Degrees of Freedom - XBee Ready (retired)



IMU 6DOF v4

Accel:

2x2

3x1

Accel:±1.5, 2, Individual<sup>2</sup>Gyro: 3.3-16VDC 4, 6g Gyro: ±500°/s

HMC1051Z magnetic sensors

Sensor Board

Accel: ±2, 4, 8,

16g Gyro: I2C

±2000°/s

IMU Digital Combo Board - 6 Degrees of Freedom

ITG3200/ADXL345

Accel:

3.3VDC Gyro:

3

Two mounting holes, Tiny!

Honeywell HMC1052L and

IMU Fusion Board -ADXL345 & IMU3000

Accel: ±2, 4, 8, 16g Gyro: I2C

±250-2000°/s

Accel:

3.3-16VDC

Gyro:

3

Hardware support for MotionFusion

data

ArduIMU+ V3

Accel: ±2, 4, 8,

16g Gyro: Serial, ±250, 500, I2C, etc.

1000, 2000°/s

Accel:

Gyro: 6-12VDC

3

Arduino compatible and open source, user self test, 3-axis

magnetometer, GPS port with FTDI

autoswitch

Accel: ±2, 4, 8,

Accel:

Onboard Digital Motion Processor™ (DMP™), auxiliary I2C bus to



16g Gyro: I2C ±250, 500, 1000, 2000°/s 3 2.3 - 3.4VDC Gyro: access external magnetometers and other sensors, Digital-output temperature sensor

#### MPU 6050

<sup>1</sup> Current consumption for IMUs can be tricky to nail down because of the variety of individual devices and operating modes that are available.

3

<sup>2</sup> The IMU 6DOF Sensor Board was intended as a sub-assembly of the 6DOF v4. The sensor outputs aren't combined into a single bus but are broken out individually.

## **Glossary of Terms**

Range: The range of values that a device is capable of measuring is an important factor in deciding which is appropriate for your project. Obviously a 24g accelerometer won't do you much good for tracking body motion unless you plan on being hurled into space by the world's largest slingshot. Likewise, if your accelerometer tops out at 1g then you won't get much useful data on, say, a rocket launch. The range of an accelerometer is measured in g-force, or multiples of the acceleration due to gravity on Earth. The range of a gyro, which measures rotational acceleration, is given in degrees of rotation per second.

**Interface:** The method by which you send and receive data between a controller and a device is called the interface. There are several standards available and each has its advantages and disadvantages. Analog signals are easy to read and can be measured by most microcontrollers with very little code. Serial communication in this case refers to UART and requires a little more processing overhead but is capable of carrying more information than analog signals, Serial or I2C are common in situations where multiple axes need to be read out to a controller. I2C is a two-wire serial interface that allows several devices to share a bus and communicate with each other, it's also a very common capability among microcontrollers.

**Axes:** This refers to the number of directions in which acceleration can be measured. Accelerometers measure acceleration *along* the specified axes whereas gyros measure acceleration *about* the axes.

**Power Requirements:** This represents the amount of power that the device will typically consume during operation, your system should be capable of sourcing at least this much current and then some to avoid erratic behavior or brown-out conditions. Many devices also have low-power or power-saving modes in which they'll consume considerably less power. We've also listed the rated voltage of the device for your convenience.

**Bonus Features:** Every device manufacturer has their own ideas about what 'bells and whistles' should be added to a gyro or an accelerometer. This column is where we list those extra features that set each device apart from the rest.