

UYUE MENU OPTIONS

To enter MENU, press and hold SET button

946-1010 cycles through 5 options:

- 1) MAX TEMP LIMIT range 0-400 sets upper limit on temperature adjustments (set 195C)
- 2) MIN TEMP LIMIT range 0-400 sets lower limit on temperature adjustments (set 25C)
- 3) DUTY CYCLE range 2-100 sets rate of temperature rise (set 100)

4) DISPLAY OFFSET - range -99 to +99 - allows calibration of display to agree with surface temperature measurement (set 0)

5) SETTING LOCK - range 0 or 1 - above settings can not be modifyed if this value is set to 1

press and hold SET for changes to take effect

OPERATION

press and release SET button to enter TEMP adjustment mode

up or down arrow to select

press SET button to exit

NOTE: THE NEW HIGHER OR LOWER SETTING WILL NOT TAKE EFFECT WITHOUT PWR OFF and PWR ON