PCB-A / Assembly - connector and shield

Work instruction, routing v1 - SAMPLE for Mini MES

1. Wear the ESD strap and check it on the tester.
2. Fit CONN-USBC; glue dot from L1-GLUE-01 must cover both tabs.
3. Press SHIELD-CAN until all 4 clips click.
4. Scan the board serial at station L1-ASM-01.