PCB-A / Packing

Work instruction, routing v1 - SAMPLE for Mini MES

1. Check the board has a PASS at TEST (the kiosk blocks it otherwise).
2. Put the board in PACK-BAG and seal it.
3. Scan the serial at L1-PACK-01, then put the bag in the carton.