# PCB-A / SMT - print, place, reflow

Work instruction, routing v1 - SAMPLE for Mini MES

1. Scan the WO and check the feeder setup list matches BOM PCBA-SMT.
2. Load PCB-BARE into the loader, bottom side down.
3. Check solder paste on the first board under the magnifier.
4. Start the line; reflow profile PCB-A-v1 must be selected on L1-REFLOW-01.
5. Every 2 hours: check 5 boards for bridges and missing parts.