

# Sample Labeling

Product Alpha inspection sample traceability | ForgeLine

|                    |            |
|--------------------|------------|
| Document           | FL-QWI-018 |
| Effective          | 2026-08-11 |
| Reference          | NCR-026    |
| Critical tolerance | ±0.18 mm   |

## Purpose

Apply a simple, synthetic trace label to each inspection sample so a result can be reconciled without using personal, supplier, or production identifiers.

## Label content

Use the format PA-YYMMDD-###, inspection point, and status. Example: PA-260811-014 | IP-03 | HOLD.

## Handling note

Use HOLD when NCR-026 containment is active. Never reuse a sample alias within the same inspection run.

## Execution sequence

| # | Action                                               | Record                     |
|---|------------------------------------------------------|----------------------------|
| 1 | Create the sample alias using the approved format.   | Unique alias written       |
| 2 | Add inspection point and current status.             | IP-03 and PASS/HOLD shown  |
| 3 | Attach label without obscuring the measured feature. | Feature remains accessible |
| 4 | Copy alias to the inspection record.                 | Label and record match     |