



Technical Service Bulletin

Technical Service Bulletin: tsb102992

Released Date: 13-Aug-2008

Main Bearing Procedure, Install Section Revision

Main Bearing Procedure, Install Section Revision

Warranty Statement

The information in this document has no effect on present warranty coverage or repair practices, nor does it authorize TRP or Campaign actions.

Contents

This Service/Parts Topic supersedes Service/Parts Topic 06T1-12. Replace Service/Parts Topic 06T1-12 with this Service/Parts Topic.

This Service/Parts Topic revises Procedure 001-006 (Bearings, Main). The number of main bearing cap surfaces on each cap to apply a bead of Loctite™ 518 thread sealant has changed from four to two surfaces on each main bearing cap before installation into the cylinder block. This step will help seal and protect the surfaces between the main bearing cap and cylinder block. The relevant illustration has been revised to show the correct location to add the Loctite™ 518 thread sealant.

Related Procedures

10-001-006-tr
(/qs3/pubsys2/xml/en/procedures/10/10-001-006-tr.html)

Bearings, Main
(/qs3/pubsys2/xml/en/procedures/10/10-001-006-tr.html)

Last Modified: 13-Aug-2008