

Note : Information Fault Codes have simple, corrective actions and no fault code troubleshooting tree.

- SRT 00-394 applies to all of the Information Fault Codes listed below.
- After correcting the condition that caused the fault, let the engine warm up; then let the engine run for 1 minute to inactivate the fault code. Then, use INSITE™ for CENSE™ to clear the fault code.

Certain applications base vehicle operation on the status of the lamps, which are controlled by CENSE™. For the effect of fault codes/lamp activity, please refer to the OEM manual for the equipment being serviced.

CODE: 111

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 112

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 113

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 114

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 115

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 116

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 117

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 118

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 119

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 121

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 122

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 123

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 124

LAMP: Yellow

REASON: Left Bank Intake Manifold pressure is above the normal operating range (overboost).

EFFECT: No action taken.

ACTION: Refer to the High Intake Manifold Pressure symptom troubleshooting procedure.

CODE: 125

LAMP: None

REASON: Left Bank Intake Manifold Pressure is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Low Intake Manifold Pressure symptom troubleshooting procedure.

CODE: 126

LAMP: Yellow

REASON: Right Bank Intake Manifold Pressure is above the normal operating range (overboost).

EFFECT: No action taken.

ACTION: Refer to the High Intake Manifold Pressure symptom troubleshooting procedure.

CODE: 127

LAMP: None

REASON: Right Bank Intake Manifold Pressure is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Low Intake Manifold Pressure symptom troubleshooting procedure.

CODE: 131

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 132

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 133

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 134

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 135

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 141

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 143

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 144

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 145

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 147

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 148

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 151

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 153

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 154

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 155

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 158

LAMP: Engine Protection

REASON: Left Bank Rear Intake Manifold Temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the High Intake Manifold Temperature symptom troubleshooting procedure.

CODE: 162

LAMP: Engine Protection

REASON: Right Bank Rear Intake Manifold Temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the High Intake Manifold Temperature symptom troubleshooting procedure.

CODE: 165

LAMP: Engine Protection

REASON: Right Bank Rear Intake Manifold Temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the High Intake Manifold Temperature symptom troubleshooting procedure.

CODE: 211

LAMP: None

REASON: An OEM connected component is broadcasting failure code information.

EFFECT: No action taken.

ACTION: Refer to the appropriate OEM manual for assistance in troubleshooting this fault.

CODE: 214

LAMP: Engine Protection

REASON: Lubricating Oil Temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the High Oil Temperature symptom troubleshooting procedure.

CODE: 219

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 221

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 222

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 223

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 224

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 225

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 226

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 231

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 232

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 233

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 234

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 235

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 237

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 252

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 253

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 254

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 259

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 261

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 263

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 265

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 292

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 293

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 294

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 296

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 297

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 298

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 299

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 316

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 318

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 335

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 343

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 346

LAMP:

REASON: ECM powerdown, internal data store error.

EFFECT: The powerdown data is lost. The powerdown data includes maintenance monitor, current ECM and engine delta times, and past fault data.

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 349

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 384

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 415

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 418

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 422

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 423

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 426

LAMP: None

REASON: Data communication error over the J1939 Datalink Circuit.

EFFECT: No action taken.

ACTION: Refer to the Public Datalink Circuit, Procedure 019-026 for troubleshooting information.

CODE: 427

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 431

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 432

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 441

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 442

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 446

LAMP: None

REASON: RS422 Communication Failure.

EFFECT: No action taken.

ACTION: Refer to the OEM System Troubleshooting Manual.

CODE: 447

LAMP: None

REASON: The RPC (Remote Procedure Called) Number is not supported.

EFFECT: No action taken.

ACTION: Refer to the OEM System Troubleshooting Manual.

CODE: 448

LAMP: None

REASON: RPC (Remote Procedure Called) argument mismatch.

EFFECT: No action taken.

ACTION: Refer to the OEM System Troubleshooting Manual.

CODE: 449

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 451

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 452

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 455

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 467

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 468

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 471

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 472

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 473

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 487

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 489

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 511

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 514

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 524

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 527

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 528

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 529

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 551

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 553

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 554

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 555

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 611

LAMP: None

REASON: The engine was shut down without the proper cool down period.

EFFECT: No action taken.

ACTION: Refer to the Engine Hot Shutdown symptom troubleshooting procedure.

CODE: 612

LAMP: Red

REASON: The difference in Post-Filter Oil Pressure and Prefilter Oil Pressure indicates that the Lubrication Oil filters are restricted.

EFFECT: No action taken.

ACTION: Refer to the High Lubricating Oil Filter Restriction symptom troubleshooting procedure.

CODE: 616

LAMP: None

REASON: Left Bank Rear Turbocharger Compressor Inlet Temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the High Intake Air Temperature symptom troubleshooting procedure.

CODE: 621

LAMP: Yellow

REASON: Left Bank Cylinder No. 1 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 622

LAMP: Yellow

REASON: Left Bank Cylinder No. 2 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 623

LAMP: Yellow

REASON: Left Bank Cylinder No. 3 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 624

LAMP: Yellow

REASON: Left Bank Cylinder No. 4 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 625

LAMP: Yellow

REASON: Left Bank Cylinder No. 5 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 626

LAMP: Yellow

REASON: Left Bank Cylinder No. 6 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 627

LAMP: Yellow

REASON: Left Bank Cylinder No. 7 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 628

LAMP: Yellow

REASON: Left Bank Cylinder No. 8 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 631

LAMP: Yellow

REASON: Right Bank Cylinder No. 1 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 632

LAMP: Yellow

REASON: Right Bank Cylinder No. 2 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 633

LAMP: Yellow

REASON: Right Bank Cylinder No. 3 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 634

LAMP: Yellow

REASON: Right Bank Cylinder No. 4 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 635

LAMP: Yellow

REASON: Right Bank Cylinder No. 5 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 636

LAMP: Yellow

REASON: Right Bank Cylinder No. 6 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 637

LAMP: Yellow

REASON: Right Bank Cylinder No. 7 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 638

LAMP: Yellow

REASON: Right Bank Cylinder No. 8 exhaust temperature is below the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Power Low symptom troubleshooting procedure.

CODE: 641

LAMP: Red

REASON: Left Bank Cylinder No. 1 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 642

LAMP: Red

REASON: Left Bank Cylinder No. 2 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 643

LAMP: Red

REASON: Left Bank Cylinder No. 3 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 644

LAMP: Red

REASON: Left Bank Cylinder No. 4 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 645

LAMP: Red

REASON: Left Bank Cylinder No. 5 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 646

LAMP: Red

REASON: Left Bank Cylinder No. 6 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 647

LAMP: Red

REASON: Left Bank Cylinder No. 7 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 648

LAMP: Red

REASON: Left Bank Cylinder No. 8 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 649

LAMP: None

REASON: The lubricating oil requires changing.

EFFECT: No action taken.

ACTION: Change the lubricating oil. Refer to the Maintenance Procedures in the base engine Operation and Maintenance Manual. Reset the Oil Change Maintenance Monitor using INSITE™ for CENSE™.

CODE: 651

LAMP: Red

REASON: Right Bank Cylinder No. 1 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 652

LAMP: Red

REASON: Right Bank Cylinder No. 2 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 653

LAMP: Red

REASON: Right Bank Cylinder No. 3 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 654

LAMP: Red

REASON: Right Bank Cylinder No. 4 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 655

LAMP: Red

REASON: Right Bank Cylinder No. 5 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 656

LAMP: Red

REASON: Right Bank Cylinder No. 6 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 657

LAMP: Red

REASON: Right Bank Cylinder No. 7 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 658

LAMP: Red

REASON: Right Bank Cylinder No. 8 exhaust temperature is above the maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 659

LAMP: None

REASON: The fuel filter requires changing.

EFFECT: No action taken.

ACTION: Change the fuel filter. Refer to the Maintenance Procedures in the base engine operation and maintenance manual.

CODE: 661

LAMP: Yellow

REASON: Left Bank Cylinder No. 1 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 662

LAMP: Yellow

REASON: Left Bank Cylinder No. 2 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 663

LAMP: Yellow

REASON: Left Bank Cylinder No. 3 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 664

LAMP: Yellow

REASON: Left Bank Cylinder No. 4 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 665

LAMP: Yellow

REASON: Left Bank Cylinder No. 5 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 666

LAMP: Yellow

REASON: Left Bank Cylinder No. 6 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 667

LAMP: Yellow

REASON: Left Bank Cylinder No. 7 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 668

LAMP: Yellow

REASON: Left Bank Cylinder No. 8 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 669

LAMP: None

REASON: The coolant filter requires changing.

EFFECT: No action taken.

ACTION: Change the coolant filter. Refer to the Maintenance Procedures in the base engine operation and maintenance manual. Reset the Coolant Filter Maintenance Monitor using INSITE™ for CENSE™.

CODE: 679

LAMP: None

REASON: The coolant requires changing.

EFFECT: No action taken.

ACTION: Change the coolant. Refer to the Maintenance Procedures in the base engine operation and maintenance manual. Reset the Coolant Maintenance Monitor using INSITE™ for CENSE™.

CODE: 711

LAMP: Yellow

REASON: Right Bank Cylinder No. 1 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 712

LAMP: Yellow

REASON: Right Bank Cylinder No. 2 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 713

LAMP: Yellow

REASON: Right Bank Cylinder No. 3 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 714

LAMP: Yellow

REASON: Right Bank Cylinder No. 4 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 715

LAMP: Yellow

REASON: Right Bank Cylinder No. 5 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 716

LAMP: Yellow

REASON: Right Bank Cylinder No. 6 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 717

LAMP: Yellow

REASON: Right Bank Cylinder No. 7 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 718

LAMP: Yellow

REASON: Right Bank Cylinder No. 8 exhaust temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to the Single Cylinder Exhaust Temperature High symptom troubleshooting procedure.

CODE: 719

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 729

LAMP:

REASON:

EFFECT:

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 747

LAMP: None

REASON: The ECM trend data memory is 90 percent full.

EFFECT: No action taken.

ACTION: Use INSITE™ for CENSE™ to read and clear the ECM trend data. For instructions on reading ECM trend data, refer to the INSITE™ for CENSE™ User's Manual.

CODE: 748

LAMP: None

REASON: The ECM trend data memory is full.

EFFECT: No action taken.

ACTION: Use INSITE™ for CENSE™ to read and clear the ECM trend data. For instructions on reading ECM trend data, refer to the INSITE™ for CENSE™ User's Manual.

CODE: 749

LAMP: None

REASON: The ECM fault code datalog is 90 percent full.

EFFECT: No action taken.

ACTION: Use INSITE™ for CENSE™ to clear inactive fault codes. For instructions on clearing inactive fault codes, refer to the INSITE™ for CENSE™ User's Manual. NOTE: Troubleshoot all fault codes before erasing the inactive fault codes.

CODE: 753

LAMP: Yellow

REASON: Engine position signal detected on pins 27, 28 and 37, 38 of the ECM do not match.

EFFECT: No action taken.

ACTION: Refer to Troubleshooting and Repair Manual, QSK Fuel System, QSK19, QSK45, QSK60 and QSK78 Series Engines, Bulletin No. 3666113, for symptom troubleshooting procedure.

CODE: 754

LAMP: None

REASON: The ECM fault code datalog is full.

EFFECT: No action taken.

ACTION: Use INSITE™ for CENSE™ to clear inactive fault codes. For instructions on clearing inactive fault codes, refer to the INSITE™ for CENSE™ User's Manual. NOTE: Troubleshoot all fault codes before erasing the inactive fault codes.

CODE: 756

LAMP: None

REASON: The lubricating oil filters require changing.

EFFECT: No action taken.

ACTION: Change the lubricating oil filters. Refer to the Maintenance Procedures in the base engine Operation and Maintenance Manual. Reset the Lubricating Oil Filter Maintenance Monitor using INSITE™ for CENSE™.

CODE: 757

LAMP: None

REASON: The ECM power was disconnected while the engine was running.

EFFECT: No action taken.

ACTION: Inspect the OEM wiring and CENSE wiring for evidence of bad wiring or tampering.

CODE: 777

LAMP: Yellow

REASON: The turbo inlet air temperature has exceeded the standard ambient air temperature limit.

EFFECT: The engine will derate until the turbo inlet air temperature drops to normal.

ACTION: Inspect the air intake for blockage, proximity to any heating elements, or proximity to the exhaust.

CODE: 783

LAMP: Engine Protection

REASON: Rapid rise in intake manifold temperature in the left bank front quadrant from QUANTUM™.

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Air Temperature Is High (Rapid Rise) symptom troubleshooting procedure.

CODE: 1000

LAMP: None

REASON: The vehicle control system initiated a fault code datalog.

EFFECT: No action taken.

ACTION: Refer to the OEM service manuals for information on this fault code.

CODE: 2144

LAMP: Red

REASON: Left bank cylinder No. 9 exhaust temperature is above maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to Exhaust Temperature is High (Single Cylinder) troubleshooting procedure.

CODE: 2145

LAMP: Red

REASON: Right bank cylinder No. 9 exhaust temperature is above maximum allowable value.

EFFECT: No action taken.

ACTION: Refer to Exhaust Temperature is High (Single Cylinder) troubleshooting procedure.

CODE: 2148

LAMP: Yellow

REASON: Left bank cylinder No. 9 exhaust temperature is above normal operating range.

EFFECT: No action taken.

ACTION: Refer to Exhaust Temperature is High (Single Cylinder) troubleshooting procedure.

CODE: 2149

LAMP: Yellow

REASON: Right bank cylinder No. 9 exhaust temperature is above normal operating range.

EFFECT: No action taken.

ACTION: Refer to Exhaust Temperature is High (Single Cylinder) troubleshooting procedure.

CODE: 2151

LAMP: Yellow

REASON: Left bank cylinder No. 9 exhaust temperature is below normal operating range.

EFFECT: No action taken.

ACTION: Refer to Exhaust Temperature is Low (Single Cylinder) troubleshooting procedure.

CODE: 2152

LAMP: Yellow

REASON: Right bank cylinder No. 9 exhaust temperature is above normal operating range.

EFFECT: No action taken.

ACTION: Refer to Exhaust Temperature is Low (Single Cylinder) troubleshooting procedure.

CODE: 2157

LAMP: Red

REASON: Rapid rise in intake manifold temperature in the left bank rear quadrant.

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Air Temperature Is High (Rapid Rise) symptom troubleshooting procedure.

CODE: 2158

LAMP: Red

REASON: Rapid rise in intake manifold temperature in the right bank front quadrant.

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Air Temperature Is High (Rapid Rise) symptom troubleshooting procedure.

CODE: 2159

LAMP: Red

REASON: Rapid rise in intake manifold temperature in the right bank rear quadrant.

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Air Temperature Is High (Rapid Rise) symptom troubleshooting procedure.

CODE: 2161

LAMP: None

REASON: Right bank rear turbocharger compressor inlet temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Air Temperature Is High symptom troubleshooting procedure.

CODE: 2241

LAMP: Red

REASON: Left bank middle intake manifold temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Air Temperature Is High symptom troubleshooting procedure.

CODE: 2244

LAMP: Red

REASON: Rapid rise in intake manifold temperature in the left bank middle cylinders.

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Air Temperature Is High (Rapid Rise) symptom troubleshooting procedure.

CODE: 2245

LAMP: Red

REASON: Right bank middle intake manifold temperature is above the normal operating range.

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Air Temperature Is High symptom troubleshooting procedure.

CODE: 2248

LAMP: Red

REASON: Rapid rise in intake manifold temperature in the right bank middle cylinders.

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Air Temperature Is High (Rapid Rise) symptom troubleshooting procedure.

CODE: 2251

LAMP: None

REASON: Front intercooler air pressure is above normal operating range (over boost).

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Air Temperature Is High symptom troubleshooting procedure.

CODE: 2252

LAMP: None

REASON: Front intercooler air pressure is below the normal operating range (over boost).

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Pressure (Boost) Is Below Normal symptom troubleshooting procedure.

CODE: 2255

LAMP: None

REASON: Rear intercooler air pressure is above the normal operating range (over boost).

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Pressure Is High symptom troubleshooting procedure.

CODE: 2256

LAMP: None

REASON: Rear intercooler air pressure is below the normal operating range (over boost).

EFFECT: No action taken.

ACTION: Refer to Intake Manifold Pressure (Boost) Is Below Normal symptom troubleshooting procedure.

Last Modified: 26-Aug-2003
