ACME DEVICE C — MAINTENANCE MANUAL (SCANNED COPY)

Section 1: Overview

Device C is a legacy industrial sensor unit manufactured in 2018.
This manual has been scanned from the original printed document.

Section 2: Installation

---

1. Mount the unit on a flat, stable surface.
2. Connect the power cable to the 12V DC input port.
3. Attach the sensor leads to terminals A and B.
4. Press and hold the RESET button for 3 seconds to initialise.

Section 3: Error Codes

Error 201 - Sensor overload. Disconnect power and wait 30 seconds.
Error 202 - Communication timeout. Check cable connections.
Error 203 - Internal temperature exceeded 85C. Allow unit to cool.

Section 4: Maintenance Schedule

Monthly: Clean sensor head with dry cloth.
Annually: Replace internal battery (model CR2032).
          Recalibrate using the ACME Calibration Tool v3.

Section 5: Support

Contact ACME support at support@acme-devices.com
or call 1-800-ACME-DEV (Mon-Fri, 9am-5pm EST).