STUDENT PROJECTS LABORATORY - 930 KINNEAR RD

STANDARD OPERATING PROCEDURE (SOP) | ASSET: FAB-01 | TAG: 15-015M1

FAB-01: General International 15-015M1 6"x48" Belt / 12" Disc Sander

Facility Zone: Zone 5: Fabrication, Sheet Metal & Abrasive Finishing (FAB) | Supervisor: Max Wright (Sr. Instructional Lab Supervisor)

CRITICAL ENTANGLEMENT WARNING: STRICTLY NO GLOVES WHILE SPINDLE / BLADE IS ROTATING

1. REQUIRED PERSONAL PROTECTIVE EQUIPMENT (PPE)

1. ANSI Z87.1 Safety Goggles + Full Face Shield
2. Hearing Protection (>90 dB Operating Noise)
3. NO GLOVES STRICTLY PROHIBITED (Severe Entanglement Hazard in 1/16" Table Gap)

2. PRIMARY OPERATIONAL HAZARDS

1. Fingers/gloves pulled into >1/16" gap between work table and abrasive belt/disc
2. Workpiece violent upward kickback if sanding on upward-travel (right) side of 12" disc
3. Abrasive dust inhalation and hot spark hazard

3. BEFORE OPERATION CHECKLIST

1. Verify work table-to-belt and table-to-disc gap is strictly <= 1/16" (0.0625").
2. Verify abrasive belt tracking and open dust collection blast gates.

4. DURING OPERATION SAFETY RULES

1. Always sand on the DOWNWARD-TRAVEL (LEFT) SIDE of the 12" disc to press stock onto table and prevent kickback.
2. Keep hands >= 4" away from belt/disc (use push stick for small parts and V-block for round stock).
3. NEVER wear gloves while operating sander.

5. AFTER USE & SHOWROOM CLEANUP

1. Wait for belt and disc to stop completely before cleaning area.

EMERGENCY SHUTDOWN & INCIDENT PROTOCOL:

Hit red front OFF switch immediately; if stock jams in gap, do NOT attempt to free until LOTO is applied.