STUDENT PROJECTS LABORATORY - 930 KINNEAR RD

STANDARD OPERATING PROCEDURE (SOP) | ASSET: FAC-02 | TAG: FAC-AIR-02

FAC-02: Shop Compressed Air System & Distribution Drops

Facility Zone: Zone 6: Facility & Infrastructure (FAC) | Supervisor: Max Wright (Sr. Instructional Lab Supervisor)

1. REQUIRED PERSONAL PROTECTIVE EQUIPMENT (PPE)

1. ANSI Z87.1 Safety Glasses
2. Hearing Protection in Compressor Room

2. PRIMARY OPERATIONAL HAZARDS

1. High-pressure hose whip if disconnected under load
2. Compressed air embolism hazard-NEVER direct compressed air at skin or clothing
3. STRICTLY NO compressed air blowdown on manual/CNC mills or lathes

3. BEFORE OPERATION CHECKLIST

1. Verify local drop regulator is set to machine specification (80-100 PSI) and inspect quick-connect coupler.

4. DURING OPERATION SAFETY RULES

1. Hold hose end firmly when disconnecting self-venting safety couplers.

5. AFTER USE & SHOWROOM CLEANUP

1. Close local drop ball valves on welding, plasma, and blast cabinet stations after use.

EMERGENCY SHUTDOWN & INCIDENT PROTOCOL:

Close local drop ball valve or main receiver header valve and notify Lab Supervisor.