STUDENT PROJECTS LABORATORY - 930 KINNEAR RD

STANDARD OPERATING PROCEDURE (SOP) | ASSET: SAW-01 | TAG: VSAW-01

SAW-01: Vertical Metal Cutting Bandsaw

Facility Zone: Zone 4: Cutting, Saws & Drilling (SAW) | Supervisor: Max Wright (Sr. Instructional Lab Supervisor)

CRITICAL ENTANGLEMENT WARNING: STRICTLY NO GLOVES WHILE SPINDLE / BLADE IS ROTATING

1. REQUIRED PERSONAL PROTECTIVE EQUIPMENT (PPE)

1. ANSI Z87.1 Safety Glasses
2. Closed-Toe Shoes
3. NO GLOVES While Feeding Workpiece Near Moving Blade

2. PRIMARY OPERATIONAL HAZARDS

1. Exposed vertical saw blade laceration/amputation hazard
2. Round stock spinning/kickback if not clamped in V-block
3. Gearbox tooth stripping if shifted at high RPM

3. BEFORE OPERATION CHECKLIST

1. Adjust upper blade guard to within 1/4" of top of workpiece.
2. Verify blade tension and proper SFPM speed for material.
3. NEVER shift transmission gear at high RPM (must drop RPM dial as low as possible first).

4. DURING OPERATION SAFETY RULES

1. Keep hands at least 4 inches away from blade path at all times.
2. Use push stick for small stock and a V-block/clamp for ALL round stock.
3. Make relief cuts before cutting tight radius curves.

5. AFTER USE & SHOWROOM CLEANUP

1. Wait for complete blade coast-down (never brake wheel or blade with hands).
2. Sweep and vacuum swarf from table and lower cabinet (no compressed air).

EMERGENCY SHUTDOWN & INCIDENT PROTOCOL:

Hit red OFF paddle switch on left column and step back until blade stops.