STUDENT PROJECTS LABORATORY - 930 KINNEAR RD

STANDARD OPERATING PROCEDURE (SOP) | ASSET: SAW-05 | TAG: JET-DP-01

SAW-05: JET Industrial Floor Drill Presses

Facility Zone: Zone 4: Cutting, Saws & Drilling (SAW) | Supervisor: Max Wright (Sr. Instructional Lab Supervisor)

CRITICAL ENTANGLEMENT WARNING: STRICTLY NO GLOVES WHILE SPINDLE / BLADE IS ROTATING

1. REQUIRED PERSONAL PROTECTIVE EQUIPMENT (PPE)

1. ANSI Z87.1 Safety Glasses
2. NO GLOVES on Drill Press (Rotating Spindle Entanglement Hazard)
3. Hair & Loose Sleeves Secured

2. PRIMARY OPERATIONAL HAZARDS

1. Severe entanglement hazard if wearing gloves, long hair, or loose sleeves
2. Workpiece helicopter spin if not clamped to drill press table
3. Chuck key ejection if left in drill chuck

3. BEFORE OPERATION CHECKLIST

1. Clamp ALL workpieces securely to table or drill press vise.
2. Remove chuck key immediately after tightening bit.
3. Verify drill speed pulley setting matches drill bit diameter and material.

4. DURING OPERATION SAFETY RULES

1. Keep hands >= 4 inches from rotating chuck and drill bit.
2. Back out drill bit periodically to clear long stringy chips.

5. AFTER USE & SHOWROOM CLEANUP

1. Never brake rotating spindle or chuck by hand.
2. Brush chips from drill table and return drill bits and chuck key to rack.

EMERGENCY SHUTDOWN & INCIDENT PROTOCOL:

Flip front paddle switch OFF immediately and step back if workpiece binds.