STUDENT PROJECTS LABORATORY - LOCKOUT / TAGOUT [LOTO] PROCEDURE

ENERGY ISOLATION SPECIFICATION | ASSET: CNC-01 | TAG: 01168375

KIA 3-Axis CNC Vertical Machining Center

Authorized LOTO Personnel: Sr. Instructional Lab Supervisor (Max Wright) & Student Research Assistants (SRAs)

Notification Channel: Max Wright - Teams / Text Message | Zone: Zone 2: CNC Machining (CNC)

STEP 1 - NORMAL MACHINE SHUTDOWN PROCEDURE

Depress red OFF button (Front Control Panel), turn main power switch counterclockwise to OFF (Right Rear Control Panel).

STEP 2 - HAZARDOUS ENERGY SOURCES, MAGNITUDES & ISOLATION POINTS

Source #1: Electrical (240V AC 3-Phase)

Isolation Location: Circuit panel on North Wall (Breaker 1-3-5).

Lockout Procedure: Switch Breaker 1-3-5 to OFF and apply Snap-On Circuit Breaker Lockout with LOTO padlock and tag.

STEP 3 - STORED / RESIDUAL ENERGY DISSIPATION

Ensure Z-axis head is resting in safe position and spindle is completely stopped.

STEP 4 - ZERO-ENERGY VERIFICATION ('TRY' STEP)

Turn power switch on left side to ON and verify no lights illuminate on control pendant.