STUDENT PROJECTS LABORATORY - LOCKOUT / TAGOUT [LOTO] PROCEDURE

ENERGY ISOLATION SPECIFICATION | ASSET: MAC-04 | TAG: SHARP-LATHE-01

Sharp Manual Engine Lathe

Authorized LOTO Personnel: Sr. Instructional Lab Supervisor (Max Wright) & Student Research Assistants (SRAs)

Notification Channel: Max Wright - Teams / Text Message | Zone: Zone 1: Manual Machining (MAC)

STEP 1 - NORMAL MACHINE SHUTDOWN PROCEDURE

Power switch to OFF position (Bottom left front face).

STEP 2 - HAZARDOUS ENERGY SOURCES, MAGNITUDES & ISOLATION POINTS

Source #1: Electrical (240V AC)

Isolation Location: Disconnect switch to the left of machine on wall.

Lockout Procedure: Pull switch box lever down to OFF position & install LOTO padlock through lever.

STEP 3 - STORED / RESIDUAL ENERGY DISSIPATION

Depress foot brake and allow chuck/spindle to come to a complete standstill.

STEP 4 - ZERO-ENERGY VERIFICATION ('TRY' STEP)

Press black power button / verify spindle does not power on.