STUDENT PROJECTS LABORATORY - 930 KINNEAR RD

STANDARD OPERATING PROCEDURE (SOP) | ASSET: FAB-02 | TAG: G0767-01

Grizzly G0767 4"x79" Tube & Pipe Notcher

Facility Zone: Zone 5: Fabrication, Sheet Metal & Abrasive Finishing (FAB) | Supervisor: Max Wright (Sr. Instructional Lab Supervisor)

CRITICAL ENTANGLEMENT WARNING: STRICTLY NO GLOVES WHILE SPINDLE / BLADE IS ROTATING

1. REQUIRED PERSONAL PROTECTIVE EQUIPMENT (PPE)

1. ANSI Z87.1 Safety Goggles + Face Shield
2. Hearing Protection
3. NO GLOVES When Operating Grizzly G0767 Tube Notcher (5,900 FPM Belt Hazard)

2. PRIMARY OPERATIONAL HAZARDS

1. 2 HP motor driving abrasive belt at 5,900 FPM; severe entanglement hazard
2. Extreme thermal heat buildup in notched steel/chromoly tubing

3. BEFORE OPERATION CHECKLIST

1. Match grinding mandrel roller precisely to tube OD and lock quick-release vise (0-30 deg angle).
2. Inspect 4"x79" grinding belt for tears or fraying.

4. DURING OPERATION SAFETY RULES

1. Stand to the side of the Grizzly G0767 during startup.
2. Feed tube steadily via feed handwheel and keep hands >= 4" from moving belt.
3. Allow notched tubing to cool before handling.

5. AFTER USE & SHOWROOM CLEANUP

1. Power down machine, brush away grinding grit, and return mandrel rollers to rack.

EMERGENCY SHUTDOWN & INCIDENT PROTOCOL:

Slam large red paddle OFF button on left side of G0767 Notcher.