STUDENT PROJECTS LABORATORY - 930 KINNEAR RD

STANDARD OPERATING PROCEDURE (SOP) | ASSET: SAW-02 | TAG: 747061

Horizontal Wet/Dry Drop Bandsaw

Facility Zone: Zone 4: Cutting, Saws & Drilling (SAW) | Supervisor: Max Wright (Sr. Instructional Lab Supervisor)

CRITICAL ENTANGLEMENT WARNING: STRICTLY NO GLOVES WHILE SPINDLE / BLADE IS ROTATING

1. REQUIRED PERSONAL PROTECTIVE EQUIPMENT (PPE)

1. ANSI Z87.1 Safety Glasses
2. Closed-Toe Shoes (Steel-Toe Recommended for Heavy Bar Stock)
3. Leather Gloves ONLY While Loading Raw Bar Stock (Remove Before Running)

2. PRIMARY OPERATIONAL HAZARDS

1. Blade splitting/whipping hazard on right side of machine
2. Crushing hazard under dropping saw head or falling cut stock
3. Tooth stripping on thin-wall tubing (<1/8" wall)

3. BEFORE OPERATION CHECKLIST

1. Minimum stock length is 4 inches (stock under 4" requires Shop Supervisor/SRA approval & custom fixturing).
2. NO thin-wall tubing under 1/8" wall thickness.
3. Verify coolant pump intake is submerged and adjust left blade guard close to soft jaw.

4. DURING OPERATION SAFETY RULES

1. DO NOT stand to the right side of the machine (blade splitting hazard zone).
2. Clamp stock securely with soft jaw and vise handwheel.
3. Ease saw head down gently into initial cut using hydraulic feed control.

5. AFTER USE & SHOWROOM CLEANUP

1. Wait for complete blade stop, release vise gently so heavy stock does not drop to floor, and clean chips with brush/vacuum.

EMERGENCY SHUTDOWN & INCIDENT PROTOCOL:

Hit red E-Stop / OFF switch and close hydraulic downfeed cylinder valve immediately.