

Falcon Service Manual (3rd Edition)

Document: MAN-FAL-3

Type: Manual

Model: Falcon

Published: 2019-03-01

1 Engine

Service procedures for the 2.0T and 1.6 litre engine families.

1.1 Ignition System Overview

The 2.0T engine uses one coil-on-plug ignition coil (part IC-2042-A) per cylinder with spark plug set SP-1108. Coils are matched to the engine calibration.

1.2 Ignition Coil Replacement

Remove the engine cover and disconnect the coil connector. Replace ignition coil IC-2042-A as an assembly. Applies to misfire codes P0301 and P0300 after plug condition is confirmed.

1.3 Misfire Diagnosis

For codes P0300 and P0301, swap coils between cylinders and retest. If the misfire follows the coil, replace it. Inspect spark plug set SP-1108 for gap and fouling.

1.4 Exhaust and Catalyst

Catalyst efficiency code P0420 requires upstream and downstream oxygen sensor comparison before replacing catalytic converter CAT-5500.

2 Electrical

Charging, battery, and control module service.

2.1 Charging System

Test alternator ALT-8810 output under load before replacing battery BAT-1200. Code P0562 indicates system voltage below threshold.

2.2 Engine Control Module

Engine control module ECM-9901 must be programmed with the latest calibration after replacement.

3 Brakes

Brake system inspection and service.

3.1 Brake Pad Service

Replace front pads with brake pad kit BP-7720. Measure rotor thickness before reuse.