

DELFT UNIVERSITY OF TECHNOLOGY

MASTER THESIS

THREE MONTH REPORT

Author:

Serwan Asaad

Supervisor:

Dr. Alessandro Bruno

January 6, 2015

Contents

1	Resonators	3
1.1	Coplanar waveguide	4
1.2	Quality factor	4
1.3	Losses	5
1.3.1	Causes of loss	5
1.3.1.1	Two-level systems	5
1.3.1.2	Quasiparticles	6
1.3.1.3	Radiation	7
1.3.1.4	7
1.3.2	Loss channels	7
1.3.3	Combatting losses	7
1.3.3.1	Infrared shielding	7
1.3.3.2	Surface treatment	7
1.3.3.3	Deep-reactive ion etching	7
1.4	Results	7
2	Measurements	8
2.1	Heterodyne detection	8
2.2	Vector network analyzer	8
3	Noise	9
3.1	Noise sources	9
3.1.1	Johnson noise	9
3.1.2	Shot noise	9
3.1.3	1/f noise	9
3.2	Noise temperature	9

INTRODUCTION

The subject of my Master's thesis will be on ways of improving T1 and T2 coherence times for qubits. The past few months I have been learning about superconducting circuit quantum electrodynamics. I have learned what set-ups are used for performing measurements on cQED samples, and about the types of measurements that are performed.

Traditionally the measurements were performed using Labview software. However, in the months that I have been working in the DiCarlo lab, a transition in measurement software has taken place from Labview to the Python-based QTLab. I have been very involved in this transition, as an important part of my research will be to characterize a sample quickly and accurately. This will enable a fast cycle from sample fabrication to characterization, hopefully leading to rapid progress in the development of quantum computing using cQED.

The past few weeks the focus of my measurements has shifted towards the characterization of resonators. This is largely due to the fact that two of my colleagues, Alessandro Bruno and Gijs de Lange, are working on a paper on ways of improving the quality factor of resonators. A large part of the data was already obtained before I joined the group, but a last set of measurements was required at the dilution refrigerator I most often operate at. The reason is that its base temperature is at 15 mK, which is considerably lower than the base temperature of the refrigerator at which the other measurements were performed, namely 250 mK. Because my focus so far has been more on resonators than of qubits, the main topic of this report will be on resonators, and will include the topic of qubits in my final thesis.

As I have spent a large part of my time at the lab performing measurements, I would also like to discuss this topic in my three month report. I will treat the types of set-up I have used so far, and the techniques used for measuring resonators.

Because the relevant regime where resonators interact with qubits is the single-photon regime, a very weak signal must be applied to determine its properties in that regime. At this point noise becomes a relevant issue. I will therefore also devote a section of this report on the subject of noise.

Chapter 1

Resonators

Topics:

- Center frequency
- Temperature dependence
- Kinetic inductance
- shift of resonance frequency due to trapped vortices
 - Trapped vortices cause parts to be non-superconducting
 - Combatting trapped vortices with grid-like structure
- photon number
- Material (Silicon, sapphire)
- Superconducting material NbTiN
- Asymmetry (can refer to [7, p. 192])

Types of resonators studied:

- Halfmon
- DRIE resonators

When a signal enters a fridge it is attenuated in several stages and eventually enters the sample being measured. In the sample the signal travels through a feedline. One or more resonators can then be capacitively coupled to the feedline. Qubits can then also be capacitively coupled to the resonators, and a resonator can even be used to connect qubits, a so-called 'bus'. However in this report only discuss the resonators connected to a central feedline will be discussed.

1.1 COPLANAR WAVEGUIDE

In the context of circuit QED, one of the most common types of resonators are coplanar waveguides (CPW). Coplanar waveguides consist of a long central conducting track, with on both sides a neighbouring grounded track. The conducting track is separated from the grounded tracks by a fixed distance.

One end is usually capacitively coupled to a feedline and has an open end, while the other end can either be open or shorted. This determines whether the resonant frequencies have a node or an antinode at that end. In the case of a shorted end, the resonant frequencies have a node at that end, resulting in a $1/4 - \lambda$ resonator. This means that the wavelength fundamental mode fits $1/4$ times into the resonator. In the case of an open end, the resonant frequencies have an antinode at that end, resulting in a $1/2\lambda$ resonator.

1.2 QUALITY FACTOR

One important property of a resonator is its quality factor. Generally speaking, the quality factor of a resonator determines the ratio between energy stored in a resonator and the energy leaking away from the resonator. For cQED resonators this corresponds to the rate at which photons dissipate from the resonator. A high quality factor corresponds to a low dissipation rate.

The quality factor can also be defined as [10, p. 23]:

$$Q = \omega_0 \tau_1 \quad (1.1)$$

Here ω_0 is the resonance frequency of the resonator, and τ_1 is the decay time of the resonator. The decay time is the time taken by a resonator to dissipate its energy to $1/e$ of its original energy. One can see that this definition is in accordance with the first definition, as the energy is related to frequency through the Planck-Einstein relation: $E = \hbar\nu$, and therefore increases with increasing frequency.

$$Q = \omega_0 / \Delta\omega \quad (1.2)$$

Photons can dissipate from the resonator through its different loss channels. Each of these loss channels has a corresponding quality factor. One such loss channel is due to resonators in cQED being capacitively coupled to a feedline. The quality factor associated to this loss channel is known as the coupling quality factor Q_c . This coupling quality factor depends on the amount of capacitive coupling between the resonator and the feedline. It can therefore be engineered to have a certain value, depending on the amount of interaction wanted between resonator and feedline.

The other loss channels are usually unwanted, and therefore desired to be as low as possible. These individual channels are usually lumped together, resulting in a combined quality factor, known as the intrinsic quality factor Q_i .

The total quality factor of the resonator is known as the loaded quality factor Q_l . It is related to Q_c and Q_i through:

$$\frac{1}{Q_l} = \frac{1}{Q_c} + \frac{1}{Q_i} \quad (1.3)$$

From equation 1.3 it can be seen that if the difference between Q_c and Q_i is large, then the loaded quality factor Q_l will be approximately equal to the minimum of the two.

For a $1/4 - \lambda$ resonator the amplitude of transmission has a minimum S_{21}^{min} , given by [10, p. 29]:

$$S_{21}^{min} = \frac{Q_c}{Q_c + Q_i} \quad (1.4)$$

With knowledge of the resonant frequency ω_0 , the resonant width $\Delta\omega$, and the transmitted signal at resonance S_{21}^{min} , it is possible through equations 1.2 and 1.4 to determine both the coupling quality factor Q_c and the intrinsic quality factor Q_i . Note that as equation 1.4 depends on the ratio of the two quality factors, to get an accurate estimate of both quality factors, they should have a comparable value.

- tan delta: loss channels, sum?
- Photon number dependence
- nonlinear effects (can refer to [1])

1.3 LOSSES

When a resonator is being driven at its resonance frequency, it is absorbing photons from the external source. When this external driving stops, the resonator slowly loses its photons through its different loss channels.

One loss channel was already discussed in section 1.2, namely through the coupling to the feedline. This loss channel is not unwanted, as the amount of coupling to the feedline determines how fast the resonator and feedline can interact with each other. The other loss channels, however, are unwanted. They cause dissipation of information. Some of the main causes of loss will be discussed in this section.

1.3.1 Causes of loss

1.3.1.1 Two-level systems

Two-level systems (TLS) are systems which can be in a ground state or an excited state. In some cases they can be useful, such as in the case of a qubit. In other cases, however, TLS can also be a source of dissipation. In cQED TLS which cause dissipation are most often oxides residing in amorphous materials (TODO: ref). In fact, study suggests that most TLS reside in a thin oxide layer at the interface between two substances (TODO: ref).

Resonators are surrounded by a large quantity of TLS, each of which has its own resonance frequency, depending on its energy landscape. When the resonance frequency of a TLS is close to that of the resonator, it can absorb a photon from the resonator, upon which it

tunnels to an excited meta-stable state. TLS have a finite lifetime in their excited state, after which they decay back to their ground state.

In the low power, low temperature regime, TLS reside mostly in their ground state, and only occasionally tunnel to the excited state, upon absorption of a photon. It is theorized that, in this regime, TLS are the main source of dissipation for resonators [6]. At higher powers and/or temperatures, TLS will tunnel to an excited state at a higher rate. Due to their finite lifetime they become saturated at a certain point. Since the quality factor depends on the ratio between energy stored and energy dissipated, when the TLS are saturated the amount of dissipation is limited, while the energy stored can still increase. Therefore, in the low power, low temperature regime, increasing either of the two parameters results in an increase in quality factor. At a certain point, however, further increasing either of the two will not improve the quality factor. This is due to other effects dominating in these regimes.

- To our knowledge, dielectric loss at low temperature arises from the presence of two-level states (TLS) formed by random bonds that tunnel between two sites. [9]
- 1/f noise [3]
- Dielectric materials (Table [9])

1.3.1.2 Quasiparticles

Another source of dissipation for resonators is due to quasiparticles being present in the superconducting layer. When a Cooper-pair is broken up, Bogoliubov quasiparticles are formed. These quasiparticles can have either electron-like or hole-like properties. Quasiparticles are a source of dissipation for resonators, since they are non-superconducting and therefore cause the surface impedance to be slightly resistive [10, p. 18].

The breaking up of Cooper-pairs is due to excitations. These excitations can either be thermal, or due to photon absorption. Therefore an increase in temperature or an increase in photon density will result in a higher density of quasiparticles.

- Quasiparticle excitation energy $E = \xi^2 + \Delta^2$, where ξ is the energy of the single particle in the normal state relative to the Fermi energy [2]
- Increases with increasing frequency
- Decreases exponentially as the temperature decreases [10]
- Quasiparticles are created through thermal excitation, but can also be excited by photons with $h\nu > 2\Delta$ [5]
- Quasiparticles change the surface impedance of resonators, which can be measured. This technique is used to create MKID detectors [5]
- "[Surface impedance] change is caused by quasiparticles blocking the Cooper pairs from occupying some of the electron states (through the exclusion principle), which modifies the effective pairing energy and reduces the density of pairs." [10, p. 3]

1.3.1.3 Radiation

A third source of dissipation is due to radiation from the resonator. This radiation is due to the spontaneous emission of photons.

The amount of dissipation due to radiation is directly related through [11, 10]:

$$Q_{rad} = \alpha \left(\frac{L}{S + W} \right)^{n_r} \quad (1.5)$$

In this formula S is the distance between the conducting and grounded track, W is the width of the conducting track, α depends on properties such as impedance and the dielectric constant of the substrate. From Formula 1.5 it is clear that a decrease of the conducting track width or the distance between tracks leads to an increase in Q_{rad} . However, with a decrease of either of the two parameters, the field strength close to the resonator becomes higher. If the TLS are not saturated (i.e. low power and temperature), this will increase the amount of dissipation through TLS. Therefore it is not necessarily advantageous to minimize S and W .

Radiation loss becomes the dominant source of dissipation at high powers and/or temperatures, but otherwise usually is not the limiting factor. Since measurements relevant for quantum computing are usually operated at low power and temperature, this source of dissipation is usually less important than other sources, such as TLS dissipation.

- Possible other useful sources: [4] [8]

1.3.1.4

1.3.2 Loss channels

1.3.3 Combatting losses

1.3.3.1 Infrared shielding

- Decrease of quasiparticle density by infrared shielding.

1.3.3.2 Surface treatment

1.3.3.3 Deep-reactive ion etching

1.4 RESULTS

- Power dependence
- Temperature dependence
 - Quality factor
 - Center frequency
 - * Shift at lowest temperature could be due to TLS [7, p. 91]

Chapter 2

Measurements

2.1 HETERODYNE DETECTION

- Idea to also obtain complex signal

2.2 VECTOR NETWORK ANALYZER

- Complex signal

Chapter 3

Noise

3.1 NOISE SOURCES

3.1.1 Johnson noise

3.1.2 Shot noise

3.1.3 1/f noise

- Two-level systems

3.2 NOISE TEMPERATURE

- Formula for noise temperature
- Show plot of noise temperature
- Explain why first amplifier is most important

Bibliography

- [1] Baleegh Abdo, Eran Segev, Oleg Shtempluck, and Eyal Buks. Nonlinear dynamics in the resonance line shape of nbn superconducting resonators. *Physical Review B*, 73(13):134513, 2006.
- [2] Rami Barends. *Photon-detecting superconducting resonators*. PhD thesis, Delft University of Technology, 2009.
- [3] J Burnett, L Faoro, I Wisby, VL Gurtovoi, AV Chernykh, GM Mikhailov, VA Tulin, R Shaikhaidarov, V Antonov, PJ Meeson, et al. Evidence for interacting two-level systems from the $1/f$ noise of a superconducting resonator. *arXiv preprint arXiv:1311.1655*, 2013.
- [4] EJ Denlinger. Radiation from microstrip resonators (correspondence). *Microwave Theory and Techniques, IEEE Transactions on*, 17(4):235–236, 1969.
- [5] Jiansong Gao. *The Physics of Superconducting Microwave Resonators*. PhD thesis, California Institute of Technology, 2008.
- [6] Jiansong Gao, Miguel Daal, Anastasios Vayonakis, Shwetank Kumar, Jonas Zmuidzinas, Bernard Sadoulet, Benjamin A Mazin, Peter K Day, and Henry G Leduc. Experimental evidence for a surface distribution of two-level systems in superconducting lithographed microwave resonators. *Applied Physics Letters*, 92(15):152505–152505, 2008.
- [7] Kurtis L. Geerlings. *Improving Coherence of Superconducting Qubits and Resonators*. PhD thesis, Yale University, 2013.
- [8] Moe S Khalil, FC Wellstood, and Kevin D Osborn. Loss dependence on geometry and applied power in superconducting coplanar resonators. *Applied Superconductivity, IEEE Transactions on*, 21(3):879–882, 2011.
- [9] John M Martinis and A Megrant. Ucsb final report for the csq program: Review of decoherence and materials physics for superconducting qubits. *arXiv preprint arXiv:1410.5793*, 2014.
- [10] Benjamin A. Mazin. *Microwave Kinetic Inductance Detectors*. PhD thesis, California Institute of Technology, 2004.

-
- [11] Jeremy M Sage, Vladimir Bolkhovsky, William D Oliver, Benjamin Turek, and Paul B Welanders. Study of loss in superconducting coplanar waveguide resonators. *Journal of Applied Physics*, 109(6):063915, 2011.