

Harfler				F TUŞLARI				SİSTEM TUŞLARI			Sayılar			OK TUŞLARI			NUMPAD		
HID	Tuş	VK		HID	Tuş	VK		HID	Tuş	VK	HID	Tuş	VK	HID	Tuş	VK	HID	Tuş	VK
0x04	A	0x41		0x3A	F1	0x70		0x29	ESC	0x1B	0x1E	1	0x31	0x4F	Sağ	0x27	0x54	/	0x6F
0x05	B	0x42		0x3B	F2	0x71		0x2A	Backspace	0x08	0x1F	2	0x32	0x50	Sol	0x25	0x55	*	0x6A
0x06	C	0x43		0x3C	F3	0x72		0x2B	Tab	0x09	0x20	3	0x33	0x51	Aşağı	0x28	0x56	-	0x6D
0x07	D	0x44		0x3D	F4	0x73		0x28	Enter	0x0D	0x21	4	0x34	0x52	Yukarı	0x26	0x57	+	0x6B
0x08	E	0x45		0x3E	F5	0x74		0x39	Caps Lock	0x14	0x22	5	0x35	NAVIGATION TUŞLARI			0x58	Enter	0x0D
0x09	F	0x46		0x3F	F6	0x75		0x53	Num Lock	0x90	0x23	6	0x36	HID	Tuş	VK	0x59		1 0x61
0x0A	G	0x47		0x40	F7	0x76		0x47	Scroll Lock	0x91	0x24	7	0x37	0x49	Insert	0x2D	0x5A		2 0x62
0x0B	H	0x48		0x41	F8	0x77		0x46	Print Screen	0x2C	0x25	8	0x38	0x4C	Delete	0x2E	0x5B		3 0x63
0x0C	I	0x49		0x42	F9	0x78		0x48	Pause	0x13	0x26	9	0x39	0x4A	Home	0x24	0x5C		4 0x64
0x0D	J	0x4A		0x43	F10	0x79		0x65	Application	0x5D	0x27	0	0x30	0x4D	End	0x23	0x5D		5 0x65
0x0E	K	0x4B		0x44	F11	0x7A								0x4B	Page Up	0x21	0x5E		6 0x66
0x0F	L	0x4C		0x45	F12	0x7B								0x4E	Page Down	0x22	0x5F		7 0x67
0x10	M	0x4D		0x68	F13	0x7C											0x60		8 0x68
0x11	N	0x4E		0x69	F14	0x7D											0x61		9 0x69
0x12	O	0x4F		0x6A	F15	0x7E				MEDYA TUŞLARI (HID Consumer Page)			Windows Tuşu				0x62		0 0x60
0x13	P	0x50		0x6B	F16	0x7F								HID	Tuş	VK	0x63	.	0x6E
0x14	Q	0x51		0x6C	F17	0x80				HID Consume	Tuş		VK	Modifier bit : Left Win			0x5B		
0x15	R	0x52		0x6D	F18	0x81				0xE9	Volume Up		0xAF	Modifier bit : Right Win			0x5C		
0x16	S	0x53		0x6E	F19	0x82				0xEA	Volume Down		0xAE						
0x17	T	0x54		0x6F	F20	0x83				0xE2	Mute		0xAD	Modifier Byte (Byte 0)					
0x18	U	0x55		0x70	F21	0x84				0xB0	Next Track		0xB0	Bit	Anlam	VK			
0x19	V	0x56		0x71	F22	0x85				0xB1	Previous Track		0xB1	0 Left Ctrl	0xA2				
0x1A	W	0x57		0x72	F23	0x86				0xB2	Stop		0xB2	1 Left Shift	0xA0				
0x1B	X	0x58		0x73	F24	0x87				0xB3	Play/Pause		0xB3	2 Left Alt	0xA4				
0x1C	Y	0x59												3 Left GUI	0x5B				
0x1D	Z	0x5A												4 Right Ctrl	0xA3				
														5 Right Shift	0xA1				
														6 Right Alt	0xA5				
														7 Right GUI	0x5C				