AIRFIELD NAME		February 21	CHELTENHAM HELIPORT		EGBC	West		
CALLSIGN (A/C RADIO)		Cheltenham Tower		CLUB TS / 121.175				
CALLSIGN (ES/VATSIM)		EGBC_TWR - ONLY OPEN DURING HORSE RACE MEETINGS		Elev.200 ft				
LOCATION La		Lat N051.55.33	.55.33.000 Long W002.03.16.000		VFR Conspicuity			
LOCATION GEOGRAPHIC		1 NM to the North of Cheltenham, next to racecourse		App. EGBJ 128.550				
CHART SOURCE		NATS	LIGHT/MEDIUM HELICOPTER TRAFFIC ONLY		QFE= QNH-6 HPscls			
METAR AIRPORT		EGBJ 127.480	ALL A/C MU	ST USE APPROVED ROUTES	NO NORDO	TRAFFIC		
HELIPADS	HELIPADS Names		APPROACH and DEPARTURE STRICLY under Tower control.					
3 x 18M Gates 1, 2 &		& 4.	EXPECT NON_STANDARD, CLEAR INSRUCTIONS/PHRASEOLOGY.					
1 x 13M	1 x 13M Gate 3		AIRBORNE HOLDS, may be required anywhere.					
4 overload	Gates 5, 6	, 7 &8	PASENGERS will EMBARK/DISEMBARK, ENGINES RUNNING.					
A/C Parking, Northern He		dge see below	A/C may be de	layed or required to depart wit	<mark>h an initial vert</mark>	ical climb		
Runway	170M X 15M;	GRASS	to 100ft before transition, due congestion.					
AIRSPACE	Class G	Transition leve	l 3000ft	Airspace above is Class C. Lon F	FIR FL195			
NO FLY	During routes in/out, A/C should try to stay clear of all farms and housing below 700ft.							
AREAS	The approved routes have been negotiated with local residents.							
LOCAL HAZARDS	The surface of the heliport is not suitable for ground taxiing. Helicopters are required to air-taxi via the routes shown. During periods of intense traffic helicopters may be required to air-taxi using ADVISED directions, in order to allow helicopters to pass each other; this may involve temporary setting down. A/C requiring FUEL, MUST obtain clearance to air taxi. Re-Fuel is ENGINES RUNNING ONLY FUEL AT EGBC IS FOR EMERGENCY ONLY, CARRYING a £1000 Surcharge, to get A/C back to EGBJ							
SPECIAL	Call for lift. Helios NOT PERMITTED to shut-down on stand. Helios who CANNOT disembark/embark							
RULES	passengers and DEPART within 5 minutes, MUST inform ATC on FIRST contact and park as shown.							
	ALL MOVEMENT requires ATC authority. OTHER A/C; exclusion Zone EGBC 3nm radius, up to A3000'							
	ALL A/C MUST follow published routes and Altitudes, unless advised otherwise by ATC.							
	PlanG: HELIPORT user Waypoint location. 51.9258333 -2.0544444							
REMARKS	Restricted Airspace (Temporary), radius 3 NM SFC - 2500 FT AMSL, is established for the duration of the Cheltenham Gold Cup Meeting. This Heliport open ONLY during Cheltenham race meeting. NIGHT Operations possible. SIM PILOTS MUST notify EGBJ_APP and EGBC_TWR, If NIGHT FLYING. A/C Callsigns: RW. All A/C are given a 'jockey' number.							
	If you wish to use a Jockey callsign as described in the briefing, change your TS nickname to include							
	that callsign instead of your aircraft registration, For example 'Neville, JKY23'							
	NOT TO BE USED FOR REAL WORLD OPERATIONS							


THE DATA BELOW RELATES TO ALL INBOUND ROUTES

There are 3 routes; NW - **Stoke Orchard**; NE - **Dixton Hill**; and SE - **Dowdeswell Reservoir**. Below are the Long./Lats. for Navigation and PlanG/Little Nav-Map.

ID	VRP Name	Latitude	Longitude	PlanG Lat	PlanG Long.
1	Stoke Orchard	N051.57.13.650	W002.07.14.300	51.953793	-2.120640
2	Dixton Hill	N051.58.27.700	W002.01.41.950	51.974361	-2.02832
3	Dowdeswell Reservoir	N051.52.37.360	W002.00.57.430	51.877044	-2.015953
4	Prestbury	N051.54.53.450	W002.02.10.440	51.914875	-2.0363138
5	Bishops Cleeve	N051.56.44.880	W002.03.42.110	51.945800	-2.0616972

INBOUND. Report inbound to one of the 3 VRPs above (1,2 or3). You will receive speed and level changes to sequence you towards the Airfield. IF BUSY EXPECT TO BE REQUIRED TO HOLD POSITION, IN THE HOVER. as required, by ATC. Expect to be handed to Tower at (or near) the second VRP. Dependant on runway in use you will be given a 'straight in' or 'downwind' join. If 'parking up' notify Tower when reporting final "jockey 3 final 14 to park".

OUTBOUND. Request your appropriate departure route. Expect possible hold, on the ground or outbound, as well as Altitude restriction. When busy, you will be handed off with "jockey3, App 128.55 callsign only" You report to App. with "Approach, Jockey3" NO MORE. There are 5 set outbound routes named 05; 09; 12; 27 and BJ ATC Phraseology will not always be standard in order to save air time. Please use phraseology as per ATC.



- KEY 1. VRPs as in table above.
 - 3. Green outbound routes.
 - 5. Expect to join downwind or Straight in.
 - 7. Maximum speed inbound to circuit 30 knts.
- 2. Orange, inbound routes
- 4. All A/C will be sequenced by App. to 4 & 5.
- 6. You may be required to slow/hold to maintain sequence.
- 8. When A/F busy, expect to hold in the hover, as instructed.
- 9. IF/when traffic allows A/C may be departed 'direct' or 'via runway, direct' to departure 'gate'.


DOWDESWELL RESERVOIR (PRESTBURY) ROUTE



Head to the ridge, left of Pink Farm



Pink farm to Ridge farm



Ridge farm to Prestbury (4),






Let down after the road, you may need to hold over the two fields.

Expect Height and Speed restrictions. You may be required to hold (in the hover) over VRP 4 for traffic.

STOKE ORCHARD INBOUND ROUTE








Follow M5; TURN RIGHT

Follow road past quarry

Continue, for the blue roof









Caution traffic from the left.

Inbound from VRP 5

Let-down, under outbounds

DIXTON HILL INBOUND ROUTE








Cross the curve of the railway line.

Look for the blue roof.

Turn left, caution other traffic.






Use the road and the 'bush' in field.

Descend to circuit height

Expect Height and Speed restrictions. You may be required to hold (in the hover) short of VRP 5 for traffic.



When you arrive in the TeamSpeak room, please assign yourself a 'Jockey' callsign. - the next number available.-Then change your nickname please. "neville munro G-RKNM" would become "neville Jockey 3" - 3rd one in TS


Notes

- 1. **INBOUND, ALL ROUTES**; On first contact with the approach controller, **state Callsign**; **A/C type**; "parking" (if staying more than 5minutes); "fuel" (if requiring emergency fuel).
- If NOT very confident, flying a helicopter yet, On FIRST contact with both Approach and Tower, put
 "STUDENT" in front of your callsign. "Gloucester Approach, Student Jockey 3.....". ". You will then be given more space and time
- 3. Please study your chosen route. You will be required to follow ALL ATC instructions, especially SPEED and HEIGHT restrictions. Also be aware of the helipad numbers.
- 4. Recommended maximum speed when with Tower is 20-30knts as mid air holds may be required due traffic.
- 5. ALL circuit joins will be either straight in or downwind join as per chart above, dependant on runway in use.
- 6. NO OTHER JOINS PERMITTED. NO PLANNED 'GO AROUNDS' Climb at once and depart the circuit, as shown above, You will be handed back to the approach controller when clear of other traffic, for another try.
- 7. Both controllers, especially if busy, will use shortened phraseology, you should do the same.
- 8. Whilst inbound, especially 'students'.
 If you have a problem NOT ON THE AIRFIELD, LAND, and call "jockey 3 ON THE GROUND". IF you solve the problem and wish to continue, call for lift. "Jockey 3 on the ground, request lift"
- 9. You will be handed off to Tower, with "Jockey 5 follow the Jetranger, Tower on 121.175"

 Your reply, "To follow the Jetranger (or 'traffic'), Tower 121.175, Jockey 5"

NOT TO BE USED FOR REAL WORLD OPERATIONS

AIRFIELD MOVEMENT OPERATIONS



ARRIVALS (with passengers)

- 1. You will be assigned a Pad with your landing clearance. Aim to set down (IN THE HOVER), at or before the aiming point on the runway. When you are in controlled hover, air taxi to your pad. DO NOT SHUT DOWN.
- 2. You should aim to depart within 3-5 minutes. To make room for other A/C. See below for departure procedure.
- 3. If you are following another A/C in. You will hear "Jockey 5, number 2 to the Jetranger (A/C) short final."
- 4. Your reply, "Wilco, final contact one ahead, Jockey 5".
- 5. Your landing clearance will be, "Jockey 5, cleared to land 14, to gate1".

ARRIVALS (to park / stay for more than 5 minutes)

- 1. On first contact with tower, state; "Jockey 3, final, to park". Empty, direct to parking.
- 2. Set down at aiming point, as above and HOVER TAXI TO SAFE SPACE BY NORTH HEDGE. SHUT DOWN.
- 3. With passengers offloaded, "Jockey 5, Gate1 to park" you will need clearance to cross the runway.

Taxiing. ALWAYS be aware of other A/C around you, especially if they are moving. Give way to inbound A/C.

DEPARTURES. NOTE Tower will broadcast winds regularly, not to each A/C. Standard departure, Climb to A1400

- 1. You should 'Call for start', but, if busy you can start and WHEN READY TO GO, call for departure.
 - "Jockey 5, outbound, 09, gate1." DO NOT CALL UNTIL READY TO DEPART.
- "Jockey5, Lift and Go 14" = lift, taxi to runway and depart 14 for 09 route. But, "Jockey 5, Lift, line up 14" = lift taxi to runway, line up and hold (or set down), Then "Jockey 5, cleared take off 14"
- "Jockey 5, Lift, Take off direct out, 09 departure. " = taxi to runway, depart direct through departure gate, climbing to A1400ft "Taking off direct, 09 (out) Jockey 5"
- 4. FLY THE 09 Departure procedure on the previous page, (normal) climbing turn over inbounds, or(direct) straight out, to departure gate.
- You will be handed to Approach with "Jockey 5, Approach on 128.550 ,callsign only"
 Your call to approach should be "Approach, Jockey 5" NO MORE.
- If "Jockey 5, Approach on 128.55, route and callsign". Your call "Approach Jockey 5, 09"

NOT TO BE USED FOR REAL WORLD OPERATIONS