```
*
 (c) Copyright 2010-13 Xilinx, Inc. All rights reserved.
*
*
* This file contains confidential and proprietary information of Xilinx, Inc.
* and is protected under U.S. and international copyright and other
 intellectual property laws.
* DISCLAIMER
* This disclaimer is not a license and does not grant any rights to the
* materials distributed herewith. Except as otherwise provided in a valid
st license issued to you by Xilinx, and to the maximum extent permitted by
* applicable law: (1) THESE MATERIALS ARE MADE AVAILABLE "AS IS" AND WITH ALL
* FAULTS, AND XILINX HEREBY DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS,
st IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF
* MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE;
st and (2) Xilinx shall not be liable (whether in contract or tort, including
st negligence, or under any other theory of liability) for any loss or damage
* of any kind or nature related to, arising under or in connection with these
* materials, including for any direct, or any indirect, special, incidental,
* or consequential loss or damage (including loss of data, profits, goodwill,
st or any type of loss or damage suffered as a result of any action brought by
* a third party) even if such damage or loss was reasonably foreseeable or
* Xilinx had been advised of the possibility of the same.
* CRITICAL APPLICATIONS
* Xilinx products are not designed or intended to be fail-safe, or for use in
* any application requiring fail-safe performance, such as life-support or
* safety devices or systems, Class III medical devices, nuclear facilities,
* applications related to the deployment of airbags, or any other applications
* that could lead to death, personal injury, or severe property or
* environmental damage (individually and collectively, "Critical
* Applications"). Customer assumes the sole risk and liability of any use of
* Xilinx products in Critical Applications, subject only to applicable laws
 and regulations governing limitations on product liability.
st THIS COPYRIGHT NOTICE AND DISCLAIMER MUST BE RETAINED AS PART OF THIS FILE
* AT ALL TIMES.
/**
* @file xgpiops_intr_example.c
* This file contains a design example using the GPIO driver (XGpioPs) in an
 interrupt driven mode of operation.
* The example uses the interrupt capability of the GPIO to detect push button
st events and set the output LEDs based on the input . The user needs to press
 all the switches SW1-SW5 on the evaluation board to exit from this example.
* @note
 This example assumes that there is a Uart device in the HW design.
*
 MODIFICATION HISTORY:
*
*
* Ver
       Who Date
                   Changes
* 1.00a sv
           01/18/10 First Release
*
```

```
#include "xparameters.h"
#include "xgpiops.h"
#include "xscugic.h"
#include "xil_exception.h"
#include <xil printf.h>
/******************** Constant Definitions *****************
/*
* The following constants map to the names of the hardware instances that
* were created in the EDK XPS system. They are defined here such that
* the user can easily change all the needed device IDs in one place.
*/
#define GPIO DEVICE ID
                          XPAR XGPIOPS O DEVICE ID
                         XPAR SCUGIC SINGLE DEVICE ID
#define INTC DEVICE ID
#define GPIO_INTERRUPT_ID
                         XPAR_XGPIOPS_0_INTR
/*
* The following constants define the GPIO banks that are used.
*/
#define INPUT BANK
                   XGPIOPS BANKO /* Bank O of the GPIO Device */
#define OUTPUT BANK
                   XGPIOPS BANK1 /* Bank 1 of the GPIO Device */
/*
* The following constants define the positions of the buttons of the GPIO.
                          0xFFFF
#define GPIO_ALL_BUTTONS
/*
* The following constant determines which buttons must be pressed to cause
* interrupt processing to stop.
*/
#define GPIO EXIT CONTROL VALUE 0x1F
#define printf
                          xil printf
                                       /* Smalller foot-print printf */
/******************** Function Prototypes *****************
static int GpioIntrExample(XScuGic *Intc, XGpioPs *Gpio, u16 DeviceId,
                      u16 GpioIntrId);
static void IntrHandler(void *CallBackRef, int Bank, u32 Status);
static int SetupInterruptSystem(XScuGic *Intc, XGpioPs *Gpio, u16 GpioIntrId);
/*
* The following are declared globally so they are zeroed and so they are
* easily accessible from a debugger.
static XGpioPs Gpio: /* The Instance of the GPIO Driver */
static XScuGic Intc; /* The Instance of the Interrupt Controller Driver */
static u32 AllButtonsPressed; /* Intr status of the bank */
/**
*
* Main function that invokes the GPIO Interrupt example.
```

```
*
 @param
              None.
 @return
              - XST SUCCESS if the example has completed successfully.
              - XST FAILURE if the example has failed.
*
* @note
              None.
************************************
int main(void)
       int Status;
       xil printf("GPIO Interrupt Example Test \r\n");
       /*
        * Run the GPIO interrupt example, specify the parameters that
        * are generated in xparameters.h.
       Status = GpioIntrExample(&Intc, &Gpio, GPIO_DEVICE_ID,
                              GPIO_INTERRUPT_ID);
       if (Status != XST SUCCESS) {
              xil printf("GPIO Interrupt Example Test Failed\r\n");
              return XST_FAILURE;
       }
       xil_printf("Successfully ran GPIO Interrupt Example Test\r\n");
       return XST_SUCCESS;
/**
* This function shows the usage of interrupt fucntionality of the GPIO device.
* It is responsible for initializing the GPIO device, setting up interrupts and
 providing a foreground loop such that interrupts can occur in the background.
              Into is a pointer to the XScuGic driver Instance.
* @param
              Gpio is a pointer to the XGpioPs driver Instance.
* @param
 @param
              DeviceId is the XPAR_<Gpio_Instance>_PS_DEVICE_ID value
              from xparameters.h.
              GpioIntrId is XPAR_<GIC>_<GPIO_Instance>_VEC_ID value
*
 @param
*
              from xparameters.h
              - XST SUCCESS if the example has completed successfully.
 @return
              - XST FAILURE if the example has failed.
*
              None
* @note
***************************
int GpioIntrExample(XScuGic *Intc, XGpioPs *Gpio, u16 DeviceId, u16 GpioIntrId)
       XGpioPs_Config *ConfigPtr;
       int Status;
       /*
        * Initialize the Gpio driver.
       ConfigPtr = XGpioPs_LookupConfig(DeviceId);
       if (ConfigPtr == NULL) {
              return XST_FAILURE;
       XGpioPs_CfgInitialize(Gpio, ConfigPtr, ConfigPtr->BaseAddr);
```

\*

```
* Run a self-test on the GPIO device.
       Status = XGpioPs_SelfTest(Gpio);
       if (Status != XST SUCCESS) {
              return XST_FAILURE;
       /*
        * Setup direction register of bankO, so
        * that all the pins are configured as inputs.
        */
       XGpioPs_SetDirection(Gpio, INPUT_BANK, ~GPIO_ALL_BUTTONS);
       /*
        * Set the direction for all signals to be
        * outputs and Enable the Output enable for the LED Pins.
        */
       XGpioPs SetDirection (Gpio, OUTPUT BANK, GPIO ALL BUTTONS);
       XGpioPs_SetOutputEnable(Gpio, OUTPUT_BANK, GPIO_ALL_BUTTONS);
       /*
        * Setup the interrupts such that interrupt processing can occur. If
        * an error occurs then exit.
       Status = SetupInterruptSystem(Intc, Gpio, GPIO INTERRUPT ID);
       if (Status != XST_SUCCESS) {
              return XST FAILURE;
       }
       printf("\n\rPush each of the 5 buttons once to exit\n\");
       AllButtonsPressed = FALSE;
        * Loop forever while the button changes are handled by the interrupt
        * level processing.
       while(AllButtonsPressed == FALSE);
       printf("\n\r The GPIO Interrupt example has passed Successfully.\n\r");
       return XST_SUCCESS;
/**
* This function is the user layer callback function for the bank 0 interrupts of
 the GPIO device. It checks if all the switches have been pressed to stop the
 interrupt processing and exit from the example.
* @param
              CallBackRef is a pointer to the upper layer callback reference.
              Status is the Interrupt status of the GPIO bank.
* @param
              None.
* @return
* @note
              None.
******************************
static void IntrHandler(void *CallBackRef, int Bank, u32 Status)
       XGpioPs *Gpio = (XGpioPs *)CallBackRef;
       static u32 ButtonsChanged;
```

/\*

```
*/
       if (Bank != INPUT BANK) {
               return;
       ButtonsChanged |= Status;
       /*
        * Set the LEDs.
       XGpioPs_Write(Gpio, OUTPUT_BANK, ButtonsChanged);
       if (ButtonsChanged == GPIO_EXIT_CONTROL_VALUE) {
                * Five buttons are pressed to mark the completion of the test.
               AllButtonsPressed = TRUE;
               ButtonsChanged = 0;
       }
}
/**
* This function sets up the interrupt system for the example. It enables falling
 edge interrupts for all the pins of bank 0 in the GPIO device.
* @param
               GicInstancePtr is a pointer to the XScuGic driver Instance.
 @param
               GpioInstancePtr contains a pointer to the instance of the GPIO
               component which is going to be connected to the interrupt
               controller.
               GpioIntrId is the interrupt Id and is typically
* @param
               XPAR <GICPS> <GPIOPS instance> VEC ID value from
               xparameters.h.
*
*
               XST SUCCESS if successful, otherwise XST FAILURE.
 @return
               None.
* @note
************************************
static int SetupInterruptSystem(XScuGic *GicInstancePtr, XGpioPs *Gpio,
                              u16 GpioIntrId)
{
       int Status:
       XScuGic Config *IntcConfig; /* Instance of the interrupt controller */
       Xil_ExceptionInit();
       /*
        * Initialize the interrupt controller driver so that it is ready to
        * use.
        */
       IntcConfig = XScuGic LookupConfig(INTC DEVICE ID);
       if (NULL == IntcConfig) {
               return XST_FAILURE;
       Status = XScuGic_CfgInitialize(GicInstancePtr, IntcConfig,
                                     IntcConfig->CpuBaseAddress);
       if (Status != XST SUCCESS) {
               return XST_FAILURE;
       }
```

\* Do nothing if the intr is generated for a different bank.

```
/*
 * Connect the interrupt controller interrupt handler to the hardware
 * interrupt handling logic in the processor.
 */
Xil ExceptionRegisterHandler(XIL EXCEPTION ID INT,
                        (Xil ExceptionHandler) XScuGic InterruptHandler,
                        GicInstancePtr);
/*
 * Connect the device driver handler that will be called when an
* interrupt for the device occurs, the handler defined above performs
* the specific interrupt processing for the device.
Status = XScuGic Connect(GicInstancePtr, GpioIntrId,
                        (Xil ExceptionHandler) XGpioPs IntrHandler,
                         (void *)Gpio);
if (Status != XST_SUCCESS) {
        return Status;
}
/*
 * Enable falling edge interrupts for all the pins in bank 0.
XGpioPs SetIntrType(Gpio, INPUT BANK, 0x00, 0x00, 0x00);
* Set the handler for gpio interrupts.
XGpioPs SetCallbackHandler(Gpio, (void *)Gpio, IntrHandler);
/*
 * Enable the GPIO interrupts of Bank O.
XGpioPs IntrEnable(Gpio, INPUT BANK, OxFFFFFFFF);
/*
* Enable the interrupt for the GPIO device.
XScuGic_Enable(GicInstancePtr, GpioIntrId);
/*
* Enable interrupts in the Processor.
Xil ExceptionEnableMask(XIL EXCEPTION IRQ);
return XST_SUCCESS;
```

}