```
/**
 1
 2
 3
        @copyright © 2010 - 2020, Fraunhofer-Gesellschaft zur Foerderung der
 4
      * angewandten Forschung e.V. All rights reserved.
 5
 6
      * BSD 3-Clause License
 7
      * Redistribution and use in source and binary forms, with or without
      * modification, are permitted provided that the following conditions are met:
 8
 9
      * 1. Redistributions of source code must retain the above copyright notice,
10
            this list of conditions and the following disclaimer.
11
       2. Redistributions in binary form must reproduce the above copyright
12
            notice, this list of conditions and the following disclaimer in the
13
            documentation and/or other materials provided with the distribution.
14
      * 3. Neither the name of the copyright holder nor the names of its
15
            contributors may be used to endorse or promote products derived from
16
            this software without specific prior written permission.
17
18
      * THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS"
19
      * AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
20
      * IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
21
      * ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE
22
      * LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR
23
      * CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF
24
      * SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
25
      * INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN
26
      * CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE)
27
      * ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE
      * POSSIBILITY OF SUCH DAMAGE.
28
29
30
      * We kindly request you to use one or more of the following phrases to refer
31
      * to foxBMS in your hardware, software, documentation or advertising
32
      * materials:
33
34
      * ″ This product uses parts of foxBMS&req; ″
35
36
      * ″ This product includes parts of foxBMS&req; ″
37
38
      * ″ This product is derived from foxBMS&req; ″
39
40
      * /
41
     /**
42
43
      * @file
                cansignal_cfg.c
44
      * @author foxBMS Team
45
      * @date 16.09.2015 (date of creation)
46
      * @ingroup DRIVERS CONF
      * @prefix CANS
47
48
49
      * @brief
                Configuration of the messages and signal settings for the CAN driver
50
51
      * /
52
```

```
/*======= Includes =======*/
 53
 54
     #include "cansignal_cfg.h"
 55
 56
     #include "bal.h"
 57 #include "database.h"
 58
     #include "diag.h"
 59
     #include "sox.h"
     #include "sys.h"
     #include "bms.h"
 61
     #include "contactor.h"
 62
 63
     /*======= Macros and Definitions =============*/
 64
     static DATA BLOCK CURRENT SENSOR s cans current tab;
 65
 66
 67
     #define CANS MODULSIGNALS VOLT
                                        (CANO SIG ModO temp valid 0 2 - CANO SIG ModO volt valid 0 2)
     #define CANS MODULSIGNALS TEMP
                                        (CANO SIG Mod1 volt valid 0 2 - CANO SIG Mod0 temp valid 0 2)
 68
 69
 70
 71
     /*======== Static Function Prototypes ===========*/
 72
 73
     static float cans_checkLimits(float value, uint32_t sigIdx);
 74
 75
     /* TX/Getter functions */
 76
     static uint32_t cans_getvolt(uint32_t, void *);
     static uint32_t cans_gettempering(uint32_t, void *);
     static uint32_t cans_getcanerr(uint32_t, void *);
 78
     static uint32 t cans gettemp (uint32 t, void *);
     static uint32_t cans_getsoc(uint32_t, void *);
 80
     static uint32 t cans_getRecommendedOperatingCurrent(uint32_t, void *);
 81
     static uint32 t cans getMaxAllowedPower(uint32 t, void *);
 82
     static uint32_t cans_getpower(uint32_t, void *);
     static uint32_t cans_getcurr(uint32_t, void *);
     static uint32 t cans getPackVoltage(uint32 t, void *);
 85
     static uint32 t cans getminmaxvolt(uint32 t, void *);
 87
     static uint32_t cans_getminmaxtemp(uint32_t, void *);
 88
     static uint32_t cans_getisoguard(uint32_t, void *);
 89
 90
     /* RX/Setter functions */
 91
 92
     static uint32 t cans setcurr(uint32 t, void *);
 93
     static uint32 t cans setstaterequest (uint32 t, void *);
                                                                                   typedef struct {
                                                                             754
     static uint32_t cans_setdebug(uint32_t, void *);
                                                                             755
                                                                                      CANS_messages_t msgIdx;
     static uint32 t cans setSWversion(uint32 t, void *);
 95
                                                                             756
                                                                                      uint8 t bit position;
     static uint32 t cans setenginerequest(uint32 t, void *);
 96
                                                                             757
                                                                                      uint8_t bit_length;
 97
                                                                             758
                                                                                      float min;
98
                                                                             759
                                                                                      float max;
 99
     #ifdef CURRENT SENSOR ISABELLENHUETTE TRIGGERED
                                                                             760
                                                                                      float factor;
     static uint32 t cans gettriggercurrent (uint32 t sigIdx, void *value);
100
                                                                             761
                                                                                      float offset;
101
     #endif /* CURRENT_SENSOR_ISABELLENHUETTE_TRIGGERED */
                                                                             762
                                                                                      CANS_byteOrder_e byteOrder;
102
                                                                             763
                                                                                      can_callback_funcPtr callback;
103
                                                                             764
                                                                                   } CANS_signal_s;
104
```

```
/*======= Static Constant and Variable Definitions =========*/
105
106
107
      /*====== Extern Constant and Variable Definitions =======*/
108
                       When using CANO MSGIdx xx, it is much easier to understand.
109
      const CANS signal s cans CANO signals tx[] = {
          { {CANO_MSG\( \sigma \)} SystemState_0 }, 0, 3, 0, 7, 1, 0, littleEndian, \( \sigma \) cans_getcanerr }, /*!< CANO_SIG_GSO_general_error, */
110
          { (CANO_MSG_SystemState_0), 8, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getcanerr }, /*!<
111
          CANO SIG GSO current state, */ Used for sending the BMS state!!!
112
          { (CANO MSG SystemState 0), 16, 3, 0, 7, 1, 0, littleEndian, &cans getcanerr }, /*!<
          CANO_SIG_GSO_error_overtemp_charge, */
113
          { (CANO_MSG_SystemState_0), 24, 3, 0, 7, 1, 0, littleEndian, &cans_getcanerr }, /*!<
          CANO SIG GSO error undertemp charge, */
114
          { (CANO_MSG_SystemState_0), 32, 3, 0, 7, 1, 0, littleEndian, &cans_getcanerr }, /*! <
          CANO_SIG_GSO_error_overtemp_discharge, */
115
          { (CANO_MSG_SystemState_0), 40, 3, 0, 7, 1, 0, littleEndian, &cans_getcanerr }, /*! <
          CANO SIG GSO error undertemp discharge, */
          { (CANO_MSG_SystemState_0), 48, 3, 0, 7, 1, 0, littleEndian, &cans_getcanerr }, /*! <
116
          CANO SIG GSO error overcurrent charge, */
117
          { (CANO MSG SystemState 0), 56, 3, 0, 7, 1, 0, littleEndian, &cans getcanerr }, /*!<
          CANO SIG GSO error overcurrent discharge, */
118
119
          { (CANO_MSG_SystemState_1), 0, 3, 0, 7, 1, 0, littleEndian, &cans_getcanerr }, /*!<
          CANO SIG GS1 error overvoltage, */
120
          { (CANO_MSG_SystemState_1), 8, 3, 0, 7, 1, 0, littleEndian, &cans_getcanerr }, /*!<
          CANO_SIG_GS1_error_undervoltage, */
121
          { (CANO_MSG_SystemState_1), 11, 1, 0, 1, 1, 0, littleEndian, &cans_getcanerr }, /*! <
          CANO SIG GS1 error deep discharge, */
122
          { (CANO_MSG_SystemState_1), 16, 1, 0, 1, 1, 0, littleEndian, &cans_getcanerr }, /*!<
          CANO SIG GS1 error temperature MCUO */
123
          { (CANO_MSG_SystemState_1), 24, 1, 0, 1, 1, 0, littleEndian, &cans_getcanerr }, /*! <
          CANO SIG GS1 error contactor */
124
          { (CANO_MSG_SystemState_1), 32, 1, 0, 1, 1, 0, littleEndian, &cans_getcanerr }, /*!<
          CANO SIG GS1 error selftest, */
125
          { (CANO_MSG_SystemState_1), 40, 1, 0, 1, 1, 0, littleEndian, &cans_getcanerr }, /*! <
          CAN_SIG_GS1_error_cantiming, */
          { (CANO_MSG_SystemState_1), 48, 1, 0, 1, 1, 0, littleEndian, &cans_getcanerr }, /*! <
126
          CANO SIG GS1 current sensor, */
127
          { (CANO_MSG_SystemState_1), 56, 1, 0, 1, 1, 0, littleEndian, &cans getcanerr }, /*! <
          CANO_SIG_GS1_balancing_active, */
128
129
          { (CANO_MSG_SystemState_2), 0, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getcanerr }, /*! <
          CAN0_SIG_GS2_states_relays */ This is for relay open/close information?
130
          { (CANO_MSG_SystemState_2), 16, 1, 0, 1, 1, 0, littleEndian, &cans_getcanerr },
          CANO SIG GS2 error insulation */
131
          { (CANO MSG SystemState 2), 24, 4, 0, 15, 1, 0, littleEndian, &cans getcanerr }, /*! < CANO SIG GS2 fuse state */
132
          { (CANO_MSG_SystemState_2), 32, 2, 0, 3, 1, 0, littleEndian, &cans_getcanerr },
                                                                                            /*!<
          CANO SIG GS2 lowCoinCellVolt */
133
          { (CANO_MSG_SystemState_2), 40, 1, 0, 1, 1, 0, littleEndian, &cans_getcanerr }, /*!<
          CANO_SIG_GS2_error_openWire */
134
          { (CANO_MSG_SystemState_2), 48, 3, 0, 7, 1, 0, littleEndian, &cans_getcanerr },
                                                                                           /*!< CANO_SIG_GS2_daisyChain */</pre>
          { (CANO_MSG_SystemState_2), 56, 3, 0, 7, 1, 0, littleEndian, &cans_getcanerr },
135
                                                                                            /*!<
          CANO SIG GS2 plausibilityCheck */
```

```
136
137
          { (CANO MSG SlaveState 0), 0, 64, 0, UINT64 MAX, 1, 0, littleEndian, NULL PTR }, /*! < CANO SIG SSO states */
138
          { (CANO_MSG_SlaveState_1), 0, 64, 0, UINT64_MAX, 1, 0, littleEndian, NULL_PTR }, /*! < CANO_SIG_SSO_states */
139
140
          { (CANO MSG RecOperatingCurrent), 0, 16, 0, 6553.5, 10, 0, littleEndian, &cans getRecommendedOperatingCurrent },
          /*!< CANO_SIG_MaxChargeCurrent */</pre>
141
          { (CANO_MSG_RecOperatingCurrent), 16, 16, 0, 6553.5, 10, 0, littleEndian, &cans_getRecommendedOperatingCurrent
          }, /*! < CANO SIG MaxChargeCurrent Peak */
          { (CANO_MSG_RecOperatingCurrent), 32, 16, 0, 6553.5, 10, 0, littleEndian, &cans_getRecommendedOperatingCurrent
142
          }, /*!< CANO SIG MaxDischargeCurrent */</pre>
143
          { (CANO_MSG_RecOperatingCurrent), 48, 16, 0, 6553.5, 10, 0, littleEndian, &cans_getRecommendedOperatingCurrent
          }, /*!< CANO SIG MaxDischargeCurrent Peak */
144
145
          { (CANO_MSG_SOP), 0, 16, 0, 6553.5, 10, 0, littleEndian, &cans_getMaxAllowedPower }, /*!<
          CANO SIG MaxChargePower */
146
          { (CANO MSG SOP), 16, 16, 0, 6553.5, 10, 0, littleEndian, &cans getMaxAllowedPower }, /*!<
          CANO SIG MaxChargePower Peak */
147
          { (CANO MSG SOP), 32, 16, 0, 6553.5, 10, 0, littleEndian, &cans getMaxAllowedPower }, /*!<
          CANO SIG MaxDischargePower */
148
          { (CANO MSG SOP), 48, 16, 0, 6553.5, 10, 0, littleEndian, &cans getMaxAllowedPower }, /*!<
          CANO_SIG_MaxDischargePower_Peak */
149
          { (CANO_MSG_SOC), 0, 16, 0, 100, 100, 0, littleEndian, &cans_getsoc }, /*! < CANO SIG SOC mean */
150
151
          { (CANO_MSG_SOC), 16, 16, 0, 100, 100, 0, littleEndian, &cans_getsoc }, /*! < CANO_SIG_SOC_min */
          { {CANO_MSG_SOC}, 32, 16, 0, 100, 100, 0, littleEndian, &cans_getsoc}, /*!< CANO_SIG SOC max */
152
153
154
          { (CANO_MSG_SOH), 0, 16, 0, 0, 100, 0, littleEndian, NULL_PTR }, /*! < CANO_SIG_SOH_mean */
155
          { (CANO_MSG_SOH), 16, 16, 0, 0, 100, 0, littleEndian, NULL_PTR }, /*! < CANO_SIG_SOH_min */
156
          { (CANO_MSG_SOH), 32, 16, 0, 0, 100, 0, littleEndian, NULL_PTR }, /*! < CANO_SIG SOH max */
157
158
          { (CANO MSG SOE), 0, 16, 0, 0, 100, 0, littleEndian, NULL PTR }, /*! < CANO SIG SOE */
          { (CANO_MSG_SOE), 16, 32, 0, UINT32_MAX, 1, 0, littleEndian, NULL_PTR }, /*! < CANO_SIG_RemainingEnergy */
159
160
          { (CANO_MSG_MinMaxCellVolt), 0, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getminmaxvolt ), /*!<
161
          CANO_SIG_Cellvolt_mean */
          { (CANO_MSG_MinMaxCellVolt), 16, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getminmaxvolt }, /*!<
162
          CANO SIG Cellvolt min */
163
          { (CANO MSG MinMaxCellVolt), 32, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getminmaxvolt }, /*!<
          CANO SIG Cellvolt max */
          { {CANO_MSG_MinMaxCellVolt}, 48, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans getminmaxvolt }, /*!<
164
          CANO SIG ModNumber min */
165
          { (CANO_MSG_MinMaxCellVolt), 56, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getminmaxvolt }, /*!<
          CANO SIG ModNumber max */
166
          { (CANO_MSG_SOV), 0, 16, 0, 100, 100, 0, littleEndian, NULL PTR }, /*!< CANO SIG SOV */
167
168
169
          { (CANO MSG MinMaxCellTemp), 0, 16, -128, 527.35, 100, 128, littleEndian, &cans getminmaxtemp }, /*!<
          CANO SIG Cellvolt mean */
          { (CANO_MSG_MinMaxCellTemp), 16, 16, -128, 527.35, 100, 128, littleEndian, &cans_getminmaxtemp }, /*! <
170
          CANO SIG Cellvolt min */
171
          { (CANO MSG MinMaxCellTemp), 32, 16, -128, 527.35, 100, 128, littleEndian, &cans getminmaxtemp }, /*! <
          CANO SIG Cellvolt max */
```

```
172
          { (CANO MSG MinMaxCellTemp), 48, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getminmaxtemp), /*!<
          CANO SIG ModNumber min */
          { {CANO_MSG_MinMaxCellTemp}, 56, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getminmaxtemp }, /*!<
173
          CANO SIG ModNumber max */
174
175
          { (CANO_MSG_Tempering), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettempering }, /*!<
          CANO SIG CoolingNeeded */
          { (CANO_MSG_Tempering), 8, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans gettempering }, /*!<
176
          CANO SIG HeatingNeeded */
177
          { (CANO_MSG_Tempering), 16, 32, 0, UINT32_MAX, 1, 0, littleEndian, &cans_gettempering }, /*! <
          CANO_SIG_TemperingDemand */
178
179
          { (CANO MSG Insulation), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getisoguard }, /*!<
          CANO SIG InsulationStatus */
          { (CANO_MSG_Insulation), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getisoguard ), /*!<
180
          CANO SIG InsulationValue */
181
182
          { (CANO_MSG_Power_0), 0, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans_getpower }, /*!<
          CANO SIG RunAverage Power 1s */
183
          { (CANO MSG Power 0), 32, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans getpower }, /*! <
          CANO_SIG_RunAverage_Power_5s */
184
          { (CANO MSG Power 1), 0, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans getpower }, /*!<
          CANO SIG RunAverage Power 10s */
185
          { (CANO_MSG_Power_1), 32, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans_getpower }, /*! <
          CANO_SIG_RunAverage_Power_30s */
186
          { (CANO MSG Power 2), 0, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans getpower }, /*!<
          CANO SIG RunAverage Power 60s */
187
          { (CANO_MSG_Power_2), 32, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans_getpower }, /*!<
          CANO SIG RunAverage Power config */
188
189
          { {CANO MSG Current 0}, 0, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans getcurr }, /*!<
          CANO SIG RunAverage Current 1s */
190
          { (CANO MSG Current 0), 32, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans getcurr }, /*!<
          CANO SIG RunAverage Current 5s */
191
          { (CANO_MSG_Current_1), 0, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans_getcurr }, /*!<
          CANO_SIG_RunAverage_Current_10s */
192
          { (CANO MSG Current 1), 32, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans getcurr }, /*!<
          CANO SIG RunAverage Current 30s */
193
          { (CANO_MSG_Current_2), 0, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans_getcurr }, /*!<
          CANO SIG RunAverage Current 60s */
194
          { (CANO MSG Current 2), 32, 32, -2500000, 4292467295, 1, 2500000, littleEndian, &cans getcurr }, /*!<
          CANO_SIG_RunAverage_Current_config */
195
196
          { (CANO MSG PackVoltage), 0, 32, 0, UINT32 MAX, 1, 0, littleEndian, &cans getPackVoltage }, /*! <
          CANO SIG PackVolt Batterv */
197
          { (CANO_MSG_PackVoltage), 32, 32, 0, UINT32_MAX, 1, 0, littleEndian, &cans_getPackVoltage }, /*!<
          CANO SIG PackVolt PowerNet */
198
199
          /* Module 0 cell voltages */
200
          { (CANO_MSG_Mod0_Cellvolt_0), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG ModO volt valid 0 2 */
          { (CANO_MSG_Mod0_Cellvolt_0), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
201
```

```
CANO SIG ModO volt 0 */
          { (CANO MSG ModO Cellvolt 0), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
202
         CANO SIG Mod0 volt 1 */
203
          { (CANO_MSG_Mod0_Cellvolt_0), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*! <
          CANO SIG Mod0 volt 2 */
          { (CANO_MSG_Mod0_Cellvolt_1}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
204
         CANO SIG ModO volt valid 3 5 */
205
          { (CANO MSG Mod0 Cellvolt 1), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG ModO volt 3 */
206
          { (CANO_MSG_Mod0_Cellvolt_1), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO_SIG_ModO_volt_4 */
207
          { (CANO MSG ModO Cellvolt 1), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG ModO volt 5 */
208
          { (CANO_MSG_Mod0_Cellvolt_2), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG ModO volt valid 6 8 */
209
          { (CANO MSG Mod0 Cellvolt 2), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG ModO volt 6 */
210
          { (CANO_MSG_Mod0_Cellvolt_2), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod0 volt 7 */
211
          { (CANO MSG ModO Cellvolt 2), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO_SIG_ModO_volt_8 */
212
          { (CANO_MSG_Mod0_Cellvolt_3), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG ModO volt valid 9 11 */
213
          { (CANO_MSG_Mod0_Cellvolt_3), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO_SIG_ModO_volt_9 */
214
          { (CANO MSG ModO Cellvolt 3), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG ModO volt 10 */
215
          { (CANO_MSG_Mod0_Cellvolt_3), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG ModO volt 11 */
216
          { (CANO MSG Mod0 Cellvolt 4), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG ModO volt valid 12 14 */
217
          { (CANO_MSG_Mod0_Cellvolt_4), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod0 volt 12 */
218
          { (CANO MSG ModO Cellvolt 4), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO_SIG_ModO_volt_13 */
          { (CANO_MSG_ModO_Cellvolt_4), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
219
         CANO SIG Mod0 volt 14 */
220
          { (CANO_MSG_Mod0_Cellvolt_5), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO_SIG_ModO_volt_valid_15_17 */
221
          { (CANO_MSG_Mod0_Cellvolt_5), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG ModO volt 15 */
222
          { (CANO_MSG_Mod0_Cellvolt_5), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG ModO volt 16 */
         { {CANO_MSG_Mod0_Cellvolt_5}, 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
223
         CANO SIG ModO volt 17 */
224
225
         /* Module 0 cell temperatures */
226
          { (CANO MSG Mod0 Celltemp 0), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
          CANO_SIG_ModO_volt_valid_0_2 */
227
          { (CANO_MSG_Mod0_Celltemp_0), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod0 temp 0 */
228
          { (CANO MSG Mod0 Celltemp 0), 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
```

```
CANO_SIG_Mod0_temp 1 */
229
          { (CANO MSG Mod0 Celltemp 0}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod0 temp 2 */
230
          { (CANO MSG Mod0 Celltemp 1), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!
          CANO SIG ModO volt valid 3 5 */
          { (CANO_MSG_Mod0_Celltemp_1}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
231
         CANO SIG Mod0 temp 3 */
          { (CANO_MSG_ModO_Celltemp_1}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
232
         CANO SIG Mod0 temp 4 */
233
          { (CANO_MSG_ModO_Celltemp_1}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO_SIG_ModO_temp 5 */
234
          { (CANO MSG Mod0 Celltemp 2), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!
         CANO SIG ModO volt valid 6 8 */
235
          { (CANO_MSG_Mod0_Celltemp_2), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod0 temp 6 */
236
          { (CANO MSG Mod0 Celltemp 2}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod0 temp 7 */
237
          { (CANO_MSG_ModO_Celltemp_2}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
         CANO SIG Mod0 temp 8 */
238
          { (CANO MSG Mod0 Celltemp 3}, 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!
         CANO_SIG_ModO_volt_valid_9_11 */
239
          { (CANO_MSG_Mod0_Celltemp_3}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod0 temp 9 */
         { {CANO_MSG_Mod0_Celltemp_3}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
240
          CANO_SIG_Mod0_temp_10 */
241
          { (CANO MSG Mod0 Celltemp 3}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod0 temp 11 */
242
243
          /* Module 1 cell voltages */
          { (CANO_MSG_Mod1_Cellvolt_0), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
244
         CANO SIG Mod1 volt valid 0 2 */
245
          { (CANO_MSG_Mod1_Cellvolt_0), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod1 volt 0 */
246
          { (CANO MSG Mod1 Cellvolt 0), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO_SIG_Mod1_volt_1 */
247
          { (CANO_MSG_Mod1_Cellvolt_0), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod1 volt 2 */
248
          { (CANO MSG Mod1 Cellvolt 1), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
          CANO_SIG_Mod1_volt_valid_3_5 */
          { (CANO_MSG_Mod1_Cellvolt_1), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
249
         CANO SIG Mod1 volt 3 */
250
          { (CANO_MSG_Mod1_Cellvolt_1), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod1 volt 4 */
251
          { (CANO MSG Mod1 Cellvolt 1), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO_SIG_Mod1_volt 5 */
252
          { (CANO_MSG_Mod1_Cellvolt_2), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod1 volt valid 6 8 */
          { \{CAN0\_MSG\_Mod1\_Cellvolt\_2\}, 8, 16, 0, UINT16\_MAX, 1, 0, littleEndian, &cans getvolt }, /*!
253
          CANO_SIG_Mod1_volt_6 */
254
          { (CANO_MSG_Mod1_Cellvolt_2), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod1 volt 7 */
          { (CANO MSG Mod1 Cellvolt 2), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
255
```

```
CANO SIG Mod1 volt 8 */
          { (CANO MSG Mod1 Cellvolt 3), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
256
          CANO SIG Mod1 volt valid 9 11 */
257
          { (CANO_MSG_Mod1_Cellvolt_3), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod1 volt 9 */
          { (CANO_MSG_Mod1_Cellvolt_3), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
258
          CANO SIG Mod1 volt 10 */
259
          { (CANO_MSG_Mod1_Cellvolt_3), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*! <
          CANO SIG Mod1 volt 11 */
260
          { (CANO_MSG_Mod1_Cellvolt_4), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG_Mod1_volt_valid_12_14 */
          { (CANO_MSG_Mod1_Cellvolt_4), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
261
          CANO SIG Mod1 volt 12 */
262
          { (CANO_MSG_Mod1_Cellvolt_4), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod1 volt 13 */
263
          { (CANO MSG Mod1 Cellvolt 4), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
          CANO SIG Mod1 volt 14 */
264
          { (CANO_MSG_Mod1_Cellvolt_5), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod1 volt valid 15 17 */
265
          { \{CAN0\_MSG\_Mod1\_Cellvolt\_5\}, 8, 16, 0, UINT16\_MAX, 1, 0, littleEndian, &cans getvolt }, /*!
          CANO_SIG_Mod1_volt_15 */
          { (CANO_MSG_Mod1_Cellvolt_5), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
266
          CANO SIG Mod1 volt 16 */
267
          { (CANO_MSG_Mod1_Cellvolt_5), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO_SIG_Mod1_volt_17 */
268
269
          /* Module 1 cell temperatures */
270
          { (CANO_MSG_Mod1_Celltemp_0), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod1 volt valid 0 2 */
271
          { (CANO MSG Mod1 Celltemp 0), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod1 temp 0 */
272
          { (CANO_MSG_Mod1_Celltemp_0), 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod1 temp 1 */
          { (CANO_MSG_Mod1_Celltemp_0}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*! <
273
          CANO_SIG_Mod1_temp_2 */
          { (CANO_MSG_Mod1_Celltemp_1}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
274
          CANO SIG Mod1 volt valid 3 5 */
275
          { (CANO MSG Mod1 Celltemp 1), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod1 temp 3 */
276
          { (CANO MSG Mod1 Celltemp 1), 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod1 temp 4 */
277
          { (CANO_MSG_Mod1_Celltemp_1}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod1 temp 5 */
278
          { (CANO MSG Mod1 Celltemp 2), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!
          CANO SIG Mod1 volt valid 6 8 */
          { (CANO_MSG_Mod1_Celltemp_2), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
279
          CANO SIG Mod1 temp 6 */
280
          { (CANO MSG Mod1 Celltemp 2}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*! <
          CANO_SIG_Mod1_temp_7 */
281
          { (CANO_MSG_Mod1_Celltemp_2}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod1 temp 8 */
282
          { (CANO_MSG_Mod1_Celltemp_3}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
```

```
CANO SIG Mod1 volt valid 9 11 */
          { (CANO MSG Mod1 Celltemp 3}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
283
         CANO SIG Mod1 temp 9 */
284
          { (CANO_MSG_Mod1_Celltemp_3}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
          CANO SIG Mod1 temp 10 */
          { (CANO_MSG_Mod1_Celltemp_3}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
285
         CANO SIG Mod1 temp 11 */
286
287
          /* Module 2 cell voltages */
          { (CANO_MSG_Mod2_Cellvolt_0), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
288
         CANO_SIG_Mod2_volt_valid_0_2 */
289
          { (CANO MSG Mod2 Cellvolt 0), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG Mod2 volt 0 */
290
          { (CANO_MSG_Mod2_Cellvolt_0), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod2 volt 1 */
291
          { (CANO MSG Mod2 Cellvolt 0), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG Mod2 volt 2 */
292
          { (CANO_MSG_Mod2_Cellvolt_1), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod2 volt valid 3 5 */
293
          { \{CAN0\_MSG\_Mod2\_Cellvolt\_1\}, 8, 16, 0, UINT16\_MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO_SIG_Mod2_volt_3 */
294
          { (CANO_MSG_Mod2_Cellvolt_1), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod2 volt 4 */
295
          { (CANO_MSG_Mod2_Cellvolt_1), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO_SIG_Mod2_volt_5 */
296
          { (CANO MSG Mod2 Cellvolt 2), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt ), /*!<
         CANO SIG Mod2 volt valid 6 8 */
297
          { (CANO_MSG_Mod2_Cellvolt_2), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod2 volt 6 */
298
          { (CANO MSG Mod2 Cellvolt 2), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG Mod2 volt 7 */
299
          { (CANO_MSG_Mod2_Cellvolt_2), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod2 volt 8 */
300
          { (CANO MSG Mod2 Cellvolt 3), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO_SIG_Mod2_volt_valid_9_11 */
301
          { (CANO_MSG_Mod2_Cellvolt_3), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod2 volt 9 */
302
          { (CANO_MSG_Mod2_Cellvolt_3), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod2 volt 10 */
303
          { (CANO MSG Mod2 Cellvolt 3), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG Mod2 volt 11 */
304
          { (CANO_MSG_Mod2_Cellvolt_4), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod2 volt valid 12 14 */
          { \{CAN0\_MSG\_Mod2\_Cellvolt\_4\}, 8, 16, 0, UINT16\_MAX, 1, 0, littleEndian, &cans getvolt }, /*!
305
         CANO SIG Mod2 volt 12 */
          { (CANO_MSG_Mod2_Cellvolt_4), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
306
         CANO SIG Mod2 volt 13 */
307
          { (CANO MSG Mod2 Cellvolt 4), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
          CANO_SIG_Mod2_volt_14 */
308
          { (CANO_MSG_Mod2_Cellvolt_5), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod2 volt valid 15 17 */
309
          { (CANO_MSG_Mod2_Cellvolt_5), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
```

```
CANO SIG Mod2 volt 15 */
310
          { (CANO MSG Mod2 Cellvolt 5), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG Mod2 volt 16 */
311
          { (CANO MSG Mod2 Cellvolt 5), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
          CANO SIG Mod2 volt 17 */
312
313
         /* Module 2 cell temperatures */
314
          { (CANO MSG Mod2 Celltemp 0), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod2 volt valid 0 2 */
          { {CANO_MSG_Mod2_Celltemp_0}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
315
         CANO_SIG_Mod2_temp 0 */
316
          { (CANO MSG Mod2 Celltemp 0}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod2 temp 1 */
317
          { (CANO_MSG_Mod2_Celltemp_0}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
          CANO SIG Mod2 temp 2 */
318
          { (CANO MSG Mod2 Celltemp 1), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!
         CANO SIG Mod2 volt valid 3 5 */
319
          { (CANO_MSG_Mod2_Celltemp_1}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod2 temp 3 */
320
          { (CANO MSG Mod2 Celltemp 1), 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO_SIG_Mod2_temp_4 */
          { (CANO_MSG_Mod2_Celltemp_1}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
321
         CANO SIG Mod2 temp 5 */
322
          { (CANO_MSG_Mod2_Celltemp_2), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod2 volt valid 6 8 */
323
          { (CANO MSG Mod2 Celltemp 2), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod2 temp 6 */
324
          { (CANO_MSG_Mod2_Celltemp_2}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod2 temp 7 */
325
          { (CANO MSG Mod2 Celltemp 2}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod2 temp 8 */
326
          { (CANO_MSG_Mod2_Celltemp_3}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod2 volt valid 9 11 */
          { (CANO_MSG_Mod2_Celltemp_3}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
327
         CANO_SIG_Mod2_temp_9 */
          { (CANO_MSG_Mod2_Celltemp_3}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
328
         CANO SIG Mod2 temp 10 */
329
          { {CANO MSG Mod2 Celltemp 3}, 40, 16, −128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
          CANO_SIG_Mod2_temp_11 */
330
331
         /* Module 3 cell voltages */
332
          { (CANO_MSG_Mod3_Cellvolt_0), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod3 volt valid 0 2 */
          { (CANO_MSG_Mod3_Cellvolt_0), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*! <
333
         CANO SIG Mod3 volt 0 */
          { (CANO_MSG_Mod3_Cellvolt_0), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
334
         CANO SIG Mod3 volt 1 */
335
          { (CANO MSG Mod3 Cellvolt 0), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
          CANO_SIG_Mod3_volt_2 */
336
          { (CANO_MSG_Mod3_Cellvolt_1), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod3 volt valid 3 5 */
          { (CANO MSG Mod3 Cellvolt 1), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
337
```

```
CANO SIG Mod3 volt 3 */
          { (CANO MSG Mod3 Cellvolt 1), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
338
         CANO SIG Mod3 volt 4 */
339
          { {CANO MSG Mod3 Cellvolt 1}, 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
          CANO SIG Mod3 volt 5 */
          { (CANO_MSG_Mod3_Cellvolt_2}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
340
         CANO SIG Mod3 volt valid 6 8 */
341
          { (CANO MSG Mod3 Cellvolt 2), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG Mod3 volt 6 */
342
          { (CANO_MSG_Mod3_Cellvolt_2), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO_SIG_Mod3_volt 7 */
343
          { (CANO MSG Mod3 Cellvolt 2), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG Mod3 volt 8 */
          { (CANO_MSG_Mod3_Cellvolt_3), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
344
          CANO SIG Mod3 volt valid 9 11 */
345
          { (CANO MSG Mod3 Cellvolt 3), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG Mod3 volt 9 */
346
          { (CANO_MSG_Mod3_Cellvolt_3), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod3 volt 10 */
347
          { (CANO MSG Mod3 Cellvolt 3), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO_SIG_Mod3_volt_11 */
348
          { (CANO_MSG_Mod3_Cellvolt_4), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod3 volt valid 12 14 */
          { (CANO_MSG_Mod3_Cellvolt_4), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
349
          CANO_SIG_Mod3_volt_12 */
350
          { (CANO MSG Mod3 Cellvolt 4), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG Mod3 volt 13 */
351
          { (CANO_MSG_Mod3_Cellvolt_4), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod3 volt 14 */
352
          { (CANO MSG Mod3 Cellvolt 5), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG Mod3 volt valid 15 17 */
353
          { (CANO_MSG_Mod3_Cellvolt_5), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod3 volt 15 */
          { (CANO_MSG_Mod3_Cellvolt_5), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*! <
354
         CANO_SIG_Mod3_volt_16 */
355
          { (CANO_MSG_Mod3_Cellvolt_5), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod3 volt 17 */
356
357
         /* Module 3 cell temperatures */
358
          { (CANO_MSG_Mod3_Celltemp_0), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod3 volt valid 0 2 */
359
          { (CANO_MSG_Mod3_Celltemp_0), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod3 temp 0 */
360
          { (CANO_MSG_Mod3_Celltemp_0}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod3 temp 1 */
361
          { (CANO MSG Mod3 Celltemp 0), 40, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod3 temp 2 */
          { {CANO_MSG_Mod3_Celltemp_1}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
362
          CANO_SIG_Mod3_volt_valid_3_5 */
363
          { (CANO_MSG_Mod3_Celltemp_1), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod3 temp 3 */
364
          { (CANO MSG Mod3 Celltemp 1), 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
```

```
CANO SIG Mod3 temp 4 */
          { (CANO MSG Mod3 Celltemp 1), 40, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
365
         CANO SIG Mod3 temp 5 */
366
          { (CANO_MSG_Mod3_Celltemp_2), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod3 volt valid 6 8 */
          { (CANO_MSG_Mod3_Celltemp_2), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
367
         CANO SIG Mod3 temp 6 */
368
          { (CANO MSG Mod3 Celltemp 2), 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod3 temp 7 */
369
          { (CANO_MSG_Mod3_Celltemp_2}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO_SIG_Mod3_temp 8 */
370
          { (CANO MSG Mod3 Celltemp 3}, 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!
         CANO SIG Mod3 volt valid 9 11 */
371
          { (CANO_MSG_Mod3_Celltemp_3}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod3 temp 9 */
372
          { (CANO MSG Mod3 Celltemp 3}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod3 temp 10 */
373
          { {CANO_MSG_Mod3_Celltemp_3}, 40, 16, −128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod3 temp 11 */
374
375
         /* Module 4 cell voltages */
376
          { (CANO_MSG_Mod4_Cellvolt_0), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod4 volt valid 0 2 */
          { {CANO_MSG_Mod4_Cellvolt_0}, 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
377
          CANO SIG Mod4 volt 0 */
378
          { (CANO MSG Mod4 Cellvolt 0), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG Mod4 volt 1 */
379
          { (CANO_MSG_Mod4_Cellvolt_0), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod4 volt 2 */
          { (CANO_MSG_Mod4_Cellvolt_1), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
380
         CANO SIG Mod4 volt valid 3 5 */
381
          { (CANO_MSG_Mod4_Cellvolt_1), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod4 volt 3 */
382
          { (CANO MSG Mod4 Cellvolt 1), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO_SIG_Mod4_volt_4 */
383
          { (CANO_MSG_Mod4_Cellvolt_1), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod4 volt 5 */
384
          { (CANO_MSG_Mod4_Cellvolt_2), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO_SIG_Mod4_volt_valid_6_8 */
          { (CANO_MSG_Mod4_Cellvolt_2), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
385
         CANO SIG Mod4 volt 6 */
386
          { (CANO_MSG_Mod4_Cellvolt_2), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod4 volt 7 */
387
          { (CANO MSG Mod4 Cellvolt 2), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO_SIG_Mod4_volt 8 */
388
          { (CANO_MSG_Mod4_Cellvolt_3), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod4 volt valid 9 11 */
          { \{CAN0\_MSG\_Mod4\_Cellvolt\_3\}, 8, 16, 0, UINT16\_MAX, 1, 0, littleEndian, &cans getvolt }, /*!
389
          CANO_SIG_Mod4_volt_9 */
390
          { (CANO_MSG_Mod4_Cellvolt_3), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod4 volt 10 */
          { (CANO MSG Mod4 Cellvolt 3), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
391
```

```
CANO SIG Mod4 volt 11 */
          { (CANO MSG Mod4 Cellvolt 4), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
392
         CANO SIG Mod5 volt valid 12 14 */
393
          { (CANO_MSG_Mod4_Cellvolt_4), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod5 volt 12 */
          { (CANO_MSG_Mod4_Cellvolt_4), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
394
         CANO SIG Mod5 volt 13 */
          { (CANO_MSG_Mod4_Cellvolt_4), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*! <
395
         CANO SIG Mod5 volt 14 */
396
          { (CANO_MSG_Mod4_Cellvolt_5), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG_Mod5_volt_valid_15_17 */
          { (CANO_MSG_Mod4_Cellvolt_5), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
397
         CANO SIG Mod5 volt 15 */
398
          { (CANO_MSG_Mod4_Cellvolt_5), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod5 volt 16 */
399
          { (CANO MSG Mod4 Cellvolt 5), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*! <
         CANO SIG Mod5 volt 17 */
400
401
         /* Module 4 cell temperatures */
402
          { (CANO MSG Mod4 Celltemp 0), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!
         CANO_SIG_Mod4_volt_valid_0_2 */
403
          { (CANO_MSG_Mod4_Celltemp_0), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod4 temp 0 */
          { (CANO_MSG_Mod4_Celltemp_0}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
404
          CANO SIG Mod4 temp 1 */
405
          { (CANO MSG Mod4 Celltemp 0}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod4 temp 2 */
406
          { (CANO_MSG_Mod4_Celltemp_1), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod4 volt valid_3_5 */
407
          { (CANO MSG Mod4 Celltemp 1), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod4 temp 3 */
408
          { (CANO_MSG_Mod4_Celltemp_1}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod4 temp 4 */
409
          { (CANO MSG Mod4 Celltemp 1), 40, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO_SIG_Mod4_temp_5 */
          { (CANO_MSG_Mod4_Celltemp_2), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*! <
410
         CANO SIG Mod4 volt valid 6 8 */
411
          { (CANO MSG Mod4 Celltemp 2), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod4 temp 6 */
412
          { (CANO MSG Mod4 Celltemp 2), 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod4 temp 7 */
413
          { (CANO_MSG_Mod4_Celltemp_2}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod4 temp 8 */
414
          { (CANO MSG Mod4 Celltemp 3), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!
         CANO SIG Mod4 volt valid 9 11 */
415
          { (CANO MSG Mod4 Celltemp 3), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod4 temp 9 */
416
          { (CANO MSG Mod4 Celltemp 3}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
          CANO_SIG_Mod4_temp_10 */
417
          { (CANO_MSG_Mod4_Celltemp_3}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod4 temp 11 */
418
```

```
419
         /* Module 5 cell voltages */
          { (CANO MSG Mod5 Cellvolt 0), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
420
         CANO SIG Mod5 volt valid 0 2 */
421
          { (CANO_MSG_Mod5_Cellvolt_0), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod5 volt 0 */
422
          { (CANO_MSG_Mod5_Cellvolt_0), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod5 volt 1 */
          { (CANO_MSG_Mod5_Cellvolt_0), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*! <
423
         CANO SIG Mod5 volt 2 */
424
          { (CANO_MSG_Mod5_Cellvolt_1), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG_Mod5_volt_valid_3_5 */
425
          { (CANO MSG Mod5 Cellvolt 1), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG Mod5 volt 3 */
426
          { (CANO_MSG_Mod5_Cellvolt_1), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod5 volt 4 */
427
          { (CANO MSG Mod5 Cellvolt 1), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG Mod5 volt 5 */
428
          { (CANO_MSG_Mod5_Cellvolt_2), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod5 volt valid 6 8 */
429
          { \{CAN0\_MSG\_Mod5\_Cellvolt\_2\}, 8, 16, 0, UINT16\_MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO_SIG_Mod5_volt_6 */
430
          { (CANO_MSG_Mod5_Cellvolt_2), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod5 volt 7 */
431
          { (CANO_MSG_Mod5_Cellvolt_2), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO_SIG_Mod5_volt_8 */
432
          { (CANO MSG Mod5 Cellvolt 3), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG Mod5 volt valid 9 11 */
433
          { (CANO_MSG_Mod5_Cellvolt_3), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod5 volt 9 */
          { (CANO_MSG_Mod5_Cellvolt_3}, 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*! <
434
         CANO SIG Mod5 volt 10 */
435
          { (CANO_MSG_Mod5_Cellvolt_3), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod5 volt 11 */
436
          { (CANO MSG Mod5 Cellvolt 4), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO_SIG_Mod5_volt_valid_12_14 */
          { (CANO_MSG_Mod5_Cellvolt_4), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
437
         CANO SIG Mod5 volt 12 */
438
          { (CANO_MSG_Mod5_Cellvolt_4), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod5 volt 13 */
439
          { (CANO MSG Mod5 Cellvolt 4), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG Mod5 volt 14 */
440
          { (CANO_MSG_Mod5_Cellvolt_5), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod5 volt valid 15 17 */
441
          { (CANO_MSG_Mod5_Cellvolt_5), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod5 volt 15 */
          { (CANO_MSG_Mod5_Cellvolt_5), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
442
         CANO SIG Mod5 volt 16 */
          { (CANO_MSG_Mod5_Cellvolt_5), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
443
         CANO_SIG_Mod5_volt_17 */
444
445
          /* Module 5 cell temperatures */
446
          { (CANO MSG Mod5 Celltemp 0), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
```

```
CANO SIG Mod5 volt valid 0 2 */
          { (CANO MSG Mod5 Celltemp 0), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
447
         CANO SIG Mod5 temp 0 */
448
          { (CANO MSG Mod5 Celltemp 0), 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod5 temp 1 */
449
          { (CANO_MSG_Mod5_Celltemp_0}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
         CANO SIG Mod5 temp 2 */
450
          { (CANO MSG Mod5 Celltemp 1), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod5 volt valid 3 5 */
          { {CANO_MSG_Mod5_Celltemp_1}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
451
         CANO_SIG_Mod5_temp 3 */
452
          { (CANO MSG Mod5 Celltemp 1), 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod5 temp 4 */
453
          { (CANO_MSG_Mod5_Celltemp_1}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod5 temp 5 */
454
          { (CANO MSG Mod5 Celltemp 2), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!
         CANO SIG Mod5 volt valid 6 8 */
455
          { (CANO_MSG_Mod5_Celltemp_2), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod5 temp 6 */
456
          { (CANO MSG Mod5 Celltemp 2}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO_SIG_Mod5_temp_7 */
          { (CANO_MSG_Mod5_Celltemp_2}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
457
         CANO SIG Mod5 temp 8 */
458
          { (CANO_MSG_Mod5_Celltemp_3}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
          CANO_SIG_Mod5_volt_valid_9_11 */
459
          { (CANO MSG Mod5 Celltemp 3}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod5 temp 9 */
460
          { (CANO_MSG_Mod5_Celltemp_3}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod5 temp 10 */
461
          { {CANO MSG Mod5 Celltemp 3}, 40, 16, −128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod5 temp 11 */
462
463
         /* Module 6 cell voltages */
464
          { (CANO MSG Mod6 Cellvolt 0), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO_SIG_Mod6_volt_valid_0_2 */
465
          { (CANO_MSG_Mod6_Cellvolt_0), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod6 volt 0 */
466
          { (CANO_MSG_Mod6_Cellvolt_0), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod6 volt 1 */
467
          { (CANO MSG Mod6 Cellvolt 0), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG Mod6 volt 2 */
468
          { (CANO_MSG_Mod6_Cellvolt_1), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod6 volt valid 3 5 */
469
          { (CANO_MSG_Mod6_Cellvolt_1), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt ), /*!<
         CANO SIG Mod6 volt 3 */
          { (CANO_MSG_Mod6_Cellvolt_1), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
470
         CANO SIG Mod6 volt 4 */
471
          { (CANO MSG Mod6 Cellvolt 1), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
          CANO_SIG_Mod6_volt_5 */
472
          { (CANO_MSG_Mod6_Cellvolt_2), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod6 volt valid 6 8 */
          { (CANO MSG Mod6 Cellvolt 2), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
473
```

```
CANO SIG Mod6 volt 6 */
          { (CANO MSG Mod6 Cellvolt 2), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
474
          CANO SIG Mod6 volt 7 */
475
          { {CANO MSG Mod6 Cellvolt 2}, 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
          CANO SIG Mod6 volt 8 */
          { (CANO_MSG_Mod6_Cellvolt_3}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
476
          CANO SIG Mod6 volt valid 9 11 */
477
          { (CANO MSG Mod6 Cellvolt 3), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
          CANO SIG Mod6 volt 9 */
478
          { (CANO_MSG_Mod6_Cellvolt_3), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO_SIG_Mod6_volt_10 */
479
          { (CANO MSG Mod6 Cellvolt 3), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
          CANO SIG Mod6 volt 11 */
          { (CANO_MSG_Mod6_Cellvolt_4), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
480
          CANO SIG Mod6 volt valid 12 14 */
481
          { (CANO MSG Mod6 Cellvolt 4), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
          CANO SIG Mod6 volt 12 */
482
          { (CANO_MSG_Mod6_Cellvolt_4), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod6 volt 13 */
483
          { (CANO MSG Mod6 Cellvolt 4), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
          CANO_SIG_Mod6_volt_14 */
          { (CANO_MSG_Mod6_Cellvolt_5), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt ), /*!<
484
          CANO SIG Mod6 volt valid 15 17 */
485
          { (CANO_MSG_Mod6_Cellvolt_5), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO_SIG_Mod6_volt_15 */
486
          { (CANO MSG Mod6 Cellvolt 5), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
          CANO SIG Mod6 volt 16 */
          { (CANO_MSG_Mod6_Cellvolt_5), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
487
          CANO SIG Mod6 volt 17 */
488
489
          /* Module 6 cell temperatures */
490
          { (CANO_MSG_Mod6_Celltemp_0}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod6 volt valid 0 2 */
          { (CANO_MSG_Mod6_Celltemp_0), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
491
          CANO_SIG_Mod6_temp_0 */
          { (CANO_MSG_Mod6_Celltemp_0}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
492
          CANO SIG Mod6 temp 1 */
493
          { (CANO_MSG_Mod6_Celltemp_0}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
          CANO SIG Mod6 temp 2 */
494
          { (CANO MSG Mod6 Celltemp 1), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod6 volt valid 3 5 */
495
          { (CANO_MSG_Mod6_Celltemp_1), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod6 temp 3 */
496
          { (CANO_MSG_Mod6_Celltemp_1}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod6 temp 4 */
          { (CANO_MSG_Mod6_Celltemp_1}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
497
          CANO SIG Mod6 temp 5 */
          { (CANO_MSG_Mod6_Celltemp_2}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
498
          CANO_SIG_Mod6_volt_valid_6_8 */
499
          { (CANO_MSG_Mod6_Celltemp_2), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod6 temp 6 */
          { (CANO MSG Mod6 Celltemp 2}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
500
```

```
CANO SIG Mod6 temp 7 */
          { {CANO MSG Mod6 Celltemp 2}, 40, 16, −128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
501
         CANO SIG Mod6 temp 8 */
502
          { (CANO_MSG_Mod6_Celltemp_3}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod6 volt valid 9 11 */
          { (CANO_MSG_Mod6_Celltemp_3}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
503
         CANO_SIG_Mod6_temp_9 */
          { (CANO_MSG_Mod6_Celltemp_3}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
504
          CANO SIG Mod6 temp 10 */
505
          { (CANO_MSG_Mod6_Celltemp_3}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
         CANO_SIG_Mod6_temp_11 */
506
507
          /* Module 7 cell voltages */
508
          { (CANO_MSG_Mod7_Cellvolt_0), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod7 volt valid 0 2 */
509
          { (CANO MSG Mod7 Cellvolt 0), 8, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG Mod7 volt 0 */
510
          { (CANO_MSG_Mod7_Cellvolt_0), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
         CANO SIG Mod7 volt 1 */
511
          { (CANO MSG Mod7 Cellvolt 0), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO_SIG_Mod7_volt_2 */
512
          { (CANO_MSG_Mod7_Cellvolt_1), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod7 volt valid 3 5 */
513
          { (CANO_MSG_Mod7_Cellvolt_1), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO_SIG_Mod7_volt_3 */
514
          { (CANO MSG Mod7 Cellvolt 1), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO SIG Mod7 volt 4 */
515
          { (CANO_MSG_Mod7_Cellvolt_1), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO SIG Mod7 volt 5 */
516
          { (CANO MSG Mod7 Cellvolt 2), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG Mod7 volt valid 6 8 */
517
          { (CANO_MSG_Mod7_Cellvolt_2), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod7 volt 6 */
518
          { (CANO MSG Mod7 Cellvolt 2), 24, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
         CANO_SIG_Mod7_volt_7 */
          { (CANO_MSG_Mod7_Cellvolt_2), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
519
         CANO SIG Mod7 volt 8 */
520
          { (CANO_MSG_Mod7_Cellvolt_3}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
          CANO_SIG_Mod7_volt_valid_9_11 */
521
          { (CANO_MSG_Mod7_Cellvolt_3), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod7 volt 9 */
522
          { (CANO_MSG_Mod7_Cellvolt_3), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod7 volt 10 */
          { (CANO_MSG_Mod7_Cellvolt_3}, 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*! <
523
         CANO SIG Mod7 volt 11 */
524
          { (CANO_MSG_Mod7_Cellvolt_4), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /*!<
         CANO SIG Mod7 volt valid 12 14 */
          { \{CAN0\_MSG\_Mod7\_Cellvolt\_4\}, 8, 16, 0, UINT16\_MAX, 1, 0, littleEndian, &cans getvolt }, /*!
525
          CANO_SIG_Mod7_volt_12 */
          { (CANO_MSG_Mod7_Cellvolt_4), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
526
         CANO SIG Mod7 volt 13 */
          { (CANO MSG Mod7 Cellvolt 4), 40, 16, 0, UINT16 MAX, 1, 0, littleEndian, &cans getvolt }, /*!
527
```

```
CANO SIG Mod7 volt 14 */
528
          { (CANO MSG Mod7 Cellvolt 5), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt }, /*!<
         CANO SIG Mod7 volt valid 15 17 */
529
          { (CANO_MSG_Mod7_Cellvolt_5), 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
          CANO SIG Mod7 volt 15 */
          { (CANO_MSG_Mod7_Cellvolt_5), 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt }, /*! <
530
         CANO SIG Mod7 volt 16 */
          { (CANO_MSG_Mod7_Cellvolt_5), 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans getvolt }, /*! <
531
         CANO SIG Mod7 volt 17 */
532
533
         /* Module 7 cell temperatures */
534
          { (CANO MSG Mod7 Celltemp 0), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod4 volt valid 0 2 */
535
          { (CANO_MSG_Mod7_Celltemp_0), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod4 temp 0 */
536
          { {CANO MSG Mod7 Celltemp 0}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*! <
         CANO SIG Mod4 temp 1 */
537
          { (CANO_MSG_Mod7_Celltemp_0), 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
         CANO SIG Mod4 temp 2 */
538
          { (CANO MSG Mod7 Celltemp 1), 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans gettemp }, /*!<
         CANO_SIG_Mod4_volt_valid_3_5 */
          { (CANO_MSG_Mod7_Celltemp_1}, 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
539
         CANO SIG Mod4 temp 3 */
          { (CANO_MSG_Mod7_Celltemp_1}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*! <
540
         CANO SIG Mod4 temp 4 */
541
          { (CANO MSG Mod7 Celltemp 1), 40, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod4 temp 5 */
542
          { (CANO_MSG_Mod7_Celltemp_2), 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
          CANO SIG Mod4 volt valid 6 8 */
          { (CANO_MSG_Mod7_Celltemp_2), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
543
         CANO SIG Mod4 temp 6 */
544
          { (CANO_MSG_Mod7_Celltemp_2}, 24, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod4 temp 7 */
545
          { (CANO_MSG_Mod7_Celltemp_2}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*! <
         CANO_SIG_Mod4_temp_8 */
          { (CANO_MSG_Mod7_Celltemp_3}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_gettemp }, /*!<
546
         CANO SIG Mod4 volt valid 9 11 */
547
          { (CANO MSG Mod7 Celltemp 3), 8, 16, -128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
          CANO SIG Mod4 temp 9 */
548
          { {CANO MSG Mod7 Celltemp 3}, 24, 16, −128, 527.35, 100, 128, littleEndian, &cans gettemp }, /*!<
         CANO SIG Mod4 temp 10 */
549
          { (CANO_MSG_Mod7_Celltemp_3}, 40, 16, -128, 527.35, 100, 128, littleEndian, &cans_gettemp }, /*!<
         CANO SIG Mod4 temp 11 */
550
551
      #ifdef CURRENT SENSOR ISABELLENHUETTE TRIGGERED
              {{CANO_MSG_BMS_CurrentTrigger}, 0, 32, 0, 0, 1, 0, &cans_gettriggercurrent} /*!< CANO_SIG_ISA Trigger */
552
      #endif /* CURRENT SENSOR ISABELLENHUETTE TRIGGERED */
553
554
      };
555
556
557
      const CANS signal s cans CAN1 signals tx[] = {
558
      };
```

## Indexes for the CAN signals:

```
C cansignal_cfg.h × C can_cfg.c
                                    C can.h
                                                    C can.c
mcu-primary > src > module > config > C cansignal_cfg.h > •○ CANS_signal_s
      typedef enum {
242
           CANO_SIG_GSO_general_error, /* 0:good, 1:error */
243
           CANO_SIG_GSO_current_state, /* currently no used */
244
           CANO_SIG_GSO_error_overtemp_charge, /* 0:good, 1:error */
C cansignal.c
                C cansignal_cfg.h × C cansign
mcu-primary > src > module > config > C cansignal_cfc
           CANO_SIG_ModO_volt_valid_0_2,
334
           CANO_SIG_ModO_volt_0,
335
           CANO_SIG_ModO_volt_1,
336
           CANO_SIG_ModO_volt_2,
337
           CANO_SIG_ModO_volt_valid_3_5,
338
           CANO_SIG_Mod0_volt_3,
339
           CANO_SIG_ModO_volt_4,
340
           CANO_SIG_Mod0_volt_5,
341
           CANO_SIG_ModO_volt_valid_6_8,
342
           CANO_SIG_ModO_volt_6,
343
           CANO_SIG_ModO_volt_7,
344
           CANO_SIG_ModO_volt_8,
345
           CANO SIG ModO volt valid 9 11,
346
           CANO_SIG_Mod0_volt_9,
347
           CANO_SIG_ModO_volt_10,
348
           CANO_SIG_ModO_volt_11,
349
           CANO_SIG_ModO_volt_valid_12_14,
350
           CANO_SIG_ModO_volt_12,
351
           CANO_SIG_ModO_volt_13,
352
           CANO_SIG_ModO_volt_14,
353
           CANO_SIG_ModO_volt_valid_15_17,
354
           CANO_SIG_ModO_volt_15,
355
           CANO_SIG_ModO_volt_16,
356
           CANO_SIG_ModO_volt_17,
357
358
           CANO_SIG_ModO_temp_valid_0_2,
C cansignal_cfg.h × C can_cfg.c
                                    C can.h
mcu-primary > src > module > config > C cansignal_cfg.h > • O CANS_signal_s
665
           CANO_SIG_Mod7_temp_9,
666
           CANO_SIG_Mod7_temp_10,
667
           CANO_SIG_Mod7_temp_11,
668
669
       #ifdef CURRENT_SENSOR_ISABELLENHUETTE_TRIGGERED
670
           CANO_SIG_ISA_Trigger,
      #endif /* CURRENT_SENSOR_ISABELLENHUETTE_TRIGGERED */
671
672
673
           CANO SIGNAL NONE = 0xFFFF
674 } CANS_CANO_signalsTx_e;
```

C strr

```
mcu-primary > src > module > config > C cansignal_cfg.h > •○ CANS_signal_s
754 typedef struct {
        CANS_messages_t msgIdx;
755
756
        uint8_t bit_position;
757
        uint8_t bit_length;
758
        float min:
759
        float max:
        float factor;
761
        float offset;
762
        CANS_byteOrder_e byteOrder;
        can_callback_funcPtr callback;
     ) CANS signal s;
```

```
560
561
      const CANS signal's cans CANO signals rx[] = {
562
          { (CANO MSG StateRequest), 8, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans setstaterequest },
563
          { (CANO MSG IVT Current), 0, 8, 0, UINT8 MAX, 1, 0, bigEndian, NULL PTR }, /* CANO SIG ISENSO I MuxID */
564
          { {CANO_MSG_IVT_Current}, 8, 8, 0, UINT8_MAX, 1, 0, bigEndian, NULL_PTR }, /* CANO_SIG_ISENSO_I_Status */
565
          { {CANO MSG IVT Current}, 16, 32, INT32 MIN, INT32 MAX, 1, 0, bigEndian, &cans setcurr }, /*
          CANO SIG ISENSO I Measurement */
566
          { (CANO MSG IVT Voltage 1), 0, 8, 0, UINT8 MAX, 1, 0, bigEndian, NULL PTR }, /* CANO SIG ISENS1 U1 MuxID */
          { {CANO_MSG_IVT_Voltage_1}, 8, 8, 0, UINT8_MAX, 1, 0, bigEndian, NULL_PTR }, /* CANO_SIG_ISENS1_U1_Status */
567
568
          { (CANO_MSG_IVT_Voltage_1), 16, 32, 0, INT32_MAX, 1, 0, bigEndian, &cans_setcurr }, /*
          CANO SIG ISENS1 U1 Measurement */
569
          { (CANO_MSG_IVT_Voltage_2), 0, 8, 0, UINT8_MAX, 1, 0, bigEndian, NULL_PTR }, /* CANO_SIG_ISENS2_U2_MuxID */
570
          { (CANO_MSG_IVT_voltage_2), 8, 8, 0, UINT8_MAX, 1, 0, bigEndian, NULL_PTR }, /* CANO_SIG_ISENS2_U2_Status */
571
          { (CANO_MSG_IVT_Voltage_2}, 16, 32, 0, INT32_MAX, 1, 0, bigEndian, &cans_setcurr, }, /*
          CANO SIG ISENS2 U2 Measurement */
572
          { (CANO_MSG_IVT_Voltage_3), 0, 8, 0, UINT8_MAX, 1, 0, bigEndian, NULL_PTR }, /* CANO_SIG_ISENS3_U3_MuxID */
573
          { (CANO_MSG_IVT_Voltage_3), 8, 8, 0, UINT8_MAX, 1, 0, bigEndian, NULL_PTR }, /* CANO_SIG_ISENS3 U3 Status */
574
          { (CANO MSG IVT Voltage 3), 16, 32, 0, INT32 MAX, 1, 0, bigEndian, &cans setcurr, }, /*
          CANO SIG ISENS3 U3 Measurement */
575
          { (CANO_MSG_IVT_Temperature), 0, 8, 0, UINT8_MAX, 1, 0, bigEndian, NULL_PTR }, /* CANO_SIG_ISENS4_T_MuxID */
576
          { (CANO_MSG_IVT_Temperature), 8, 8, 0, UINT8_MAX, 1, 0, bigEndian, NULL_PTR }, /* CANO_SIG_ISENS4_T_Status */
          { (CANO_MSG_IVT_Temperature), 16, 32, INT32_MIN, INT32_MAX, 0.1, 0, bigEndian, &cans_setcurr }, /*
577
          CANO_SIG_ISENS4_T_Measurement */
578
          { (CANO_MSG_IVT_Power), 0, 8, 0, UINT8_MAX, 1, 0, bigEndian, NULL_PTR }, /* CANO_SIG_ISENS5_P_MuxID */
579
          { (CANO MSG IVT Power), 8, 8, 0, UINT8 MAX, 1, 0, bigEndian, NULL PTR }, /* CANO SIG ISENS5 P Status */
580
          { (CANO_MSG_IVT_Power), 16, 32, INT32_MIN, INT32_MAX, 1, 0, bigEndian, &cans_setcurr }, /*
          CANO SIG ISENS5 P Measurement */
581
          { {CANO MSG IVT CoulombCount}, 0, 8, 0, UINT8 MAX, 1, 0, bigEndian, NULL PTR }, /* CANO SIG ISENS6 CC MuxID */
582
          { (CANO_MSG_IVT_CoulombCount), 8, 8, 0, UINT8_MAX, 1, 0, bigEndian, NULL_PTR }, /* CANO_SIG_ISENS6_CC_Status */
          { (CANO_MSG_IVT_CoulombCount), 16, 32, INT32_MIN, INT32_MAX, 1, 0, bigEndian, &cans_setcurr }, /*
583
          CANO SIG ISENS6 CC Measurement */
584
          { (CANO MSG IVT EnergyCount), 0, 8, 0, UINT8 MAX, 1, 0, bigEndian, NULL PTR }, /* CANO SIG ISENS7 EC MuxID */
585
          { (CANO MSG IVT EnergyCount), 8, 8, 0, UINT8 MAX, 1, 0, bigEndian, NULL PTR }, /* CANO SIG ISENS7 EC Status */
          { (CANO_MSG_IVT_EnergyCount), 16, 32, INT32_MIN, INT32_MAX, 1, 0, bigEndian, &cans_setcurr }, /*
586
          CANO SIG ISENS7 EC Measurement */
587
          { (CANO_MSG_DEBUG), 0, 64, 0, UINT64_MAX, 1, 0, littleEndian, &cans_setdebug }, /* CANO_SIG_DEBUG_Data */
588
          { (CANO MSG GetReleaseVersion), 0, 64, 0, UINT64 MAX, 1, 0, littleEndian, &cans setSWversion }, /*
          CANO SIG DEBUG Data */
                                                                            C cansignal.c × C cansignal_cfg.h
                                                                                                  C can_cfq.c
                                                                                                           C can.h
                                                                                                                      C can.c
589
          { (CANO MSG EngineRequest), 0, 8, 0, UINT8 MAX, 1, 0, littleEnd
                                                                            mcu-common > src > module > cansignal > C cansignal.c > 分 CANS_ParseMessage(CAN_Node
590
      };
                                                                                        /* simple, not multiplexed signal */
591
                                                                            343
                                                                                        uint64 t value = 0;
592
      const CANS_signal_s cans_CAN1_signals_rx[] = {
                                                                            344
                                                                                        if (cans_signals_tx[i].callback != NULL_PTR) {
593
      };
                                                                            345
                                                                                          cans_signals_tx[i].callback(i, &value);
594
                                                                            346
                                                                            347
                                                                                        CANS_SetSignalData(cans signals tx[i], value, dataptr);
595
596
      const uint16 t cans CANO signals tx length = sizeof(cans CANO signals tx)/sizeof(cans CANO signals tx[0]);
597
      const uint16 t cans CAN1 signals tx length = sizeof(cans CAN1 signals tx)/sizeof(cans CAN1 signals tx[0]);
598
599
      const uint16_t cans_CAN0_signals_rx_length = sizeof(cans_CAN0_signals_rx)/sizeof(cans_CAN0_signals_rx[0]);
600
      const uint16 t cans CAN1 signals rx length = sizeof(cans CAN1 signals rx)/sizeof(cans CAN1 signals rx[0]);
601
```

559

```
602
       /*========= Static Function Implementations ================*/
603
                          Called in Line 345 \
                                                                                    C cansignal_cfq.h × C can_cfq.c
604
      static uint32_t cans_getvolt(uint32_t sigIdx, void *value) {
605
           static DATA_BLOCK_CELLVOLTAGE_s volt_tab;
                                                                                    mcu-primary > src > module > config > C cansignal_cfg.h
                                                                                             CANO_SIG_ModO_volt_valid_0_2,
606
           uint16 t modIdx = 0;
                                                                                     334
                                                                                             CANO_SIG_ModO_volt_0,
607
           uint32_t cellIdx = 0;
                                                                                     335
                                                                                             CANO_SIG_ModO_volt_1,
608
           uint32_t tmp = 0;
                                                                                     336
                                                                                             CANO_SIG_Mod0_volt_2,
609
           uint32 t tmpVal = 0;
                                                                                     337
                                                                                             CANO_SIG_Mod0_volt_valid_3_5,
610
           float canData = 0;
                                     No need to have a floating point number.
611
                                                                                  C cansignal_cfq.c X C cansignal.c P Search: CANS_add C cansignal.h
                                                                                                                                         C bms_cfg.h
612
           /* first signal to transmit cell voltages */
                                                                                  mcu-primary ≥ src > module > config > C cansignal_cfg.c > [ø] cans_CAN0_signals_rx
613
           if (sigIdx == CANO SIG ModO volt valid 0 2) {
                                                                                   201
                                                                                          /* Module 0 cell voltages */
                                                                                          { {CANO MSG Modo Cellvolt 0}, 0, 8, 0, UINT8 MAX, 1, 0, littleEndian, &cans getvolt },
                                                                                   202
614
                DB_ReadBlock(&volt_tab, DATA_BLOCK_ID_CELLVOLTAGE);
                                                                                   203
                                                                                          { {CANO_MSG_ModO_Cellvolt_0}, 8, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt },
615
           }
                                                                                   204
                                                                                          { {CANO_MSG_Mod0_Cellvolt_0}, 24, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt },
                                                                                   205
                                                                                          { {CANO_MSG_Mod0_Cellvolt_0}, 40, 16, 0, UINT16_MAX, 1, 0, littleEndian, &cans_getvolt },
616
                                                                                         { {CANO_MSG_Mod0_Cellvolt_1}, 0, 8, 0, UINT8_MAX, 1, 0, littleEndian, &cans_getvolt }, /
617
           /* Determine module and cell number */
618
           if (sigIdx - CANO_SIG_Mod0_volt_valid_0_2 < CANS_MODULSIGNALS_VOLT) {</pre>
619
                modIdx = 0;
                cellIdx = sigIdx - CANO SIG ModO volt valid 0 2;
620
621
           } else if (sigIdx - CANO SIG Mod1 volt valid 0 2 < CANS MODULSIGNALS VOLT) {
622
                modIdx = 1;
623
                cellIdx = sigIdx - CANO SIG Mod1 volt valid 0 2;
624
           } else if (sigIdx - CANO SIG Mod2 volt valid 0 2 < CANS MODULSIGNALS VOLT) {
625
                modIdx = 2;
626
                cellIdx = sigIdx - CANO_SIG_Mod2_volt_valid_0_2;
627
           } else if (sigIdx - CANO SIG Mod3 volt valid 0 2 < CANS MODULSIGNALS VOLT) {
628
629
                cellIdx = sigIdx - CANO_SIG_Mod3_volt_valid_0_2;
630
           } else if (sigIdx - CAN0_SIG_Mod4_volt_valid_0_2 < CANS_MODULSIGNALS_VOLT) {</pre>
631
                modIdx = 4:
632
                cellIdx = sigIdx - CANO SIG Mod4 volt valid 0 2;
633
           } else if (siqIdx - CANO_SIG_Mod5_volt_valid_0_2 < CANS_MODULSIGNALS_VOLT) {</pre>
634
                modIdx = 5;
635
                cellIdx = sigIdx - CANO SIG Mod5 volt valid 0 2;
636
           } else if (siqIdx - CANO_SIG_Mod6_volt_valid_0_2 < CANS_MODULSIGNALS_VOLT) {</pre>
637
                modIdx = 6;
638
                cellIdx = sigIdx - CANO_SIG_Mod6_volt_valid_0_2;
639
           } else if (sigIdx - CANO SIG Mod7 volt valid 0 2 < CANS MODULSIGNALS VOLT) {
640
                modIdx = 7;
641
                cellIdx = sigIdx - CANO SIG Mod7 volt valid 0 2;
642
           }
                                                                                              C cansignal_cfg.c × C can_cfg.c
                                                                               C cansignal_cfg.h
                                                                                                                                     C can.c
                                                                                                                                                  C stm
643
644
           if (value != NULL PTR) {
                                                                   645
                switch (siqIdx) {
                                                                    67 #define CANS_MODULSIGNALS_VOLT (CAN0 SIG Mod0 temp valid 0 2 - CAN0 SIG Mod0 volt valid 0 2)
646
                     case CANO SIG ModO volt valid 0 2:
                                                                    68 #define CANS_MODULSIGNALS_TEMP
                                                                                                     (CANO SIG Mod1 volt valid 0 2 - CANO SIG Mod0 temp valid 0 2)
647
                     case CANO SIG Mod1 volt valid 0 2:
648
                     case CANO SIG Mod2 volt valid 0 2:
649
                     case CANO SIG Mod3 volt valid 0 2:
650
                                                               /* Valid flags for cell voltages 0 - 2 */
                     case CANO_SIG_Mod4_volt_valid_0_2:
651
                     case CAN0_SIG_Mod5_volt_valid_0_2:
652
                     case CAN0_SIG_Mod6_volt_valid_0_2:
653
                     case CAN0_SIG_Mod7_volt_valid_0_2:
```

```
654
                      if (modIdx >= BS NR OF MODULES) {
655
                           tmpVal = CAN DEFAULT VALID FLAG;
656
                      } else {
657
                           tmp = volt_tab.valid_volt[modIdx];
658
659
                      *(uint32_t *) value = 0x07 & tmp;
660
                      break;
661
662
                  case CANO SIG Mod0 volt valid 3 5:
663
                  case CAN0_SIG_Mod1_volt_valid_3_5:
664
                  case CAN0_SIG_Mod2_volt_valid_3_5:
665
                  case CAN0_SIG_Mod3_volt_valid_3_5:
666
                  case CANO SIG Mod4 volt valid 3 5:
                                                        /* Valid flags for cell voltages 3 - 5 */
667
                  case CAN0_SIG_Mod5_volt_valid_3_5:
668
                  case CAN0_SIG_Mod6_volt_valid_3_5:
669
                  case CANO SIG Mod7 volt valid 3 5:
670
                      if (modIdx >= BS_NR_OF_MODULES) {
671
                           tmpVal = CAN_DEFAULT_VALID_FLAG;
672
                      } else {
673
                           tmp = volt tab.valid volt[modIdx] >> 3;
674
675
                      tmpVal = 0x07 \& tmp;
676
                      break;
677
678
                  case CAN0_SIG_Mod0_volt_valid_6_8:
679
                  case CANO SIG Mod1 volt valid 6 8:
680
                  case CANO SIG Mod2 volt valid 6 8:
681
                  case CAN0_SIG_Mod3_volt_valid_6_8;
682
                  case CANO_SIG_Mod4_volt_valid_6_8;
                                                       /* Valid flags for cell voltages 6 - 8 */
683
                  case CANO SIG Mod5 volt valid 6 8:
684
                  case CAN0_SIG_Mod6_volt_valid_6_8:
685
                  case CAN0_SIG_Mod7_volt_valid_6_8:
686
                      if (modIdx >= BS NR OF MODULES) {
687
                           tmpVal = CAN DEFAULT VALID FLAG;
688
                      } else {
689
                           tmp = volt_tab.valid_volt[modIdx] >> 6;
                      } /
690
                      tmpVal = 0 \times 07 & tmp;
691
692
                      break;
693
694
                  case CANO SIG ModO volt valid 9 11:
695
                  case CANO_SIG_Mod1_volt_valid_9_11:
696
                  case CANO SIG Mod2 volt valid 9 11:
697
                  case CANO SIG Mod3 volt valid 9 11:
698
                  case CANO SIG Mod4 volt valid 9 11: /* Valid flags for cell voltages 9 - 11 */
699
                  case CANO SIG Mod5 volt valid 9 11:
700
                  case CANO SIG Mod6 volt valid 9 11:
701
                  case CANO SIG Mod7 volt valid 9 11:
702
                      if (modIdx >= BS_NR_OF_MODULES) {
703
                           tmpVal = CAN_DEFAULT_VALID_FLAG;
704
                      } else {
705
                           tmp = volt tab.valid volt[modIdx] >> 9;
```

```
706
707
                      tmpVal = 0x07 \& tmp;
708
                      break;
709
710
                  case CANO SIG ModO volt valid 12 14:
711
                  case CAN0_SIG_Mod1_volt_valid_12_14:
712
                  case CANO_SIG_Mod2_volt_valid_12_14:
713
                  case CANO SIG Mod3 volt valid 12 14:
714
                  case CANO SIG Mod4 volt valid 12 14:
                                                          /* Valid flags for cell voltages 12 - 14 */
715
                  case CAN0_SIG_Mod5_volt_valid_12_14:
716
                  case CANO_SIG_Mod6_volt_valid_12_14:
717
                  case CAN0_SIG_Mod7_volt_valid_12_14:
718
                       if (modIdx >= BS NR OF MODULES) {
719
                           tmpVal = CAN_DEFAULT_VALID_FLAG;
720
                       } else {
721
                           tmp = volt tab.valid volt[modIdx] >> 12;
722
723
                      tmpVal = 0x07 \& tmp;
724
                      break;
725
726
                  case CAN0_SIG_Mod0_volt_valid_15_17:
727
                  case CAN0_SIG_Mod1_volt_valid_15_17:
728
                  case CANO SIG Mod2 volt valid 15 17:
729
                  case CANO_SIG_Mod3_volt_valid_15_17:
730
                  case CANO_SIG_Mod4_volt_valid_15_17:
                                                         /* Valid flags for cell voltages 15 - 17 */
731
                  case CANO SIG Mod5 volt valid 15 17:
732
                  case CAN0_SIG_Mod6_volt_valid_15_17:
733
                  case CAN0_SIG_Mod7_volt_valid_15_17:
734
                       if (modIdx >= BS_NR_OF_MODULES) {
735
                           tmpVal = CAN DEFAULT VALID FLAG;
736
                       } else {
737
                           tmp = volt_tab.valid_volt[modIdx] >> 15;
738
739
                      tmpVal = 0x07 \& tmp;
740
                      break;
741
742
                  case CAN0_SIG_Mod0_volt_0:
743
                  case CANO SIG Mod0 volt 1:
744
                  case CAN0_SIG_Mod0_volt_2:
745
                  case CAN0_SIG_Mod1_volt_0:
746
                  case CANO SIG Mod1 volt 1:
747
                  case CAN0_SIG_Mod1_volt_2:
748
                  case CANO SIG Mod2 volt 0:
749
                  case CAN0_SIG_Mod2_volt_1:
750
                  case CANO SIG Mod2 volt 2:
751
                  case CANO SIG Mod3 volt 0:
752
                  case CANO SIG Mod3 volt 1:
753
                  case CANO SIG Mod3 volt 2:
754
                  case CAN0_SIG_Mod4_volt_0:
755
                  case CANO_SIG_Mod4_volt_1:
756
                  case CAN0_SIG_Mod4_volt_2:
                  case CAN0_SIG_Mod5_volt_0:
757
```

```
758
                  case CANO SIG Mod5 volt 1:
759
                  case CANO SIG Mod5 volt 2:
760
                  case CAN0_SIG_Mod6_volt_0:
761
                  case CANO SIG Mod6 volt 1:
762
                  case CANO SIG Mod6 volt 2:
763
                  case CAN0_SIG_Mod7_volt_0:
764
                  case CANO SIG Mod7 volt 1:
765
                  case CANO SIG Mod7 volt 2:
                      cellIdx--; /* Because cell 0 - valid flag = 1, decrement by one to get the right index */
766
767
                      if ((modIdx * BS_NR_OF_BAT_CELLS_PER_MODULE) + cellIdx >= BS_NR_OF_BAT_CELLS) {
768
                          tmpVal = CAN_DEFAULT_VOLTAGE;
769
                      } else {
770
                          tmpVal = volt_tab.voltage[(modIdx * BS_NR_OF_BAT_CELLS_PER_MODULE) + cellIdx];
771
772
                      break;
773
774
                  case CAN0_SIG_Mod0_volt_3:
775
                  case CAN0_SIG_Mod0_volt_4:
776
                  case CANO SIG ModO volt 5:
777
                  case CANO SIG Mod1 volt 3:
778
                  case CANO_SIG_Mod1_volt_4:
779
                  case CAN0_SIG_Mod1_volt_5:
780
                  case CANO SIG Mod2 volt 3:
781
                  case CAN0_SIG_Mod2_volt_4:
782
                  case CAN0_SIG_Mod2_volt_5:
783
                  case CANO SIG Mod3 volt 3:
784
                  case CANO SIG Mod3 volt 4:
785
                  case CAN0_SIG_Mod3_volt_5:
786
                  case CANO SIG Mod4 volt 3:
787
                  case CANO SIG Mod4 volt 4:
788
                  case CAN0_SIG_Mod4_volt_5:
789
                  case CANO SIG Mod5 volt 3:
790
                  case CANO SIG Mod5 volt 4:
791
                  case CANO SIG Mod5 volt 5:
792
                  case CANO_SIG_Mod6_volt_3:
793
                  case CAN0_SIG_Mod6_volt_4:
794
                  case CAN0_SIG_Mod6_volt_5:
795
                  case CANO SIG Mod7 volt 3:
796
                  case CAN0_SIG_Mod7_volt_4:
797
                  case CANO SIG Mod7 volt 5:
798
                      cellIdx--; /* Because cell 0 - valid flag = 1, decrement by one to get the right index */
799
                      cellIdx--; /* Because of signal: CANO_SIG_Modx_volt_valid_3_5 */
800
                      if ((modIdx * BS_NR_OF_BAT_CELLS_PER_MODULE) + cellIdx >= BS_NR_OF_BAT_CELLS) {
801
                          tmpVal = CAN DEFAULT VOLTAGE;
802
                      } else {
803
                          tmpVal = volt_tab.voltage[(modIdx * BS_NR_OF_BAT_CELLS_PER_MODULE) + cellIdx];
804
                      }
805
                      break;
806
807
                  case CAN0_SIG_Mod0_volt_6:
808
                  case CAN0_SIG_Mod0_volt_7:
809
                  case CANO SIG Mod0 volt 8:
```

```
810
                  case CANO SIG Mod1 volt 6:
811
                  case CANO SIG Mod1 volt 7:
812
                  case CAN0_SIG_Mod1_volt_8:
813
                  case CANO SIG Mod2 volt 6:
814
                  case CANO SIG Mod2 volt 7:
815
                  case CAN0_SIG_Mod2_volt_8:
816
                  case CANO SIG Mod3 volt 6:
817
                  case CANO SIG Mod3 volt 7:
818
                  case CANO SIG Mod3 volt 8:
819
                  case CAN0_SIG_Mod4_volt_6:
820
                  case CANO_SIG_Mod4_volt_7:
821
                  case CAN0_SIG_Mod4_volt_8:
822
                  case CANO SIG Mod5 volt 6:
823
                  case CAN0_SIG_Mod5_volt_7:
824
                  case CAN0_SIG_Mod5_volt_8:
825
                  case CANO SIG Mod6 volt 6:
826
                  case CAN0_SIG_Mod6_volt_7:
827
                  case CAN0_SIG_Mod6_volt_8:
828
                  case CANO SIG Mod7 volt 6:
829
                  case CANO SIG Mod7 volt 7:
830
                  case CANO_SIG_Mod7_volt_8:
831
                      cellIdx--; /* Because cell 0 - valid flag = 1, decrement by one to get the right index */
832
                      cellIdx--; /* Because of signal: CANO SIG Modx volt valid 3 5 */
833
                      cellIdx--; /* Because of signal: CANO_SIG_Modx_volt_valid_6_8 */
834
                      if ((modIdx * BS_NR_OF_BAT_CELLS_PER_MODULE) + cellIdx >= BS_NR_OF_BAT_CELLS) {
835
                          tmpVal = CAN DEFAULT VOLTAGE;
836
                      } else {
837
                          tmpVal = volt_tab.voltage[(modIdx * BS_NR_OF_BAT_CELLS_PER_MODULE) + cellIdx];
838
839
                      break;
840
841
                  case CANO SIG ModO volt 9:
842
                  case CANO SIG Mod0 volt 10:
843
                  case CANO SIG Mod0 volt 11:
844
                  case CAN0_SIG_Mod1_volt_9:
845
                  case CANO_SIG_Mod1_volt_10:
846
                  case CAN0_SIG_Mod1_volt_11:
847
                  case CANO SIG Mod2 volt 9:
848
                  case CANO_SIG_Mod2_volt_10:
849
                  case CAN0_SIG_Mod2_volt_11:
850
                  case CANO SIG Mod3 volt 9:
851
                  case CANO_SIG_Mod3_volt_10:
852
                  case CANO SIG Mod3 volt 11:
853
                  case CANO SIG Mod4 volt 9:
854
                  case CANO SIG Mod4 volt 10:
855
                  case CANO SIG Mod4 volt 11:
856
                  case CANO SIG Mod5 volt 9:
857
                  case CANO SIG Mod5 volt 10:
858
                  case CANO_SIG_Mod5_volt_11:
859
                  case CANO_SIG_Mod6_volt_9:
860
                  case CAN0_SIG_Mod6_volt_10:
861
                  case CANO SIG Mod6 volt 11:
```

```
862
                  case CANO SIG Mod7 volt 9:
863
                  case CANO SIG Mod7 volt 10:
864
                  case CANO_SIG_Mod7_volt_11:
865
                      cellIdx--; /* Because cell 0 - valid flag = 1, decrement by one to get the right index */
866
                      cellIdx--; /* Because of signal: CAN0_SIG_Modx_volt_valid_3_5 */
867
                      cellIdx--; /* Because of signal: CANO_SIG_Modx_volt_valid_6_8 */
868
                      cellIdx--; /* Because of signal: CANO_SIG_Modx_volt_valid_9_11 */
                      if ((modIdx * BS_NR_OF_BAT_CELLS_PER_MODULE) + cellIdx >= BS_NR_OF_BAT_CELLS) {
869
870
                          tmpVal = CAN DEFAULT VOLTAGE;
871
                      } else {
872
                          tmpVal = volt_tab.voltage[(modIdx * BS_NR_OF_BAT_CELLS_PER_MODULE) + cellIdx];
873
                      }
874
                      break;
875
876
                  case CANO SIG ModO volt 12:
877
                  case CANO SIG Mod0 volt 13:
878
                  case CANO_SIG_Mod0_volt_14:
879
                  case CANO SIG Mod1 volt 12:
880
                  case CANO SIG Mod1 volt 13:
881
                  case CANO SIG Mod1 volt 14:
882
                  case CAN0_SIG_Mod2_volt_12:
883
                  case CAN0_SIG_Mod2_volt_13:
884
                  case CANO SIG Mod2 volt 14:
885
                  case CANO_SIG_Mod3_volt_12:
886
                  case CANO_SIG_Mod3_volt_13:
887
                  case CANO SIG Mod3 volt 14:
888
                  case CANO SIG Mod4 volt 12:
889
                  case CANO_SIG_Mod4_volt_13:
890
                  case CANO SIG Mod4 volt 14:
891
                  case CANO SIG Mod5 volt 12:
892
                  case CANO SIG Mod5 volt 13:
893
                  case CANO SIG Mod5 volt 14:
894
                  case CANO SIG Mod6 volt 12:
895
                  case CANO SIG Mod6 volt 13:
896
                  case CAN0_SIG_Mod6_volt_14:
897
                  case CAN0_SIG_Mod7_volt_12:
898
                  case CAN0_SIG_Mod7_volt_13:
899
                  case CANO SIG Mod7 volt 14:
                      cellIdx--; /* Because cell 0 - valid flag = 1, decrement by one to get the right index */
900
901
                      cellIdx--; /* Because of signal: CANO SIG Modx volt valid 3 5 */
902
                      cellIdx--: /* Because of signal: CANO SIG Modx volt valid 6 8 */
903
                      cellIdx--; /* Because of signal: CANO_SIG_Modx_volt_valid_9_11 */
904
                      cellIdx--; /* Because of signal: CANO SIG Modx volt valid 12 14 */
905
                      if ((modIdx * BS NR OF BAT CELLS PER MODULE) + cellIdx >= BS NR OF BAT CELLS) {
                          tmpVal = CAN DEFAULT VOLTAGE;
906
907
908
                          tmpVal = volt tab.voltage[(modIdx * BS NR OF BAT CELLS PER MODULE) + cellIdx];
909
910
                      break;
911
912
                  case CANO SIG Mod0 volt 15:
913
                  case CANO SIG Mod0 volt 16:
```

```
914
                  case CANO SIG Mod0 volt 17:
915
                  case CANO SIG Mod1 volt 15:
916
                  case CANO_SIG_Mod1_volt_16:
917
                  case CANO SIG Mod1 volt 17:
918
                  case CANO SIG Mod2 volt 15:
919
                  case CANO_SIG_Mod2_volt_16:
920
                  case CAN0_SIG_Mod2_volt_17:
921
                  case CANO SIG Mod3 volt 15:
922
                  case CANO SIG Mod3 volt 16:
923
                  case CAN0_SIG_Mod3_volt_17:
924
                  case CAN0_SIG_Mod4_volt_15:
925
                  case CANO SIG Mod4 volt 16:
926
                  case CANO SIG Mod4 volt 17:
927
                  case CANO_SIG_Mod5_volt_15:
928
                  case CAN0_SIG_Mod5_volt_16:
929
                  case CANO SIG Mod5 volt 17:
930
                  case CANO_SIG_Mod6_volt_15:
                  case CAN0_SIG_Mod6_volt_16:
931
932
                  case CANO SIG Mod6 volt 17:
933
                  case CANO SIG Mod7 volt 15:
934
                  case CAN0_SIG_Mod7_volt_16:
935
                  case CAN0_SIG_Mod7_volt_17:
936
                      cellIdx--; /* Because cell 0 - valid flag = 1, decrement by one to get the right index */
937
                      cellIdx--; /* Because of signal: CANO_SIG_Modx_volt_valid_3_5 */
938
                      cellIdx--; /* Because of signal: CANO_SIG_Modx_volt_valid_6_8 */
                      cellIdx--; /* Because of signal: CANO SIG Modx volt valid 9 11 */
939
                      cellIdx--; /* Because of signal: CANO SIG Modx volt valid 12 14 */
940
941
                      cellIdx--; /* Because of signal: CANO_SIG_Modx_volt_valid_15_17 */
942
                      if ((modIdx * BS_NR_OF_BAT_CELLS_PER_MODULE) + cellIdx >= BS_NR_OF_BAT_CELLS) {
943
                          tmpVal = CAN DEFAULT VOLTAGE;
944
                      } else {
945
                          tmpVal = volt_tab.voltage[(modIdx * BS_NR_OF_BAT_CELLS_PER_MODULE) + cellIdx];
946
947
                      break;
948
949
                  default:
950
                      break;
951
952
              /* Check limits */
953
              canData = cans_checkLimits((float)tmpVal, sigIdx);
954
              /* Apply offset and factor */
955
              *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
              cans_CAN0_signals_tx[sigIdx].factor);
956
          }
957
958
          return 0;
959
      }
960
961
      uint32_t cans_gettemp(uint32_t sigIdx, void *value) {
962
          static DATA_BLOCK_CELLTEMPERATURE_s temp_tab;
963
          uint16 t modIdx = 0;
964
          uint32 t cellIdx = 0;
```

```
965
           uint32 t tmp = 0:
 966
           float tmpVal = 0;
 967
           float canData = 0;
 968
 969
           /* first signal to transmit cell temperatures */
 970
           if (sigIdx == CAN0_SIG_Mod0_temp_valid_0_2) {
 971
               DB ReadBlock (&temp tab, DATA BLOCK ID CELLTEMPERATURE);
 972
           }
 973
 974
           /* Determine module and cell number */
 975
           if (sigIdx - CAN0_SIG_Mod0_temp_valid_0_2 < CANS_MODULSIGNALS_TEMP) {</pre>
 976
               modIdx = 0:
 977
               cellIdx = sigIdx - CANO SIG Mod0 temp valid 0 2;
 978
           } else if (sigIdx - CANO_SIG_Mod1_temp_valid_0_2 < CANS_MODULSIGNALS_TEMP) {</pre>
 979
               modIdx = 1:
 980
               cellIdx = sigIdx - CANO SIG Mod1 temp valid 0 2;
           } else if (siqIdx - CANO_SIG_Mod2_temp_valid_0_2 < CANS_MODULSIGNALS_TEMP) {</pre>
 981
 982
               modIdx = 2;
 983
               cellIdx = sigIdx - CANO SIG Mod2 temp valid 0 2;
 984
           } else if (sigIdx - CANO SIG Mod3 temp valid 0 2 < CANS MODULSIGNALS TEMP) {
 985
               modIdx = 3;
 986
               cellIdx = siqIdx - CANO SIG Mod3 temp valid 0 2;
 987
           } else if (sigIdx - CANO SIG Mod4 temp valid 0 2 < CANS MODULSIGNALS TEMP) {
 988
               modIdx = 4;
 989
               cellIdx = sigIdx - CANO_SIG_Mod4_temp_valid_0_2;
 990
           } else if (sigIdx - CANO SIG Mod5 temp valid 0 2 < CANS MODULSIGNALS TEMP) {
 991
               modIdx = 5:
 992
               cellIdx = sigIdx - CANO_SIG_Mod5_temp_valid_0_2;
           } else if (siqIdx - CAN0_SIG_Mod6_temp_valid_0_2 < CANS_MODULSIGNALS_TEMP) {</pre>
 993
 994
               modIdx = 6:
 995
               cellIdx = sigIdx - CANO SIG Mod6 temp valid 0 2;
           } else if (siqIdx - CAN0_SIG_Mod7_temp_valid_0_2 < CANS_MODULSIGNALS_TEMP) {</pre>
 996
 997
               modIdx = 7;
 998
               cellIdx = sigIdx - CAN0_SIG_Mod7_temp_valid_0_2;
 999
           }
1000
1001
           if (value != NULL PTR) {
1002
               switch (siqIdx) {
                   case CAN0_SIG_Mod0_temp_valid_0_2:
1003
1004
                   case CANO SIG Mod1 temp valid 0 2:
1005
                   case CANO SIG Mod2 temp valid 0 2:
1006
                   case CAN0_SIG_Mod3_temp_valid_0_2:
1007
                   case CANO SIG Mod4 temp valid 0 2:
1008
                   case CANO SIG Mod5 temp valid 0 2:
                   case CANO SIG Mod6 temp valid 0 2:
1009
                   case CANO SIG Mod7 temp valid 0 2:
1010
1011
                        if (modIdx >= BS NR OF MODULES) {
1012
                            tmpVal = CAN DEFAULT VALID FLAG;
1013
1014
                            tmp = temp_tab.valid_temperature[modIdx];
1015
1016
                       tmpVal = 0x07 \& tmp;
```

```
1017
                       break;
1018
1019
                   case CANO SIG Mod0 temp valid 3 5:
1020
                   case CANO SIG Mod1 temp valid 3 5:
1021
                   case CANO SIG Mod2 temp valid 3 5:
1022
                   case CAN0_SIG_Mod3_temp_valid_3_5:
1023
                   case CAN0_SIG_Mod4_temp_valid_3_5:
1024
                   case CANO SIG Mod5 temp valid 3 5:
1025
                   case CANO SIG Mod6 temp valid 3 5:
1026
                   case CAN0_SIG_Mod7_temp_valid_3_5:
1027
                        if (modIdx >= BS_NR_OF_MODULES) {
1028
                            tmpVal = CAN DEFAULT VALID FLAG;
1029
                       } else {
                            tmp = temp_tab.valid_temperature[modIdx] >> 3;
1030
1031
                       }
1032
                       tmpVal = 0x07 \& tmp;
1033
                       break;
1034
1035
                   case CANO SIG Mod0 temp valid 6 8:
1036
                   case CANO SIG Mod1 temp valid 6 8:
1037
                   case CAN0_SIG_Mod2_temp_valid_6_8:
1038
                   case CAN0_SIG_Mod3_temp_valid_6_8:
1039
                   case CANO SIG Mod4 temp valid 6 8:
1040
                   case CAN0_SIG_Mod5_temp_valid_6_8:
1041
                   case CAN0_SIG_Mod6_temp_valid_6_8:
1042
                   case CANO SIG Mod7 temp valid 6 8:
1043
                       if (modIdx >= BS NR OF MODULES) {
1044
                            tmpVal = CAN_DEFAULT_VALID_FLAG;
1045
                       } else {
1046
                            tmp = temp tab.valid temperature[modIdx] >> 6;
1047
                       }
1048
                       tmpVal = 0x07 \& tmp;
1049
                       break;
1050
1051
                   case CAN0_SIG_Mod0_temp_valid_9_11:
1052
                   case CANO_SIG_Mod1_temp_valid_9_11:
1053
                   case CAN0_SIG_Mod2_temp_valid_9_11:
1054
                   case CANO SIG Mod3 temp valid 9 11:
1055
                   case CAN0_SIG_Mod4_temp_valid_9_11:
1056
                   case CANO SIG Mod5 temp valid 9 11:
1057
                   case CANO SIG Mod6 temp valid 9 11:
1058
                   case CAN0_SIG_Mod7_temp_valid_9_11:
1059
                        if (modIdx >= BS NR OF MODULES) {
1060
                            tmpVal = CAN DEFAULT VALID FLAG;
1061
                       } else {
1062
                            tmp = temp_tab.valid_temperature[modIdx] >> 9;
1063
                       }
1064
                       tmpVal = 0x07 \& tmp;
1065
                       break;
1066
1067
                   case CANO SIG Mod0 temp 0:
1068
                   case CANO SIG Mod0 temp 1:
```

```
1069
                   case CANO SIG Mod0 temp 2:
1070
                   case CANO SIG Mod1 temp 0:
1071
                   case CAN0_SIG_Mod1_temp_1:
1072
                   case CANO SIG Mod1 temp 2:
1073
                   case CANO SIG Mod2 temp 0:
1074
                   case CAN0_SIG_Mod2_temp_1:
1075
                   case CAN0_SIG_Mod2_temp_2:
1076
                   case CANO SIG Mod3 temp 0:
1077
                   case CANO SIG Mod3 temp 1:
1078
                   case CAN0_SIG_Mod3_temp_2:
1079
                   case CAN0_SIG_Mod4_temp_0:
1080
                   case CANO SIG Mod4 temp 1:
1081
                   case CANO SIG Mod4 temp 2:
1082
                   case CANO SIG Mod5 temp 0:
1083
                   case CANO SIG Mod5 temp 1:
1084
                   case CANO SIG Mod5 temp 2:
1085
                   case CANO SIG Mod6 temp 0:
1086
                   case CANO SIG Mod6 temp 1:
1087
                   case CANO SIG Mod6 temp 2:
1088
                   case CANO SIG Mod7 temp 0:
1089
                   case CAN0_SIG_Mod7_temp_1:
1090
                   case CAN0_SIG_Mod7_temp_2:
1091
                       cellIdx--; /* Because cell 0 - valid flag = 1, decrement by one to get the right index */
1092
                       if ((modIdx * BS_NR_OF_TEMP_SENSORS_PER_MODULE) + cellIdx >= BS_NR_OF_TEMP_SENSORS) {
1093
                            tmpVal = CAN_DEFAULT_TEMPERATURE;
1094
                       } else {
1095
                            tmpVal = temp tab.temperature[(modIdx * BS NR OF TEMP SENSORS PER MODULE) + cellIdx];
1096
1097
                       break;
1098
1099
                   case CANO SIG Mod0 temp 3:
1100
                   case CANO SIG Mod0 temp 4:
1101
                   case CANO SIG Mod0 temp 5:
1102
                   case CANO SIG Mod1 temp 3:
1103
                   case CANO_SIG_Mod1_temp_4:
1104
                   case CANO_SIG_Mod1_temp_5:
1105
                   case CAN0_SIG_Mod2_temp_3:
1106
                   case CANO SIG Mod2 temp 4:
1107
                   case CAN0_SIG_Mod2_temp_5:
1108
                   case CANO SIG Mod3 temp 3:
1109
                   case CANO SIG Mod3 temp 4:
1110
                   case CAN0_SIG_Mod3_temp_5:
1111
                   case CANO SIG Mod4 temp 3:
1112
                   case CANO SIG Mod4 temp 4:
1113
                   case CANO SIG Mod4 temp 5:
1114
                   case CANO SIG Mod5 temp 3:
1115
                   case CANO SIG Mod5 temp 4:
1116
                   case CANO SIG Mod5 temp 5:
                   case CANO_SIG_Mod6_temp_3:
1117
1118
                   case CANO_SIG_Mod6_temp_4:
1119
                   case CANO SIG Mod6 temp 5:
1120
                   case CANO SIG Mod7 temp 3:
```

```
1121
                   case CANO SIG Mod7 temp 4:
1122
                   case CANO SIG Mod7 temp 5:
1123
                       cellIdx--; /* Because cell 0 - valid flag = 1, decrement by one to get the right index */
1124
                       cellIdx--; /* Because of signal: CANO SIG Modx temp valid 3 5 */
1125
                       if ((modIdx * BS_NR_OF_TEMP_SENSORS_PER_MODULE) + cellIdx >= BS NR OF TEMP SENSORS) {
1126
                           tmpVal = CAN_DEFAULT_TEMPERATURE;
1127
                       } else {
1128
                           tmpVal = temp tab.temperature[(modIdx * BS NR OF TEMP SENSORS PER MODULE) + cellIdx];
1129
1130
                       break;
1131
1132
                   case CANO SIG Mod0 temp 6:
1133
                   case CANO SIG Mod0 temp 7:
1134
                   case CANO SIG Mod0 temp 8:
1135
                   case CANO SIG Mod1 temp 6:
1136
                   case CANO SIG Mod1 temp 7:
1137
                   case CANO SIG Mod1 temp 8:
1138
                   case CANO SIG Mod2 temp 6:
1139
                   case CANO SIG Mod2 temp 7:
1140
                   case CANO SIG Mod2 temp 8:
1141
                   case CANO_SIG_Mod3_temp_6:
1142
                   case CAN0_SIG_Mod3_temp_7:
1143
                   case CANO SIG Mod3 temp 8:
1144
                   case CAN0_SIG_Mod4_temp_6:
1145
                   case CAN0_SIG_Mod4_temp_7:
1146
                   case CANO SIG Mod4 temp 8:
1147
                   case CANO SIG Mod5 temp 6:
1148
                   case CAN0_SIG_Mod5_temp_7:
                   case CANO SIG Mod5 temp 8:
1149
1150
                   case CANO SIG Mod6 temp 6:
1151
                   case CANO SIG Mod6 temp 7:
                   case CANO SIG Mod6 temp 8:
1152
1153
                   case CANO SIG Mod7 temp 6:
1154
                   case CANO SIG Mod7 temp 7:
1155
                   case CAN0_SIG_Mod7_temp_8:
1156
                       cellIdx--; /* Because cell 0 - valid flag = 1, decrement by one to get the right index */
1157
                       cellIdx--; /* Because of signal: CANO SIG Modx temp valid 3 5 */
                       cellIdx--; /* Because of signal: CANO SIG Modx temp valid 6 8 */
1158
                       if ((modIdx * BS_NR_OF_TEMP_SENSORS_PER_MODULE) + cellIdx >= BS_NR OF TEMP SENSORS) {
1159
1160
                           tmpVal = CAN DEFAULT TEMPERATURE;
1161
                       } else {
1162
                           tmpVal = temp_tab.temperature[(modIdx * BS_NR_OF_TEMP_SENSORS_PER_MODULE) + cellIdx];
1163
1164
                       break;
1165
1166
                   case CANO SIG Mod0 temp 9:
1167
                   case CANO SIG Mod0 temp 10:
1168
                   case CANO SIG Mod0 temp 11:
1169
                   case CAN0_SIG_Mod1_temp_9:
1170
                   case CAN0_SIG_Mod1_temp_10:
1171
                   case CANO SIG Mod1 temp 11:
1172
                   case CANO SIG Mod2 temp 9:
```

```
1173
                   case CANO SIG Mod2 temp 10:
                   case CANO SIG Mod2 temp 11:
1174
1175
                   case CAN0_SIG_Mod3_temp_9:
1176
                   case CANO SIG Mod3 temp 10:
1177
                   case CANO SIG Mod3 temp 11:
1178
                   case CANO_SIG_Mod4_temp_9:
1179
                   case CANO SIG Mod4 temp 10:
1180
                   case CANO SIG Mod4 temp 11:
1181
                   case CANO SIG Mod5 temp 9:
1182
                   case CAN0_SIG_Mod5_temp_10:
1183
                   case CANO_SIG_Mod5_temp_11:
1184
                   case CANO SIG Mod6 temp 9:
1185
                   case CANO SIG Mod6 temp 10:
1186
                   case CANO SIG Mod6 temp 11:
1187
                   case CANO SIG Mod7 temp 9:
                   case CANO SIG Mod7 temp 10:
1188
1189
                   case CANO SIG Mod7 temp 11:
1190
                       cellIdx--; /* Because cell 0 - valid flag = 1, decrement by one to get the right index */
                       cellIdx--; /* Because of signal: CANO SIG Modx temp valid 3 5 */
1191
1192
                       cellIdx--; /* Because of signal: CANO SIG Modx temp valid 6 8 */
1193
                       cellIdx--; /* Because of signal: CANO_SIG_Modx_temp_valid_9_11 */
                       if ((modIdx * BS_NR_OF_TEMP_SENSORS_PER_MODULE) + cellIdx >= BS_NR_OF_TEMP_SENSORS) {
1194
1195
                           tmpVal = CAN DEFAULT TEMPERATURE;
1196
                       } else {
1197
                           tmpVal = temp_tab.temperature[(modIdx * BS_NR_OF_TEMP_SENSORS_PER_MODULE) + cellIdx];
1198
1199
                       break;
1200
                   default:
1201
                       break:
1202
1203
               }
               /* Check limits */
1204
1205
               canData = cans checkLimits((float)tmpVal, sigIdx);
1206
               /* Apply offset and factor */
1207
               *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
               cans_CAN0_signals_tx[sigIdx].factor);
1208
           }
1209
1210
           return 0;
1211
       }
1212
1213
                                                                          Not implemented.
1214
       uint32_t cans_gettempering(uint32_t sigIdx, void *value) {
1215
           if (value != NULL PTR) {
1216
               switch (siqIdx) {
1217
                   case CANO SIG CoolingNeeded:
1218
                       *(uint32 t *) value = 0;
1219
                       break;
1220
1221
                   case CANO_SIG_HeatingNeeded:
                       *(uint32 t *) value = 0;
1222
1223
                       break;
```

```
1224
1225
                   case CANO SIG TemperingDemand:
1226
                        *(uint32_t *)value = 0;
1227
                       break;
1228
1229
                   default:
1230
                       *(uint32_t *) value = 0;
1231
                       break;
1232
               }
1233
1234
           return 0;
1235
       }
1236
1237
1238
       uint32 t cans getcanerr(uint32 t sigIdx, void *value) {
1239
           static DATA BLOCK ERRORSTATE s canerr tab;
1240
           static DATA BLOCK MSL FLAG s canMSL tab;
1241
           static DATA BLOCK RSL FLAG s canRSL tab;
1242
           static DATA BLOCK MOL FLAG s canMOL tab;
1243
           static DATA BLOCK CONTFEEDBACK s cancontfeedback tab;
1244
           static DATA_BLOCK_ILCKFEEDBACK_s canilckfeedback_tab;
1245
           static DATA_BLOCK_BALANCING_CONTROL_s balancing_tab;
1246
           static DATA BLOCK SYSTEMSTATE s systemstate tab;
1247
1248
           static uint8_t tmp = 0;
1249
1250
           if (value != NULL PTR) {
               switch (sigIdx) {
1251
1252
                   case CANO SIG GSO general error:
1253
1254
                       /* First signal in CAN MSG GeneralState messages -> get database entry */
1255
                       DB ReadBlock (&canerr tab, DATA BLOCK ID ERRORSTATE);
1256
                       DB ReadBlock (&canMSL tab, DATA BLOCK ID MSL);
1257
                       DB ReadBlock (&canRSL tab, DATA BLOCK ID RSL);
1258
                       DB_ReadBlock(&canMOL_tab, DATA_BLOCK_ID_MOL);
1259
                       tmp = 0;
1260
                       /* Check maximum safety limit flags */
1261
                       if (canMSL tab.over current charge cell
1262
                                                                   == 1 | |
1263
                            canMSL tab.over current discharge cell == 1 ||
1264
                            canMSL tab.over current charge pl0
                                                                   == 1 ||
1265
                            canMSL tab.over current discharge pl0 == 1 ||
1266
                            canMSL tab.over current charge pl1
                                                                    == 1 | |
1267
                            canMSL tab.over current discharge pl1 == 1 ||
1268
                           canMSL tab.over voltage
                                                                   == 1 | |
1269
                            canMSL tab.under voltage
                                                                   == 1 | |
1270
                            canMSL tab.over temperature charge
                                                                   == 1 ||
1271
                            canMSL tab.over temperature discharge == 1 ||
1272
                            canMSL_tab.under_temperature_charge
                                                                    == 1 | |
1273
                            canMSL_tab.under_temperature_discharge == 1 ||
1274
                       /* Check system error flags */
1275
                            canerr tab.deepDischargeDetected
                                                                 == 1 | |
```

```
1276
                            canerr tab.main plus
                                                                   == 1 | |
1277
                            canerr tab.main minus
                                                                   == 1 | |
                                                                   == 1 ||
1278
                            canerr tab.precharge
1279
                            canerr tab.charge main plus
                                                                   == 1 | |
1280
                            canerr tab.charge main minus
                                                                   == 1 | |
1281
                            canerr_tab.charge_precharge
                                                                   == 1 | |
1282
                            canerr tab.fuse state normal
                                                                   == 1 | |
1283
                            canerr tab.fuse state charge
                                                                   == 1 | |
                                                                   == 1 ||
1284
                            canerr tab.interlock
1285
                                                                   == 1 | |
                            canerr_tab.crc_error
1286
                            canerr_tab.mux_error
                                                                   == 1 | |
                                                                   == 1 ||
                            canerr tab.spi error
1287
                                                                   == 1 ||
                            canerr tab.currentsensorresponding
1288
1289
                            canerr tab.open wire
                                                                   == 1 | |
                    #if BMS OPEN CONTACTORS ON INSULATION ERROR == TRUE
1290
1291
                            canerr tab.insulation error
                                                                   == 1 | |
                    #endif /* BMS OPEN CONTACTORS ON INSULATION ERROR */
1292
1293
                            canerr tab.can timing cc
                                                                   == 1 | |
1294
                            canerr tab.can timing
                                                                  == 1) {
1295
                            /* set flag if error detected */
1296
                            tmp = 0x01 << 0;
1297
                        }
1298
                        /* Check recommended safety limit flags */
1299
                        if (canRSL tab.over current charge cell
                                                                     == 1 | |
1300
                            canRSL tab.over current discharge cell == 1 ||
                            canRSL tab.over current charge pl0
                                                                     == 1 | |
1301
1302
                            canRSL tab.over current discharge pl0 == 1 ||
1303
                            canRSL tab.over current charge pl1
                                                                     == 1 | |
                            canRSL tab.over current discharge pl1
1304
                                                                    == 1 | |
1305
                            canRSL tab.over voltage
                                                                     == 1 | |
1306
                            canRSL tab.under voltage
                                                                     == 1 | |
1307
                            canRSL tab.over temperature charge
                                                                     == 1 | |
1308
                            canRSL tab.over temperature discharge == 1 ||
1309
                            canRSL tab.under temperature charge
                                                                     == 1 | |
1310
                            canRSL_tab.under_temperature_discharge == 1) {
1311
                            /* set flag if error detected */
1312
                            tmp |= 0x01 << 1;
1313
                        /* Check maximum operating limit flags */
1314
1315
                        if (canMOL tab.over current charge cell
                                                                     == 1 | |
1316
                            canMOL tab.over current discharge cell == 1 ||
                            canMOL tab.over current charge pl0
1317
                                                                     == 1 | |
                            canMOL tab.over current discharge pl0
1318
                                                                    == 1 | |
1319
                            canMOL tab.over current charge pl1
                                                                     == 1 ||
1320
                            canMOL tab.over current discharge pl1 == 1 ||
                            canMOL_tab.over_voltage
1321
                                                                     == 1 | |
                                                                     == 1 ||
                            canMOL tab.under voltage
1322
1323
                            canMOL tab.over temperature charge
                                                                     == 1 ||
1324
                            canMOL_tab.over_temperature_discharge == 1 ||
1325
                            canMOL_tab.under_temperature_charge
                                                                     == 1 | |
1326
                            canMOL tab.under temperature discharge == 1) {
                            /* set flag if error detected */
1327
```

```
1328
                            tmp l = 0 \times 01 << 2;
1329
                        1
1330
                        *(uint32 t *) value = tmp;
1331
                        break;
1332
1333
                    case CANO_SIG_GSO_current_state:
1334
                        DB_ReadBlock(&systemstate_tab, DATA_BLOCK_ID_SYSTEMSTATE);
1335
                        *(uint32 t *) value = systemstate tab.bms state;
1336
                        break:
1337
                    case CAN0_SIG_GS0_error_overtemp_charge:
1338
                        tmp = 0;
1339
                        tmp |= canMOL tab.over temperature charge << 2;
                        tmp |= canRSL tab.over temperature charge << 1;</pre>
1340
1341
                        tmp |= canMSL tab.over temperature charge;
1342
                        *(uint32 t *) value = tmp;
1343
                       break:
1344
                    case CANO SIG GSO error undertemp charge:
1345
                        tmp = 0;
1346
                        tmp |= canMOL tab.under temperature charge << 2;
1347
                        tmp |= canRSL tab.under temperature charge << 1;</pre>
1348
                        tmp |= canMSL_tab.under_temperature_charge;
1349
                        *(uint32 t *) value = tmp;
1350
                       break:
1351
                    case CAN0_SIG_GS0_error_overtemp_discharge:
1352
                        t.mp = 0:
1353
                        tmp |= canMOL tab.over temperature discharge << 2;
1354
                        tmp |= canRSL tab.over temperature discharge << 1;
1355
                        tmp |= canMSL tab.over temperature discharge;
1356
                        *(uint32 t *) value = tmp;
1357
                       break:
1358
                    case CANO SIG GSO error undertemp discharge:
1359
                        tmp = 0;
1360
                        tmp |= canMOL tab.under temperature discharge << 2;</pre>
1361
                        tmp |= canRSL tab.under temperature discharge << 1;</pre>
1362
                        tmp |= canMSL_tab.under_temperature_discharge;
1363
                        *(uint32 t *) value = tmp;
1364
                       break:
1365
                    case CANO SIG GSO error overcurrent charge:
1366
                        t.mp = 0:
1367
                        tmp |= canMOL tab.over current charge cell << 2;
1368
                        tmp |= canMOL tab.over current charge pl0 << 2;
1369
                        tmp |= canMOL tab.over current charge pl1 << 2;
1370
                        tmp |= canRSL tab.over current charge cell << 1;
1371
                        tmp |= canRSL tab.over current charge pl0 << 1;</pre>
1372
                        tmp |= canRSL tab.over current charge pl1 << 1;</pre>
1373
                        tmp |= canMSL tab.over current charge cell;
1374
                        tmp |= canMSL tab.over current charge pl0;
1375
                        tmp |= canMSL tab.over current charge pl1;
1376
                        *(uint32_t *) value = tmp;
1377
                       break;
1378
                    case CANO SIG GSO error overcurrent discharge:
1379
                        tmp = 0;
```

```
1380
                        tmp |= canMOL tab.over current discharge cell << 2;
                       tmp |= canMOL tab.over current discharge pl0 << 2;
1381
1382
                       tmp |= canMOL_tab.over_current_discharge_pl1 << 2;</pre>
1383
                       tmp |= canRSL tab.over current discharge cell << 1;
1384
                       tmp |= canRSL tab.over current discharge pl0 << 1;
1385
                       tmp |= canRSL_tab.over_current_discharge_pl1 << 1;</pre>
1386
                       tmp |= canMSL_tab.over_current_discharge_cell;
1387
                       tmp |= canMSL tab.over current discharge pl0;
1388
                       tmp |= canMSL tab.over current discharge pl1;
1389
                       *(uint32_t *) value = tmp;
1390
                       break;
                   case CANO_SIG_GS1_error_overvoltage:
1391
1392
                       tmp = 0:
1393
                       tmp |= canMOL tab.over voltage << 2;
1394
                       tmp |= canRSL tab.over voltage << 1;
                       tmp |= canMSL tab.over voltage;
1395
1396
                       *(uint32_t *) value = tmp;
1397
                       break;
                   case CANO SIG GS1 error undervoltage:
1398
1399
                       tmp = 0;
1400
                       tmp |= canMOL_tab.under_voltage << 2;</pre>
1401
                       tmp |= canRSL tab.under voltage << 1;
1402
                       tmp |= canMSL tab.under voltage;
1403
                       *(uint32_t *) value = tmp;
1404
                       break;
1405
                   case CANO SIG GS1 error deep discharge:
                        *(uint32 t *) value = canerr tab.deepDischargeDetected;
1406
                       break;
1407
1408
                   case CANO SIG GS1 error temperature MCUO:
1409
                        *(uint32 t *) value = canerr tab.mcuDieTemperature;
1410
                       break;
1411
                   case CANO SIG GS1 error contactor:
1412
                        *(uint32 t *) value = canerr tab.main plus | canerr tab.main minus | canerr tab.precharge |
                       canerr tab.charge main plus | canerr tab.charge main minus | canerr tab.charge precharge;
1413
                       break;
1414
                   case CANO_SIG_GS1_error_selftest:
1415
                        *(uint32_t *)value = 0;
1416
                       break:
1417
                   case CANO_SIG_GS1_error_cantiming:
1418
                        *(uint32 t *) value = canerr tab.can timing;
1419
                       break:
1420
                   case CANO_SIG_GS1_current_sensor:
1421
                        *(uint32_t *)value = canerr_tab.currentsensorresponding | canerr_tab.can_timing_cc;
1422
                       break;
                   case CANO SIG GS1 balancing active:
1423
1424
1425
                        /* only signal to use the balancing database entry */
1426
                       DB ReadBlock (&balancing tab, DATA BLOCK ID BALANCING CONTROL VALUES);
1427
                        *(uint32_t *) value = balancing_tab.enable_balancing;
1428
                       break;
1429
1430
                   case CANO SIG GS2 state cont interlock:
```

```
1431
                        DB ReadBlock (&cancontfeedback tab, DATA BLOCK ID CONTFEEDBACK);
1432
                        DB ReadBlock (&canilckfeedback tab, DATA BLOCK ID ILCKFEEDBACK):
1433
                        cancontfeedback tab.contactor feedback &= ~(1 << 9);
1434
                        cancontfeedback tab.contactor feedback |= canilckfeedback tab.interlock feedback << 9;</pre>
1435
                        *(uint32 t *) value = cancontfeedback tab.contactor feedback;
1436
                       break;
1437
1438
                   case CANO SIG GS2 error insulation:
                        *(uint32 t *) value = canerr tab.insulation error;
1439
                        break;
1440
1441
1442
                   case CANO SIG GS2 fuse state:
1443
                        tmp = 0:
                        if (canerr tab.fuse state normal != 0) {
1444
       #if BS CHECK FUSE PLACED IN NORMAL PATH == TRUE
1445
1446
                            tmp l = 0 \times 01:
1447
       #else /* BS CHECK FUSE PLACED IN NORMAL PATH == FALSE */
1448
                            tmp l = 0 \times 02;
1449
       #endif
1450
                        }
1451
                        if (canerr_tab.fuse_state_charge != 0) {
1452
       #if BS CHECK FUSE PLACED IN CHARGE PATH == TRUE
1453
                            tmp = 0x04;
1454
       #else /* BS_CHECK_FUSE_PLACED_IN_CHARGE_PATH == FALSE */
1455
                            tmp | = 0x08;
       #endif
1456
1457
1458
                        *(uint32_t *) value = tmp;
1459
                       break;
1460
1461
                   case CANO SIG GS2 lowCoinCellVolt:
1462
                        *(uint32 t *) value = canerr tab.coinCellVoltage;
1463
                       break;
1464
1465
                   case CANO_SIG_GS2_error_openWire:
1466
                        *(uint32_t *)value = canerr_tab.open_wire;
1467
                        break:
1468
                   case CANO_SIG_GS2_daisyChain:
1469
1470
                        tmp = 0;
1471
                        tmp |= canerr tab.spi error;
1472
                        tmp |= canerr_tab.crc_error << 1;</pre>
1473
                        tmp |= canerr tab.mux error << 2;
                        tmp |= canerr tab.ltc config error << 3;</pre>
1474
                        *(uint32 t *) value = tmp;
1475
1476
                       break;
1477
1478
                   case CANO SIG GS2 plausibilityCheck:
1479
                        *(uint32_t *) value = canerr_tab.plausibilityCheck;
1480
                       break;
1481
1482
                   default:
```

```
1483
                       *(uint32 t *) value = 0;
1484
                       break:
1485
               }
1486
           }
1487
           return 0;
1488
      }
1489
1490
1491
       uint32 t cans getsoc(uint32 t sigIdx, void *value) {
1492
           static DATA_BLOCK_SOX_s sox_tab;
1493
           DB_ReadBlock(&sox_tab, DATA_BLOCK_ID_SOX);
1494
           if (value != NULL PTR) {
1495
               switch (siqIdx) {
1496
                   case CANO SIG SOC mean:
                       /* CAN signal resolution 0.01%, --> factor 100 */
1497
1498
                       *(uint32 t *) value = (uint32 t) (sox tab.soc mean * cans CANO signals tx[sigIdx].factor);
1499
                       break;
                   case CANO SIG SOC min:
1500
1501
                       /* CAN signal resolution 0.01%, --> factor 100 */
1502
                       *(uint32 t *)value = (uint32 t) (sox_tab.soc_min * cans_CAN0_signals_tx[sigIdx].factor);
1503
                       break;
1504
                   case CANO SIG SOC max:
1505
                       /* CAN signal resolution 0.01%, --> factor 100 */
                       *(uint32 t *) value = (uint32_t) (sox_tab.soc_max * cans_CANO_signals_tx[sigIdx].factor);
1506
1507
                       break:
                   default:
1508
1509
                       *(uint32 t *) value = 50.0;
1510
                       break;
1511
               }
1512
           }
1513
           return 0;
1514
       }
1515
1516
1517
       static uint32_t cans_getRecommendedOperatingCurrent(uint32_t sigIdx, void *value) {
           static DATA_BLOCK_SOF_s sof tab;
1518
1519
           float canData = 0;
1520
1521
           if (value != NULL PTR) {
1522
               /* values transmitted in resolution of 10mA (16bit means 0A-655.35A) */
1523
               switch (sigIdx) {
1524
                   case CANO_SIG_RecChargeCurrent:
1525
                       /* first signal */
1526
                       DB ReadBlock (&sof tab, DATA BLOCK ID SOF);
1527
1528
                       /* Check limits */
                       canData = cans_checkLimits((float)sof_tab.recommended_continuous_charge, sigIdx);
1529
1530
                       /* Apply offset and factor */
1531
                       *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                       cans_CAN0_signals_tx[sigIdx].factor);
1532
                       break;
1533
```

```
1534
                   case CANO SIG RecChargeCurrent Peak:
1535
                       /* Check limits */
1536
                       canData = cans_checkLimits((float)sof_tab.recommended_peak_charge, sigIdx);
1537
                       /* Apply offset and factor */
1538
                       *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
                       cans_CAN0_signals_tx[sigIdx].factor);
1539
                       break;
1540
1541
                   case CANO SIG RecDischargeCurrent:
                       /* Check limits */
1542
1543
                       canData = cans_checkLimits((float)sof_tab.recommended_continuous_discharge, sigIdx);
                       /* Apply offset and factor */
1544
                       *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
1545
                       cans_CAN0_signals_tx[sigIdx].factor);
1546
                       break:
1547
1548
                   case CANO SIG RecDischargeCurrent Peak:
1549
                       /* Check limits */
                       canData = cans checkLimits((float)sof tab.recommended peak discharge, sigIdx);
1550
1551
                       /* Apply offset and factor */
1552
                       *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                       cans_CAN0_signals_tx[sigIdx].factor);
1553
                       break;
1554
1555
                   default:
1556
                       break;
1557
               }
1558
           }
1559
           return 0;
1560
       }
1561
1562
1563
       static uint32 t cans getMaxAllowedPower(uint32 t sigIdx, void *value) {
1564
           if (value != NULL PTR) {
1565
               switch (sigIdx) {
1566
                   default:
1567
                       *(uint32_t *)value = 0;
1568
                       break;
1569
               }
1570
           }
1571
           return 0;
1572
       }
1573
1574
1575
       static uint32 t cans getminmaxvolt (uint32 t sigIdx, void *value) {
1576
           static DATA BLOCK MINMAX s minmax volt tab;
           float canData = 0;
1577
1578
1579
           if (value != NULL_PTR) {
1580
               switch (sigIdx) {
1581
                   case CANO SIG Cellvolt mean:
                       /* First signal that is called */
1582
```

```
1583
                       DB ReadBlock (&minmax volt tab, DATA BLOCK ID MINMAX);
1584
1585
                       /* Check limits */
1586
                       canData = cans checkLimits((float)minmax volt tab.voltage mean, sigIdx);
1587
                       /* Apply offset and factor */
1588
                       *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                       cans_CAN0_signals_tx[sigIdx].factor);
                       break;
1589
1590
1591
                   case CANO SIG Cellvolt min:
1592
                       /* Check limits */
1593
                       canData = cans checkLimits((float)minmax volt tab.voltage min, sigIdx);
                       /* Apply offset and factor */
1594
1595
                       *(uint32 t *) value = (uint32 t)((canData + cans CANO signals tx[sigIdx].offset) *
                       cans CANO signals tx[sigIdx].factor);
1596
                       break:
1597
1598
                   case CANO SIG Cellvolt max:
1599
                       /* Check limits */
1600
                       canData = cans checkLimits((float)minmax volt tab.voltage max, sigIdx);
1601
                       /* Apply offset and factor */
                       *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
1602
                       cans CANO signals tx[sigIdx].factor);
1603
                       break;
1604
1605
                   case CANO SIG ModNumber volt min:
                       /* Check limits */
1606
1607
                       canData = cans_checkLimits((float)minmax_volt_tab.voltage_module_number_min, sigIdx);
                       /* Apply offset and factor */
1608
                       *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
1609
                       cans CANO signals tx[sigIdx].factor);
1610
                       break;
1611
1612
                   case CANO SIG ModNumber volt max:
1613
                       /* Check limits */
1614
                       canData = cans_checkLimits((float)minmax_volt_tab.voltage_module_number_max, sigIdx);
                       /* Apply offset and factor */
1615
                       *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
1616
                       cans CANO signals tx[sigIdx].factor);
1617
                       break;
1618
1619
                   default:
                       *(uint32 t *) value = 0;
1620
1621
                       break;
1622
               }
1623
           }
1624
           return 0;
1625
       }
1626
1627
       uint32_t cans_getminmaxtemp(uint32_t sigIdx, void *value) {
1628
           static DATA BLOCK MINMAX s minmax temp tab;
           float canData = 0;
1629
```

```
1630
1631
           if (value != NULL PTR) {
1632
               switch (sigIdx) {
1633
               case CANO SIG Celltemp mean:
1634
                   /* First signal that is called */
1635
                   DB_ReadBlock(&minmax_temp_tab, DATA_BLOCK_ID_MINMAX);
1636
                   /* Check limits */
1637
                   canData = cans checkLimits((float)minmax temp tab.temperature mean, sigIdx);
1638
1639
                   /* Apply offset and factor */
1640
                   *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                   cans CANO signals tx[sigIdx].factor);
1641
                   break;
1642
1643
               case CANO SIG Celltemp min:
1644
                   /* Check limits */
1645
                   canData = cans checkLimits((float)minmax temp tab.temperature min, sigIdx);
                   /* Apply offset and factor */
1646
1647
                   *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
                   cans CANO signals tx[sigIdx].factor);
1648
                   break;
1649
1650
               case CANO SIG Celltemp max:
1651
                   /* Check limits */
1652
                   canData = cans_checkLimits((float)minmax_temp_tab.temperature_max, sigIdx);
                   /* Apply offset and factor */
1653
1654
                   *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
                   cans_CAN0_signals_tx[sigIdx].factor);
1655
                   break;
1656
1657
               case CANO SIG ModNumber temp min:
1658
                   /* Check limits */
1659
                   canData = cans checkLimits((float)minmax temp tab.temperature module number min, sigIdx);
1660
                   /* Apply offset and factor */
1661
                   *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                   cans CANO_signals_tx[sigIdx].factor);
1662
                   break;
1663
1664
               case CANO SIG ModNumber temp max:
1665
                   /* Check limits */
1666
                   canData = cans checkLimits((float)minmax temp tab.temperature module number max, sigIdx);
1667
                   /* Apply offset and factor */
1668
                   *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                   cans CANO signals tx[sigIdx].factor);
1669
                   break;
1670
1671
               default:
1672
                   *(uint32 t *) value = 0;
1673
                   break;
1674
               }
1675
1676
           return 0;
```

```
1677
             }
1678
1679
1680
              #ifdef CURRENT SENSOR ISABELLENHUETTE TRIGGERED
1681
              uint32 t cans gettriggercurrent(uint32 t sigIdx, void *value) {
                       *(uint32_t *) value = 0 \times 0.00 = 0 \times 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 = 0.00 
1682
1683
                      return 0;
1684
              #endif /* CURRENT SENSOR ISABELLENHUETTE TRIGGERED */
1685
1686
1687
              static uint32 t cans getpower(uint32 t sigIdx, void *value) {
1688
1689
                       uint32 t retVal = 0:
1690
                       float canData = 0;
1691
                       static DATA BLOCK MOVING AVERAGE s powMovMean tab:
1692
1693
                      if (value != NULL PTR) {
1694
                             switch (siqIdx) {
1695
                                     case CANO SIG MovAverage Power 1s:
1696
                                             /* first signal to call function */
1697
                                             DB_ReadBlock(&powMovMean_tab, DATA_BLOCK_ID_MOV_AVERAGE);
1698
                                             /* Check limits */
1699
                                             canData = cans checkLimits((float)powMovMean tab.movAverage power 1s, sigIdx);
1700
                                             /* Apply offset and factor */
1701
                                              *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                                             cans CANO signals tx[sigIdx].factor);
1702
                                             break:
1703
1704
                                     case CANO SIG MovAverage Power 5s:
1705
                                             /* Check limits */
1706
                                             canData = cans checkLimits((float)powMovMean tab.movAverage power 5s, sigIdx);
                                              /* Apply offset and factor */
1707
1708
                                              *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
                                              cans CANO signals tx[sigIdx].factor);
1709
                                             break;
1710
1711
                                     case CANO SIG MovAverage Power 10s:
                                             /* Check limits */
1712
                                             canData = cans_checkLimits((float)powMovMean_tab.movAverage_power_10s, sigIdx);
1713
1714
                                              /* Apply offset and factor */
1715
                                              *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
                                             cans CANO signals tx[sigIdx].factor);
1716
                                             break;
1717
1718
                                     case CANO SIG MovAverage Power 30s:
1719
                                             /* Check limits */
1720
                                             canData = cans checkLimits((float)powMovMean tab.movAverage power 30s, sigIdx);
1721
                                             /* Apply offset and factor */
1722
                                              *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                                             cans_CAN0_signals_tx[sigIdx].factor);
                                             break;
1723
1724
```

```
1725
                  case CANO SIG MovAverage Power 60s:
                      /* Check limits */
1726
1727
                      canData = cans checkLimits((float)powMovMean tab.movAverage power 60s, sigIdx);
1728
                      /* Apply offset and factor */
1729
                      *(uint32 t *)value = (uint32 t)((canData + cans CANO signals tx[sigIdx].offset) *
                      cans_CAN0_signals_tx[sigIdx].factor);
1730
                      break;
1731
1732
                  case CANO SIG MovAverage Power config:
                      /* Check limits */
1733
1734
                      canData = cans_checkLimits((float)powMovMean_tab.movAverage_power_config, sigIdx);
                      /* Apply offset and factor */
1735
                      *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
1736
                      cans CANO signals tx[sigIdx].factor);
                      break:
1737
1738
1739
                  default:
                      *(uint32 t *) value = 0;
1740
1741
                      break;
1742
              }
1743
1744
           return retVal;
1745
      }
1746
1747
       static uint32_t cans_getcurr(uint32_t sigIdx, void *value) {
1748
           uint32 t retVal = 0;
1749
           float canData = 0:
1750
           static DATA_BLOCK_MOVING_AVERAGE_s curMovMean_tab;
1751
1752
           if (value != NULL PTR) {
1753
              switch (siqIdx) {
1754
                  case CANO SIG MovAverage Current 1s:
1755
                      /* first signal to call function */
1756
                      DB ReadBlock (&curMovMean tab, DATA BLOCK ID MOV AVERAGE);
1757
                      /* Check limits */
                      canData = cans checkLimits((float)curMovMean_tab.movAverage_current_1s, sigIdx);
1758
                      /* Apply offset and factor */
1759
                      *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
1760
                      cans CANO signals tx[sigIdx].factor);
1761
                      break:
1762
1763
                  case CANO_SIG_MovAverage_Current 5s:
1764
                      /* Check limits */
1765
                      canData = cans checkLimits((float)curMovMean tab.movAverage current 5s, sigIdx);
                      /* Apply offset and factor */
1766
1767
                      *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
                      cans CANO signals tx[sigIdx].factor);
1768
                      break;
1769
1770
                  case CANO_SIG_MovAverage_Current_10s:
                      /* Check limits */
1771
1772
                      canData = cans checkLimits((float)curMovMean tab.movAverage current 10s, sigIdx);
```

```
/* Apply offset and factor */
1773
1774
                      *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                      cans CANO signals tx[sigIdx].factor);
1775
                      break;
1776
1777
                  case CAN0_SIG_MovAverage_Current_30s:
1778
                      /* Check limits */
1779
                      canData = cans checkLimits((float)curMovMean tab.movAverage current 30s, sigIdx);
                      /* Apply offset and factor */
1780
1781
                      *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                      cans_CAN0_signals_tx[sigIdx].factor);
                      break:
1782
1783
1784
                  case CANO SIG MovAverage Current 60s:
                      /* Check limits */
1785
                      canData = cans checkLimits((float)curMovMean tab.movAverage current 60s, sigIdx);
1786
1787
                      /* Apply offset and factor */
                      *(uint32 t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
1788
                      cans CANO signals tx[sigIdx].factor);
1789
                      break;
1790
1791
                  case CANO SIG MovAverage Current config:
1792
                      /* Check limits */
1793
                      canData = cans_checkLimits((float)curMovMean_tab.movAverage_current_config, sigIdx);
1794
                      /* Apply offset and factor */
                      *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
1795
                      cans CANO signals tx[sigIdx].factor);
1796
                      break;
1797
                  default:
1798
1799
                          *(uint32 t *) value = 0;
1800
                          break;
1801
              }
1802
1803
           return retVal;
1804
       }
1805
1806
1807
       static uint32_t cans_getPackVoltage(uint32_t sigIdx, void *value) {
1808
           uint32 t retVal = 0;
1809
           float canData = 0:
1810
           static DATA_BLOCK_CURRENT_SENSOR_s packVolt_tab;
1811
1812
           if (value != NULL PTR) {
1813
              switch (siqIdx) {
1814
                  case CANO SIG PackVolt Battery:
1815
                      /* first signal to call function */
1816
                      DB ReadBlock (&packVolt tab, DATA BLOCK ID CURRENT SENSOR);
1817
                      /* Check limits */
1818
                      canData = cans_checkLimits((float)packVolt_tab.voltage[0], sigIdx);
                      /* Apply offset and factor */
1819
1820
                      *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
```

```
cans CANO signals tx[sigIdx].factor);
1821
                      break:
1822
1823
                  case CANO SIG PackVolt PowerNet:
1824
                      /* first signal to call function */
1825
                      DB_ReadBlock(&packVolt_tab, DATA_BLOCK_ID_CURRENT_SENSOR);
1826
                      /* Check limits */
1827
                      canData = cans checkLimits((float)packVolt tab.voltage[2], sigIdx);
                      /* Apply offset and factor */
1828
1829
                      *(uint32_t *)value = (uint32_t)((canData + cans_CANO_signals_tx[sigIdx].offset) *
                      cans_CAN0_signals_tx[sigIdx].factor);
1830
                      break:
1831
1832
                  default:
1833
                      break:
1834
              }
1835
1836
           return retVal;
1837
       }
1838
1839
1840
       static uint32 t cans setcurr(uint32 t sigIdx, void *value) {
1841
           int32 t currentValue;
1842
           int32 t temperatureValue;
1843
           int32 t powerValue;
1844
           int32 t currentcounterValue;
1845
           int32 t energycounterValue:
1846
           int32 t voltageValue[3];
1847
           uint32 t idx = 0;
           uint8 t dummy = 0;
1848
1849
1850
           if (value != NULL PTR) {
1851
               switch (sigIdx) {
1852
                   case CANO SIG_IVT_Current_Status:
1853
                   case CANO_SIG_IVT_Voltage_1_Status:
1854
                   case CANO_SIG_IVT_Voltage_2_Status:
1855
                   case CANO_SIG_IVT_Voltage_3_Status:
                   case CANO SIG IVT Temperature Status:
1856
1857
                   case CANO_SIG_IVT_Power_Status:
1858
                   case CANO SIG IVT CC Status:
1859
                   case CANO SIG IVT EC Status:
1860
                       dummy = *(uint32_t *) value & 0x000000FF;
                       dummy &= 0xF0; /* only high nibble contains diag info */
1861
                       if ((dummy & 0 \times 10) == TRUE) {
1862
                            /* Overcurrent detected. This feature is currently not supported. */
1863
1864
                       if ((dummy & 0x20) == TRUE) {
1865
1866
                           if (sigIdx == CANO SIG IVT Current Status) {
1867
                               cans_current_tab.state_current = 1;
1868
                           } else if (sigIdx == CAN0_SIG_IVT_Voltage_1_Status || sigIdx == CAN0_SIG_IVT_Voltage_2_Status ||
                           sigIdx == CAN0_SIG_IVT_Voltage_3_Status) {
1869
                                cans current tab.state voltage = 1;
```

```
1870
                           } else if (sigIdx == CANO SIG IVT Temperature Status) {
                               cans current tab.state temperature = 1;
1871
1872
                           } else if (sigIdx == CANO_SIG_IVT_Power_Status) {
1873
                               cans current tab.state power = 1;
1874
                           } else if (sigIdx == CANO SIG IVT CC Status) {
1875
                               cans_current_tab.state_cc = 1;
1876
                           } else {
1877
                               cans current tab.state ec = 1;
1878
                           }
1879
                       } else {
1880
                           cans_current_tab.state_current = 0;
1881
                           cans current tab.state voltage = 0;
1882
                           cans current tab.state temperature = 0;
1883
                           cans current tab.state power = 0;
1884
                           cans_current_tab.state_cc = 0;
1885
                           cans current tab.state ec = 0;
1886
1887
                       if ((dummy & 0 \times 40) == TRUE || (dummy & 0 \times 80) == TRUE) {
                           cans current tab.state current = 1;
1888
1889
                           cans current tab.state voltage = 1;
1890
                           cans_current_tab.state_temperature = 1;
1891
                           cans_current_tab.state_power = 1;
1892
                           cans current tab.state cc = 1;
1893
                           cans_current_tab.state_ec = 1;
1894
                       }
1895
1896
                       break;
1897
1898
                       case CANO SIG IVT Current Measurement:
                       /* case CAN1 SIG ISENSO I Measurement: uncommented because identical position in CAN0 and CAN1 rx
1899
                       signal struct */
1900
                           currentValue = *(int32 t*)value;
1901
                           cans current tab.current = (currentValue);
1902
                           cans current tab.newCurrent++;
1903
                           cans_current_tab.previous_timestamp_cur = cans_current_tab.timestamp_cur;
1904
                           cans_current_tab.timestamp_cur = OS_getOSSysTick();
                           DB WriteBlock (&cans current tab, DATA BLOCK ID CURRENT SENSOR);
1905
                           break:
1906
                       case CANO SIG IVT Voltage 1 Measurement:
1907
1908
                       /* case CAN1 SIG ISENS1 U1 Measurement: uncommented because identical position in CAN0 and CAN1 rx
                       signal struct */
1909
                           idx = 0;
1910
                           voltageValue[idx] = *(int32 t*)value;
1911
                           cans current tab.voltage[idx] = (float) (voltageValue[idx])*cans CANO signals rx[sigIdx].factor;
1912
                           DB WriteBlock (&cans current tab, DATA BLOCK ID CURRENT SENSOR);
1913
                           break;
1914
                       case CANO SIG IVT Voltage 2 Measurement:
1915
                       /* case CAN1 SIG ISENS2 U2 Measurement: uncommented because identical position in CAN0 and CAN1 rx
                       signal struct */
1916
                           idx = 1;
                           voltageValue[idx] = *(int32 t*)value;
1917
                           cans current tab.voltage[idx] = (float)(voltageValue[idx])*cans CANO signals rx[sigIdx].factor;
1918
```

```
1919
                           DB WriteBlock (&cans current tab, DATA BLOCK ID CURRENT SENSOR);
1920
                           break:
1921
                       case CANO_SIG_IVT_Voltage_3_Measurement:
1922
                       /* case CAN1 SIG ISENS3 U3 Measurement: uncommented because identical position in CAN0 and CAN1 rx
                       signal struct */
1923
                           idx = 2;
1924
                           voltageValue[idx] = *(int32 t*)value;
                           cans current tab.voltage[idx]=(float)(voltageValue[idx])*cans CANO signals rx[sigIdx].factor;
1925
                           DB WriteBlock (&cans current tab, DATA BLOCK ID CURRENT SENSOR);
1926
1927
                           break;
1928
                       case CANO_SIG_IVT_Temperature_Measurement:
                       /* case CAN1 SIG ISENS4 T Measurement: uncommented because identical position in CAN0 and CAN1 rx
1929
                       signal struct */
1930
                           temperatureValue = *(int32 t*)value;
                           cans current tab.temperature = (float)(temperatureValue)*cans CANO signals rx[sigIdx].factor;
1931
                           DB WriteBlock (&cans current tab, DATA BLOCK ID CURRENT SENSOR);
1932
1933
                           break;
1934
                       case CANO SIG IVT Power Measurement:
1935
                       /* case CAN1 SIG ISENS5 P Measurement: uncommented because identical position in CAN0 and CAN1 rx
                       signal struct */
1936
                           powerValue = *(int32_t*)value;
1937
                           cans_current_tab.power = (float) (powerValue);
1938
                           cans current tab.newPower++;
1939
                           DB_WriteBlock(&cans_current_tab, DATA_BLOCK_ID_CURRENT_SENSOR);
                           break;
1940
                       case CANO SIG IVT CC Measurement:
1941
                       /* case CAN1 SIG ISENS6 CC Measurement: uncommented because identical position in CAN0 and CAN1 rx
1942
                       signal struct */
1943
                           currentcounterValue = *(int32 t*)value;
                           cans current tab.previous timestamp cc = cans current tab.timestamp cc;
1944
1945
                           cans current tab.timestamp cc = OS getOSSysTick();
                           cans current tab.current counter = (float)(currentcounterValue);
1946
1947
                           DB WriteBlock (&cans current tab, DATA BLOCK ID CURRENT SENSOR);
1948
                           break:
1949
                       case CANO_SIG_IVT_EC_Measurement:
1950
                       /* case CAN1_SIG_ISENS7_EC_Measurement: uncommented because identical position in CAN0 and CAN1 rx
                       signal struct */
1951
                           energycounterValue = *(int32 t*)value;
                           cans_current_tab.energy_counter = (float) (energycounterValue);
1952
1953
                           DB WriteBlock (&cans current tab, DATA BLOCK ID CURRENT SENSOR);
1954
                           break:
1955
               }
1956
1957
           return 0;
1958
       }
1959
1960
1961
       uint32 t cans setstaterequest (uint32 t sigIdx, void *value) { This is the callback function for setting state request for BMS/CONT.
1962
           DATA_BLOCK_STATEREQUEST_s staterequest_tab;
1963
           uint8_t staterequest;
1964
1965
           DB ReadBlock (&staterequest tab, DATA BLOCK ID STATEREQUEST);
```

```
1966
1967
           if (value != NULL PTR) {
1968
               if (sigIdx == CANO SIG ReceiveStateRequest) {
1969
                   staterequest = *(uint8 t *)value;
1970
                   staterequest tab.previous state request = staterequest tab.state request;
1971
                   staterequest_tab.state_request = staterequest;
1972
                   if ((staterequest_tab.state_request != staterequest_tab.previous_state_request)|| \
1973
                           (OS getOSSysTick() - staterequest tab.timestamp) > 3000) {
1974
                       staterequest tab.state request pending = staterequest;
1975
1976
                   staterequest_tab.state++;
1977
                   DB WriteBlock (&staterequest tab, DATA BLOCK ID STATEREQUEST);
1978
               }
1979
           }
1980
           return 0;
1981
       }
1982
1983
1984
       uint32 t cans getisoguard(uint32 t sigIdx, void *value) {
1985
           static DATA BLOCK ISOMETER s isoquard tab;
1986
           float canData = 0;
1987
1988
           if (value != NULL PTR) {
1989
               switch (sigIdx) {
1990
                   case CANO_SIG_InsulationStatus:
1991
                   /* First signal call */
1992
                   DB_ReadBlock(&isoguard_tab, DATA_BLOCK_ID_ISOGUARD);
1993
                   /* Check limits */
1994
1995
                   canData = cans checkLimits((float)) isoquard tab.state, siqIdx);
1996
                   /* Apply offset and factor */
1997
                   *(uint32 t *) value = (uint32 t)((canData + cans CANO signals tx[sigIdx].offset) *
                   cans CANO signals tx[sigIdx].factor);
1998
                   break;
1999
2000
                   case CANO_SIG_InsulationValue:
2001
                   /* Check limits */
2002
                   canData = cans checkLimits((float) isoquard tab.resistance kOhm, sigIdx);
                   /* Apply offset and factor */
2003
2004
                   *(uint32 t *) value = (uint32 t) ((canData + cans CANO signals tx[sigIdx].offset) *
                   cans CANO signals tx[sigIdx].factor);
2005
                   break;
2006
2007
                   default:
2008
                       *(uint32 t *) value = 0;
2009
                       break;
2010
               }
2011
2012
           return 0;
2013
       }
2014
2015
```

```
2016
      uint32 t cans setdebug(uint32 t sigIdx, void *value) {
2017
          uint8 t data[8] = \{0, 0, 0, 0, 0, 0, 0, 0, 0\};
2018
          DATA_BLOCK_SYSTEMSTATE_s systemstate_tab;
2019
2020
2021
          data[0] = *(uint64_t *) value & 0x000000000000000FF;
2022
          2023
2024
          2025
          data[4] = (*(uint64_t *)value & 0x0000000FF000000000) >> 32;
2026
          data[5] = (*(uint64_t *)value & 0 \times 00000 FF0000000000 >> 40;
          2027
          data[7] = (*(uint64 t *)value & 0xFF000000000000) >> 56;
2028
2029
2030
2031
          if (value != NULL PTR) {
2032
             switch (data[0]) {
2033
                 case 0x0B: /* Set Soc directly with value. Unit in CAN message: 0.01 percent --> range 0...10000 means
                 0%Soc...100%Soc */
2034
                     SOC SetValue(((float)((data[1]) << 8 | (data[2])))/100.0f, ((float)((data[1]) << 8 |
                     (data[2]))/100.0f, ((float)((data[1]) << 8 | (data[2])))/100.0f); /* divide by 100 to get SOC
                     between 0 and 100 */
2035
                     break:
2036
                 case 0 \times 0 = 0 \times 0 = 0 /* debug Message for Balancing on pack level */
2037
                     if (data[1] == 0) {
2038
                        BAL SetStateRequest (BAL STATE GLOBAL DISABLE REQUEST);
2039
                     } else {
2040
                        BAL_SetStateRequest (BAL_STATE_GLOBAL_ENABLE_REQUEST);
2041
2042
                    break:
2043
                 case 0xAA:
2044
                     DIAG_Handler(DIAG_CH_DEEP_DISCHARGE_DETECTED, DIAG_EVENT_OK, 0);
2045
                    break;
2046
                 case 0xBB:
2047
                     DB_ReadBlock(&systemstate_tab, DATA_BLOCK_ID_SYSTEMSTATE);
2048
                     systemstate_tab.bms_state = 0xF0;
2049
                     DB WriteBlock (&systemstate tab, DATA BLOCK ID SYSTEMSTATE);
2050
                    break:
2051
                 default:
2052
                    break:
2053
             }
2054
          }
2055
          return 0;
2056
      }
2057
2058
2059
      uint32 t cans setSWversion(uint32 t sigIdx, void *value) {
2060
          SYS SendBootMessage(0);
2061
          return 0;
2062
      }
2063
2064
      static uint32 t cans setenginerequest (uint32 t sidIdx, void *value) {
```

```
2065
          uint8_t data = *(uint64_t *)value & 0xFF;
2066
2067
          if (data == 1) {
2068
              // Close contactor
2069
              // CONT SetContactorState(CONT ENGINE, CONT SWITCH ON);
          } else {
2070
2071
              // Open contactor
              // CONT SetContactorState(CONT ENGINE, CONT SWITCH OFF);
2072
2073
          }
2074
2075
          return 0;
2076
      }
2077
2078
2079
       float cans_checkLimits(float value, uint32_t sigIdx) {
2080
          float retVal = value;
2081
2082
          if (value < cans_CANO_signals_tx[sigIdx].min)</pre>
              retVal = cans_CAN0_signals_tx[sigIdx].min;
2083
2084
2085
          if (value > cans_CANO_signals_tx[sigIdx].max)
              retVal = cans_CAN0_signals_tx[sigIdx].max;
2086
2087
2088
          return retVal;
2089
      }
2090
2091
       /*====== Extern Function Implementations ======*/
2092
```