
## link质量&惯量图: 图片

## 质量&惯量



baselink



报告与以下项相对的坐标值: 坐标系7


✓ 包括隐藏的实体/零部件(H) □创建质心特征 显示焊缝质量


所选零部件 的质量属性

leftlink1

由重心决定。 Ix = (0.3723258, 0.9280830, 0.0059556) Iy = (-0.9280200, 0.3723706, -0.0109128) Iz = (-0.0123456, -0.0014638, 0.9999227) Px = 0.0018608 Py = 0.0021238 Pz = 0.0022448 Lxz = -0.0000021 Lyz = -0.0000016 Lzz = 0.0022448 lxy = 0.0000842 lyy = 0.0019129 lzy = 0.0000049 lxz = -0.0000027 lyz = 0.0000049 lzz = 0.0042188 Izx = -0.0000027

rightlink1





leftlink3

leftlink2



✓包括隐藏的实体/零部件(H) □ 创建质心特征 □显示焊缝质量 报告与以下项相对的坐标值: 坐标系9 所选零部件 的质量属性 坐标系:坐标系9 质量 = 2.1149564 干克 体积 = 0.0004299 立方米 表面积 = 0.2088304 平方米 重心:(米) X = -0.0002834 Y = -0.0056758 Z = -0.1063657 惯性主轴和惯性主力矩:(干克\*平方米) 由重心决定。 |x = (-0.0115529, 0.1883602, 0.9820321) |y = (0.3230739, -0.9287210, 0.1819356) |z = (0.9463032, 0.3193708, -0.0501248) Px = 0.0036594 Py = 0.0105562 Pz = 0.0107860 惯性张量:(干克\*平方米) 由输出座标系决定。(使用负张量记数法。) lxx = 0.0347571 ly = 0.00008 lyx = 0.0000811 lyx = 0.00256 lzx = 0.000036 lzy = -0.0255 lxy = 0.0000811 lyy = 0.0342630 lzy = -0.0025562 Ixz = 0.0000036 Iyz = -0.0025562 Izz = 0.0039739

rightlink3





rightlink4



覆盖质量属性 重質(R) ✓ 包括隐藏的实体/零部件(H) □创建质心特征 □显示焊缝质量 报告与以下项相对的坐标值: 坐标系11 GR1-07-2-030,踝十字轴\_copy 的质量属性 配置: 默认 坐标系: 坐标系11 重心和惯性张量的输出是以 Alexbotmini\_lowerbody 为坐标系。 密度 = 2700.0000000 干克 / 立方米 质量 = 0.0173111 千克 体积 = 0.0000064 立方米 表面积 = 0.0045071 平方米 重心:(米) X = 0.0000000 Y = 0.0000000 Z = 0.0000000 rightlink5 惯性主轴和惯性主力矩:(干克\*平方米) 由重心決定。 Ix = (0.000000, 1.000000, 0.000000) Iy = (0.000000, 0.000000, 1.000000) Iz = (1.000000, 0.000000, 0.000000) Px = 0.0000013 Py = 0.0000015 Pz = 0.0000018 lxz = 0.0000000 lyz = 0.0000000 lzz = 0.0000015

leftlink5

leftlink4



leftlink6

rightlink6

注意事项: 1. 更改坐标系,改为你导出urdf的坐标系 2. 更改负张量计数法 3. 注意单位: kg&m















