# Perception System Launch Files Documentation

# xAI Generated Documentation

# May 13, 2025

# **Contents**

1	Introduction		2	
2	System Overview			2
3	File Descriptions			3
	3.1	1 Perception_system_real.launch.py		
		3.1.1	Purpose and Functionality	3
		3.1.2	Components and Structure	3
		3.1.3	Key Component: RPLidar Node	4
		3.1.4	Key Component: Camera Node	4
		3.1.5	Key Component: Perception and Emotion Recognition Nodes	5
		3.1.6	Flow Within the File	
	3.2	Perce	ption_system_sim.launch.py	
		3.2.1		
		3.2.2	Components and Structure	
		3.2.3	Key Component: USB Camera Node	
		3.2.4	Key Component: RQT Image View Node	
		3.2.5	Key Component: Perception and Emotion Recognition Nodes	
		3.2.6	Flow Within the File	7
4	System Workflow			7
5	5 Relationships Between Files		8	
6 Deployment Considerations		9		
7	Con	clusio	n	10

### 1 Introduction

This document provides a detailed technical overview of the launch files for a ROS 2-based perception system designed for robotic applications. The system focuses on initializing hardware and software components to enable hand detection and other perception tasks. The two key files analyzed are Perception\_system\_real.launch.py, which configures the system for real hardware (RPLidar and Raspberry Pi camera), and Perception\_system\_sim.launch.py, which sets up a simulated environment using a USB camera and visualization tools. This 10-page documentation covers the purpose, structure, components, and workflow of these files, providing code snippets, diagrams, and insights into their roles within the broader perception system. It is intended for developers, engineers, and roboticists working with ROS 2.

## 2 System Overview

The perception system is designed to enable robots to detect human interactions, such as raised hands, using camera and LiDAR data. The launch files serve as the entry point, orchestrating the startup of ROS 2 nodes for hardware drivers, perception processing, and visualization. The system supports two environments:

- Real Setup: Uses RPLidar and Raspberry Pi camera for real-world deployment.
- **Simulated Setup**: Uses a USB camera and RQT visualization for testing and development.

Both launch files initialize nodes that publish sensor data to topics like /image\_raw and /scan, which are consumed by perception nodes for processing. The launch files also reference a configuration file (detector\_params.yaml) for parameter tuning.




Figure 1: System Architecture

3 FILE DESCRIPTIONS 3

## 3 File Descriptions

### 3.1 Perception\_system\_real.launch.py

The Perception\_system\_real.launch.py file is a Python-based ROS 2 launch script that initializes the perception system for a real robot equipped with an RPLidar sensor and a Raspberry Pi camera. It is responsible for starting hardware drivers and perception nodes, ensuring seamless integration with the robot's physical environment.

### 3.1.1 Purpose and Functionality

- **Purpose**: Configures and launches nodes to interface with real hardware, enabling data acquisition and perception processing.
- **Functionality**: Initializes RPLidar for depth sensing, Raspberry Pi camera for imaging, and perception nodes for hand detection and emotion recognition.
- Output: Publishes sensor data to /scan (LiDAR) and /image\_raw (camera), consumed by downstream nodes.

### 3.1.2 Components and Structure

The file follows a modular structure:

- Imports: Includes ROS 2 launch utilities (launch, launch\_ros.actions), package directory access (ament\_index\_python.packages), and os for file path manipulation.
- **Function**: generate\_launch\_description() constructs a LaunchDescription object containing node definitions.
- Nodes:
  - **RPLidar Node**: Configures the RPLidar sensor for depth data.
  - Camera Node: Interfaces with the Raspberry Pi camera for image streaming.
  - Perception Node: Executes perception.py for hand detection and pose estimation.
  - Emotion Recognition Node: Runs Emotion\_Recognition.py for additional perception tasks.

Listing 1: Core Structure of Perception\_system\_real.launch.py

```
#!/usr/bin/env python3
  from launch import LaunchDescription
  from launch ros.actions import Node
  from ament_index_python.packages import get_package_share_directory
4
  import os
5
  def generate_launch_description():
7
       pkg_dir = get_package_share_directory('robot_perception')
8
       pkg_rplidar_ros = get_package_share_directory('rplidar_ros')
9
       params_file = os.path.join(pkg_dir, 'config', 'detector_params.yaml')
10
       # Node definitions follow
11
```

### 3.1.3 Key Component: RPLidar Node

The RPLidar node is critical for providing depth data, enabling 3D pose estimation.

- Package: rplidar\_ros.
- Executable: rplidar\_composition.
- Parameters:
  - serial\_port: /dev/ttyUSB1 for hardware connection.
  - serial\_baudrate: 115200 (for A1/A2 models, with a commented option for 256000 for A3).
  - frame\_id: lidar\_link for TF2 integration.
  - inverted: False, angle\_compensate: True for accurate scans.
- Output: Publishes sensor\_msgs/LaserScan messages to /scan.

Listing 2: RPLidar Node Configuration

```
rplidar_node = Node(
1
       name='rplidar_composition',
2
       package='rplidar_ros',
3
       executable='rplidar_composition',
       output='screen',
5
       parameters=[{
6
            'serial_port': '/dev/ttyUSB1',
7
           'serial baudrate': 115200,
8
           'frame id': 'lidar link',
9
           'inverted': False,
10
           'angle compensate': True,
11
       }],
12
   )
13
```

#### 3.1.4 Key Component: Camera Node

The camera node streams images from the Raspberry Pi camera using the v412\_camera package.

- Package: v412\_camera.
- Executable: v4l2\_camera\_node.
- · Parameters:
  - video device: /dev/video0.
  - image\_size: [640, 480] pixels.
  - camera\_frame\_id: camera\_link for TF2.
- Output: Publishes sensor\_msgs/Image messages to /image\_raw.

Listing 3: Camera Node Configuration

```
camera_node = Node(
package='v412_camera',
executable='v412_camera_node',
name='camera_node',
parameters=[{
```

3 FILE DESCRIPTIONS 5

```
'video_device': '/dev/video0',
'image_size': [640, 480],
'camera_frame_id': 'camera_link'
}
```

### 3.1.5 Key Component: Perception and Emotion Recognition Nodes

- **Perception Node**: Executes perception.py from the robot\_perception package, processing sensor data for hand detection and pose estimation.
- **Emotion Recognition Node**: Runs Emotion\_Recognition.py, likely processing /image\_raw for facial or emotional analysis.
- Output: Both nodes produce outputs (e.g., /hand\_raised, /customer\_pose) for downstream use.

Listing 4: Perception Node Configuration

```
perception_node = Node(
    package='robot_perception',
    executable='perception.py',
    output='screen'
)
```

#### 3.1.6 Flow Within the File

The internal flow of Perception\_system\_real.launch.py is as follows:

- Retrieve package directories for robot\_perception and rplidar\_ros.
- 2. Construct the path to detector\_params.yaml for parameter loading.
- 3. Define nodes for RPLidar, camera, perception, and emotion recognition.
- 4. Return a LaunchDescription object to launch all nodes.

### 3.2 Perception\_system\_sim.launch.py

The Perception\_system\_sim.launch.py file is a ROS 2 launch script designed for a simulated environment, replacing the RPLidar and Raspberry Pi camera with a USB camera and adding a visualization tool for debugging.

#### 3.2.1 Purpose and Functionality

- **Purpose**: Facilitates testing and development by simulating the perception system without physical hardware.
- **Functionality**: Initializes a USB camera for imaging, perception nodes for processing, and RQT for visualizing debug outputs.
- Output: Publishes /image\_raw and debug images to /hand\_detection\_debug.

3 FILE DESCRIPTIONS 6

#### 3.2.2 Components and Structure

- Imports: Includes ROS 2 launch utilities, ament\_index\_python.packages for package paths, and os.
- Function: generate\_launch\_description() defines the launch configuration.
- Nodes:
  - USB Camera Node: Streams simulated camera data.
  - **Perception Node**: Executes perception.py.
  - Emotion Recognition Node: Runs Emotion\_Recognition.py.
  - **RQT Image View Node**: Visualizes debug images.

Listing 5: Core Structure of Perception\_system\_sim.launch.py

```
#!/usr/bin/env python3
from launch import LaunchDescription
from launch_ros.actions import Node
from ament_index_python.packages import get_package_share_directory
import os

def generate_launch_description():
    pkg_dir = get_package_share_directory('robot_perception')
    params_file = os.path.join(pkg_dir, 'config', 'detector_params.yaml')
    # Node definitions follow
```

#### 3.2.3 Key Component: USB Camera Node

The USB camera node simulates the camera input for testing.

- Package: usb\_cam.
- Executable: usb cam node exe.
- Parameters:
  - video\_device: /dev/video0.
  - image\_width, image\_height: 640x480.
  - pixel\_format: yuyv.
  - framerate: 30.0.
  - camera\_frame\_id: camera\_link.
- **Remappings**: Maps image to /image\_raw.
- Output: Publishes sensor\_msgs/Image to /image\_raw.

Listing 6: USB Camera Node Configuration

```
'image_height': 480,
8
            'pixel_format': 'yuyv',
9
            'camera_frame_id': 'camera_link',
10
            'framerate': 30.0,
11
       }],
12
       remappings=[
13
            ('image', '/image_raw'),
14
       ]
15
   )
16
```

#### 3.2.4 Key Component: RQT Image View Node

The RQT node provides real-time visualization of debug images.

- Package: rqt\_image\_view.
- Executable: rqt\_image\_view.
- Arguments: Subscribes to /hand\_detection\_debug.
- Output: Displays annotated images for debugging.

Listing 7: RQT Image View Node Configuration

```
rqt_image_view = Node(
    package='rqt_image_view',
    executable='rqt_image_view',
    name='rqt_image_view',
    arguments=['/hand_detection_debug']
)
```

#### 3.2.5 Key Component: Perception and Emotion Recognition Nodes

These nodes are identical to those in the real setup, ensuring consistency in processing logic across environments.

#### 3.2.6 Flow Within the File

The internal flow of Perception\_system\_sim.launch.py is:

- Retrieve the robot\_perception package directory.
- 2. Construct the path to detector\_params.yaml.
- 3. Define nodes for USB camera, perception, emotion recognition, and RQT.
- 4. Return a LaunchDescription object to launch all nodes.

# 4 System Workflow

The perception system's workflow, driven by the launch files, is as follows:

#### 1. Launch Initialization:

- Perception\_system\_real.launch.py starts:
  - RPLidar node, publishing / scan.

- Raspberry Pi camera node, publishing /image\_raw.
- Perception and emotion recognition nodes.
- Perception\_system\_sim.launch.py starts:
  - USB camera node, publishing /image\_raw.
  - Perception and emotion recognition nodes.
  - RQT node for visualizing /hand detection debug.
- 2. **Parameter Loading**: Both launch files reference detector\_params.yaml to configure perception nodes.

#### 3. Data Acquisition:

- In the real setup, RPLidar and camera nodes provide depth and image data.
- In simulation, the USB camera provides image data.

#### 4. Data Processing:

- The perception node (perception.py) subscribes to /image\_raw and /scan (real setup only), processing data to detect hands and estimate poses.
- The emotion recognition node likely processes / image\_raw for additional tasks.

#### 5. Output Publication:

- The perception node publishes:
  - /hand\_raised: Boolean indicating hand status.
  - /customer\_pose: 3D pose of the detected person.
  - /hand\_detection\_debug: Annotated images for debugging.
- The RQT node (simulation only) visualizes debug images.
- 6. **Downstream Integration**: Outputs are consumed by other robotic components (e.g., navigation or interaction modules).

# 5 Relationships Between Files

The two launch files are closely related, serving as entry points for different environments:

#### Shared Components:

- Both launch perception.py and Emotion\_Recognition.py from the robot\_perception package, ensuring consistent processing logic.
- Both reference detector\_params.yaml for parameter configuration.

#### • Differences:

- Perception\_system\_real.launch.py includes RPLidar for depth data and uses v412\_camera for the Raspberry Pi camera.
- Perception\_system\_sim.launch.py uses usb\_cam for simulation and adds rqt\_image\_view for visualization.




Figure 2: System Workflow Diagram

#### • Data Flow:

- Both files initialize nodes that publish to /image\_raw, consumed by perception nodes.
- The real setup additionally publishes /scan for depth processing.
- Outputs from perception nodes are consistent across setups, enabling seamless transitions between real and simulated environments.

# **6 Deployment Considerations**

To deploy the launch files:

#### • Real Setup:

- Ensure RPLidar and Raspberry Pi camera are connected to /dev/ttyUSB1 and /dev/video0, respectively.
- Install dependencies: rplidar\_ros, v4l2\_camera, robot\_perception.
- Run: ros2 launch robot\_perception Perception\_system\_real.launch.py.

#### Simulation Setup:

- Connect a USB camera to /dev/video0.
- Install dependencies: usb\_cam, rqt\_image\_view, robot\_perception.
- Run: ros2 launch robot\_perception Perception\_system\_sim.launch.py.

7 CONCLUSION 10

• **Configuration**: Verify detector\_params.yaml exists in the robot\_perception/config directory.

### 7 Conclusion

The Perception\_system\_real.launch.py and Perception\_system\_sim.launch.py files are critical components of a ROS 2-based perception system, enabling flexible deployment in real and simulated environments. By initializing hardware drivers, perception nodes, and visualization tools, they ensure robust data acquisition and processing for hand detection and related tasks. This documentation provides a comprehensive understanding of their structure, components, and workflow, serving as a valuable resource for roboticists developing perception-enabled systems.