

Totally Integrated Automation Portal

FC_InterfaceConnection_HMI [FC10]

FC_InterfaceConnection_HMI Properties

General

Name	FC_InterfaceConne- ction_HMI	Number	10	Type	FC	Language	LAD
Numbering	Manual						

Information

Title		Author		Comment		Family	
Version	0.1	User-defined ID					

Name	Data type	Default value	Comment
Input			
Output			
InOut			
Temp			
Constant			
▼ Return			
FC_InterfaceConnection_HMI	Void		

Network 1:

```
0001 // RB154
0002 "DB_HMI".STS.RB154_Transfer := "DB_External_Interface".RB154.ReadyToTransfer;
0003
0004 // RB155
0005 "DB_HMI".SNS.Front_RB155 := "DB_Global".RB155.SNS.Front;
0006 "DB_HMI".SNS.Rear_RB155 := "DB_Global".RB155.SNS.Rear;
0007
0008 // RB156
0009 "DB_HMI".SNS.Front_RB156 := "DB_Global".RB156.SNS.Front;
0010 "DB_HMI".SNS.Rear_RB156 := "DB_Global".RB156.SNS.Rear;
0011
0012 // RB157
0013 "DB_HMI".SNS.Front_RB157 := "DB_Global".RB157.SNS.Front;
0014 "DB_HMI".SNS.Rear_RB157 := "DB_Global".RB157.SNS.Rear;
0015
0016 // RB158
0017 "DB_HMI".SNS.Front_RB158 := "DB_Global".RB158.SNS.Front;
0018 "DB_HMI".SNS.Rear_RB158 := "DB_Global".RB158.SNS.Rear;
0019
0020
0021 // E156
0022 "DB_HMI".SNS.Low_E156 := "DB_Global".E156.SNS.LowsNS;
0023 "DB_HMI".SNS.Middle_E156 := "DB_Global".E156.SNS.MiddleSNS;
0024 "DB_HMI".SNS.Top_E156 := "DB_Global".E156.SNS.TopSNS;
0025 "DB_HMI".SNS.Home_E156 := "DB_Global".E156.SNS.Home;
0026
0027 "DB_HMI".SNS.BlocksOpened := "DB_Global".E156.SNS.BlocksOpened;
0028 "DB_HMI".SNS.BlocksClosed := "DB_Global".E156.SNS.BlocksClosed;
```

Network 2:

```
0001 // RB155
0002 "DB_HMI".STS.RB155_Fault := "DB_Global".RB155.STS.Fault;
0003 "DB_HMI".STS.RB155_ReadyTransfer := "DB_Global".RB155.STS.ReadyToTransfer;
0004
0005 // RB156
0006 "DB_HMI".STS.RB156_Fault := "DB_Global".RB156.STS.Fault;
0007 "DB_HMI".STS.RB156_Transfer_RB157 := "DB_Global".RB156.STS.ReadyToTransfer AND "DB_Global".E156.SNS."Skid_RB156-RB157";
0008 "DB_HMI".STS.RB156_Transfer_RB158 := "DB_Global".RB156.STS.ReadyToTransfer AND "DB_Global".E156.SNS."Skid_RB156-RB158";
0009 "DB_HMI".STS.RB156_Transfer := "DB_Global".RB156.STS.ReadyToTransfer;
0010
0011 // RB157
0012 "DB_HMI".STS.RB157_Fault := "DB_Global".RB157.STS.Fault;
0013 "DB_HMI".STS.RB157_ReadyTransfer := "DB_Global".RB157.STS.ReadyToTransfer;
0014
0015 // RB158
0016 "DB_HMI".STS.RB158_Fault := "DB_Global".RB158.STS.Fault;
0017 "DB_HMI".STS.RB158_ReadyTransfer := "DB_Global".RB158.STS.ReadyToTransfer;
0018
0019 // E156
0020 "DB_HMI".STS.E156_MovingDown := "DB_Global".E156.STS.MovingDown;
0021 "DB_HMI".STS.E156_MovingUp := "DB_Global".E156.STS.MovingUp;
```

Network 3:

```
0001 // Manual moves
0002 IF "DB_Global".GENERAL.CMD.ManualMode = FALSE THEN
0003     "DB_HMI".CMD.ManualMoves := 0;
0004 END_IF;
0005
```

Totally Integrated Automation Portal		
0006 // RB155 "DB_Global".RB155.CMD.BackwardMove := FALSE; "DB_Global".RB155.CMD.FordwardMove := FALSE; "DB_Global".RB155.CMD.ResetToNext := FALSE; "DB_Global".RB155.CMD.SetToNext := FALSE; 0011 0012 // RB156 "DB_Global".RB156.CMD.BackwardMove := FALSE; "DB_Global".RB156.CMD.FordwardMove := FALSE; "DB_Global".RB156.CMD.ResetToNext := FALSE; "DB_Global".RB156.CMD.SetToNext := FALSE; 0017 0018 // RB157 "DB_Global".RB157.CMD.BackwardMove := FALSE; "DB_Global".RB157.CMD.FordwardMove := FALSE; "DB_Global".RB157.CMD.ResetToNext := FALSE; "DB_Global".RB157.CMD.SetToNext := FALSE; 0023 0024 // RB158 "DB_Global".RB158.CMD.BackwardMove := FALSE; "DB_Global".RB158.CMD.FordwardMove := FALSE; "DB_Global".RB158.CMD.ResetToNext := FALSE; "DB_Global".RB158.CMD.SetToNext := FALSE; 0029 0030 // E156 "DB_Global".E156.CMD.Ascent := FALSE; "DB_Global".E156.CMD.Descent := FALSE; "DB_Global".E156.CMD.Homing := FALSE; "DB_Global".E156.CMD.CloseBlocks := FALSE; "DB_Global".E156.CMD.OpenBlocks := FALSE; 0036 0037 0038 CASE "DB_HMI".CMD.ManualMoves OF 0039 1: 0040 "DB_Global".RB155.CMD.BackwardMove := TRUE; 0041 2: 0042 "DB_Global".RB155.CMD.FordwardMove := TRUE; 0043 3: 0044 "DB_Global".RB155.CMD.ResetToNext := TRUE; 0045 4: 0046 "DB_Global".RB155.CMD.SetToNext := TRUE; 0047 5: 0048 "DB_Global".RB156.CMD.BackwardMove := TRUE; 0049 6: 0050 "DB_Global".RB156.CMD.FordwardMove := TRUE; 0051 7: 0052 "DB_Global".RB156.CMD.ResetToNext := TRUE; 0053 8: 0054 "DB_Global".RB156.CMD.SetToNext := TRUE; 0055 9: 0056 "DB_Global".RB157.CMD.BackwardMove := TRUE; 0057 10: 0058 "DB_Global".RB157.CMD.FordwardMove := TRUE; 0059 11: 0060 "DB_Global".RB157.CMD.ResetToNext := TRUE; 0061 12: 0062 "DB_Global".RB157.CMD.SetToNext := TRUE; 0063 13: 0064 "DB_Global".RB158.CMD.BackwardMove := TRUE; 0065 14: 0066 "DB_Global".RB158.CMD.FordwardMove := TRUE; 0067 15: 0068 "DB_Global".RB158.CMD.ResetToNext := TRUE; 0069 16: 0070 "DB_Global".RB158.CMD.SetToNext := TRUE; 0071 17: 0072 "DB_Global".E156.CMD.Ascent := TRUE; 0073 18: 0074 "DB_Global".E156.CMD.Descent := TRUE; 0075 19: 0076 "DB_Global".E156.CMD.Homing := TRUE; 0077 20: 0078 "DB_Global".E156.CMD.CloseBlocks := TRUE; 0079 21: 0080 "DB_Global".E156.CMD.OpenBlocks := TRUE; 0081 END_CASE; Network 4: 0001 // General 0002 "DB_HMI".ALM.AlarmWord2.%X8 := "DB_Global".GENERAL.STS.LossComm_PLC_0; 0003 "DB_HMI".ALM.AlarmWord2.%X9 := "DB_Global".GENERAL.STS.LossComm_PLC_0; 0004 "DB_HMI".ALM.AlarmWord2.%X10 := "DB_External_Interface".RB154.Faulted; 0005 "DB_HMI".ALM.AlarmWord2.%X11 := "DB_External_Interface".RB159.Faulted; 0006 "DB_HMI".ALM.AlarmWord2.%X12 := "DB_External_Interface".RB160.Faulted; 0007 0008 // RB155		

Totally Integrated Automation Portal		
0009 "DB_HMI".ALM.AlarmWord1.%X0 := "DB_Global".RB155.ALM.ThermalProtection; 0010 "DB_HMI".ALM.AlarmWord1.%X1 := "DB_Global".RB155.ALM.TimeOutTransfer; 0011 0012 // RB156 0013 "DB_HMI".ALM.AlarmWord1.%X2 := "DB_Global".RB156.DRIVE.StatusWord.%X2; 0014 "DB_HMI".ALM.AlarmWord1.%X3 := "DB_Global".RB156.ALM.ThermalProtection; 0015 "DB_HMI".ALM.AlarmWord1.%X4 := "DB_Global".RB156.ALM.TimeOutTransfer; 0016 "DB_HMI".ALM.AlarmWord1.%X5 := "DB_Global".RB156.ALM.ExtraPositionFront; 0017 "DB_HMI".ALM.AlarmWord1.%X6 := "DB_Global".RB156.ALM.ExtraPositionRear; 0018 0019 // RB157 0020 "DB_HMI".ALM.AlarmWord1.%X7 := "DB_Global".RB157.ALM.ThermalProtection; 0021 "DB_HMI".ALM.AlarmWord1.%X8 := "DB_Global".RB157.ALM.TimeOutTransfer; 0022 0023 // RB158 0024 "DB_HMI".ALM.AlarmWord1.%X9 := "DB_Global".RB158.ALM.ThermalProtection; 0025 "DB_HMI".ALM.AlarmWord1.%X10 := "DB_Global".RB158.ALM.TimeOutTransfer; 0026 0027 // E156 0028 "DB_HMI".ALM.AlarmWord1.%X11 := "DB_Global".E156.ALM.BlocksOpenedTraveling; 0029 "DB_HMI".ALM.AlarmWord1.%X12 := "DB_Global".E156.ALM.MismatchLevel; 0030 "DB_HMI".ALM.AlarmWord1.%X13 := "DB_Global".E156.ALM.NoComandeE156; 0031 "DB_HMI".ALM.AlarmWord1.%X14 := "DB_Global".E156.ALM.OverlapSNS; 0032 "DB_HMI".ALM.AlarmWord1.%X15 := "DB_Global".E156.ALM.OvertravelHigh; 0033 "DB_HMI".ALM.AlarmWord2.%X0 := "DB_Global".E156.ALM.OvertravelLow; 0034 "DB_HMI".ALM.AlarmWord2.%X1 := "DB_Global".E156.ALM.ThermalProtectDrive; 0035 "DB_HMI".ALM.AlarmWord2.%X2 := "DB_Global".E156.ALM.ThermaProtectBlocks; 0036 "DB_HMI".ALM.AlarmWord2.%X3 := "DB_Global".E156.ALM.TimeOutAscent; 0037 "DB_HMI".ALM.AlarmWord2.%X4 := "DB_Global".E156.ALM.TimeOutDescent; 0038 "DB_HMI".ALM.AlarmWord2.%X5 := "DB_Global".E156.ALM.TimeOutCloseBlocks; 0039 "DB_HMI".ALM.AlarmWord2.%X6 := "DB_Global".E156.ALM.TimeOutOpenBlocks; 0040 "DB_HMI".ALM.AlarmWord2.%X7 := "DB_Global".E156.DRIVE.StatusWord.%X2; 0041		