

SOLIDWORKS API (NET VBA C#) — Reference (62/337): ICurve (part 2 of 2)

SOLIDWORKS API Documentation (converted from CHM)

ICurve (part 2 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetBCurveParamsSize2 Method (ICurve)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IGetBCurveParamsSize2 Method (ICurve)

Obsolete. Superseded by [ICurve::IGetBCurveParamsSize3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBCurveParamsSize2( _  
    ByVal WantCubic As System.Boolean, _  
    ByVal WantNRational As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim WantCubic As System.Boolean  
Dim WantNRational As System.Boolean  
Dim value As System.Integer  
  
value = instance.IGetBCurveParamsSize2(WantCubic, WantNRational)
```

C#

```
System.int IGetBCurveParamsSize2(  
    System.bool WantCubic,  
    System.bool WantNRational  
)
```

C++/CLI

```
System.int IGetBCurveParamsSize2(  
& System.bool WantCubic,  
& System.bool WantNRational  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WantCubic

True for cubic curves, false if not

WantNRational

True for non-rational curves, false if not

Return Value

Size of the data set returned by [ICurve::IGetBCurveParams](#).

Visual Basic for Applications (VBA) Syntax

See [Curve::IGetBCurveParamsSize2](#).

Example

[Get Curve Spline Points \(C++\)](#)

Remarks

Use this method to control the type of information returned in the subsequent call to [ICurve::IGetBCurveParams](#).

To control the accuracy of the curve data, use [IModeler::SetToleranceValue](#).

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::GetBCurveParams Method](#)
[ICurve::IGetBCurveParams Method](#)
[ICurve::IsBCurve Method](#)
[ICurve::SimplifyBCurve Method](#)
[ICurve::MakeBSplineCurve Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetBCurveParamsSize3 Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IGetBCurveParamsSize3 Method (ICurve)

Gets the b-curve size.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBCurveParamsSize3( _  
    ByVal WantCubicIn As System.Boolean, _  
    ByVal WantNRRational As System.Boolean, _  
    ByVal ForceNonPeriodic As System.Boolean _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim WantCubicIn As System.Boolean  
Dim WantNRRational As System.Boolean  
Dim ForceNonPeriodic As System.Boolean  
Dim value As System.Integer  
  
value = instance.IGetBCurveParamsSize3(WantCubicIn, WantNRRational, ForceNonPeriodic)
```

C#

```
System.int IGetBCurveParamsSize3(  
    System.bool WantCubicIn,  
    System.bool WantNRRational,  
    System.bool ForceNonPeriodic  
)
```

C++/CLI

```
System.int IGetBCurveParamsSize3(  
& System.bool WantCubicIn,  
& System.bool WantNRRational,  
& System.bool ForceNonPeriodic  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WantCubicIn

True for cubic curves, false if not

WantNRRational

True for non-rational curves, false if not

ForceNonPeriodic

True converts the curve to nonperiodic and returns parameters, false does not

Return Value

Size of the data set returned by [ICurve::IGetBCurveParams3](#)

Visual Basic for Applications (VBA) Syntax

See [Curve::IGetBCurveParamsSize3](#).

Remarks

Use this method to control the type of information returned in the subsequent call to [ICurve::IGetBCurveParams3](#).

To control the accuracy of the curve data, see [IModeler::SetToleranceValue](#).

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::IGetBCurveParams3 Method](#)

Availability

SOLIDWORKS 2007 SP5, Revision Number 15.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetClosestPointOn Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IGetClosestPointOn Method (ICurve)

Determines the closest point on the curve using the x,y,z input point.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetClosestPointOn( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Double  
  
value = instance.IGetClosestPointOn(X, Y, Z)
```

C#

```
System.double IGetClosestPointOn(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.double IGetClosestPointOn(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
X value of the input point
Y
Y value of the input point
Z

Z value of the input point

Return Value

Array of 5 doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Curve::IGetClosestPointOn](#).

Remarks

This method returns only one point, regardless of the number of valid minimum distance points.

The array return contains the following values:

[*PointX*, *PointY*, *PointZ*, *ParamU*, *NotUsed*]

where:

- *PointX*, *PointY*, and *PointZ* represent the point on the curve
- *ParamU* is the parameter on the curve that is closest to the input point
- *NotUsed* is unused

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::GetClosestPointOn Method](#)
[IEdge::GetClosestPointOn Method](#)
[IEdge::IGetClosestPointOn Method](#)
[IFace2::GetClosestPointOn Method](#)
[IFace2::IGetClosestPointOn Method](#)
[ISelectionMgr::GetSelectionPoint2 Method](#)
[ISelectionMgr::IGetSelectionPoint2 Method](#)
[ISelectionMgr::IGetSelectionPointInSketchSpace2 Method](#)
[ISelectionMgr::GetSelectionPointInSketchSpace2 Method](#)
[ISurface::GetClosestPointOn Method](#)
[ISurface::IGetClosestPointOn Method](#)
[IVertex::GetClosestPointOn Method](#)
[IVertex::IGetClosestPointOn Method](#)
[IVertex::IGetClosestPointOn Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetEllipseParams Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IGetEllipseParams Method (ICurve)

Gets the parameters for this elliptical curve.

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetEllipseParams( _  
    ByRef ParamArray As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim ParamArray As System.Double  
  
instance.IGetEllipseParams(ParamArray)
```

C#

```
void IGetEllipseParams(  
    ref System.double ParamArray
```

)

C++/CLI

```
void IGetEllipseParams(  
& System.double% ParamArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ParamArray

- In-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Use [ICurve::IsEllipse](#) to determine if a curve is an ellipse.

The return value is an array of doubles with the following format:

[*centerptX*, *centerptY*, *centerptZ*, *majorRad*, *majorAxisX*, *majorAxisY*, *majorAxisZ*, *minorRad*, *minorAxisX*, *minorAxisY*, *minorAxisZ*]

where:

- *centerptX*, *centerptY*, *centerptZ* = location of ellipse center
- *majorRad* = major radius
- *majorAxisX*, *majorAxisY*, *majorAxisZ* = major axis values
- *minorRad* = minor radius
- *minorAxisX*, *minorAxisY*, *minorAxisZ* = minor axis values

You must pass an array of 11 doubles that has already been allocated. If you pass a NULL pointer or the curve is not an ellipse, then SOLIDWORKS returns *S_false*.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::GetEllipseParams Method](#)
[ICurve::Identity Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPCurveParams Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IGetPCurveParams Method (ICurve)

Converts a curve to a piecewise rational cubic polynomial form.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPCurveParams() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim value As System.Double
```

```
value = instance.IGetPCurveParams()
```

C#

```
System.double IGetPCurveParams()
```

C++/CLI

```
System.double IGetPCurveParams();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles describing the parameters of the curve (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The curve is output as a series of segments.

This method returns the curve as a series of segments, each of which has this form:

$$p(t) = \frac{(w_0 \cdot a_0 + w_1 \cdot a_1 \cdot t + w_2 \cdot a_2 \cdot t^2 + w_3 \cdot a_3 \cdot t^3)}{(w_0 + w_1 \cdot t + w_2 \cdot t^2 + w_3 \cdot t^3)}$$

Where *w* is the weight coefficient and *a* is the polynomial coefficient.

The coefficients returned are vectors of dimensions "dim". For example, if the curve is rational, then *dimension* = 4, and the coefficients returned for each segment are as follows:

(a0x,a0y,a0z,w0),(a1x,a1y,a1z,w1)...

However, if the curve is returned as non-rational, then *dimension* = 3, and its coefficients are:

(a0x,a0y,a0z),(a1x,a1y,a1z),...

Use [ICurve::IGetPCurveParamsSize](#) to determine the size of the array returned.

The size of the return value array is (3 + *NumberKnots* + *NumberSegments* x *Order* x *Dimension*).

The array is as follows:

[*packedDouble1*, *packedDouble2*, *packedDouble3*, *knot1*, *knot2*,..., *CoefficientsSegment1*[*Dimension*], *CoefficientsSegment2*[*Dimension*],...]

where:

packedDouble1: Integer pair containing *Reserved* and *Order*
packedDouble2: Integer pair containing *NumberSegments* and *Periodicity*
packedDouble3: Integer pair containing *NumberKnots* and *Dimension*
knot1
knot2
...
CoefficientsSegment1[*Dimension*]
CoefficientsSegment2[*Dimension*]
...

The coefficients for each segment start with the constant term and end with the term of highest degree (for example, ConstantX, ConstantY, ConstantZ, AX, AY, AZ, BX, BY, BZ). The total number of coefficients is:

(*NumberSegments*) x (*Order*) x (*Dimension*).

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::Identity Method](#)
[ICurve::GetPCurveParams Method](#)
[ICurve::IGetPCurveParamsSize Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPCurveParamsSize Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IGetPCurveParamsSize Method (ICurve)

Gets the p-curve size.

.NET Syntax

Visual Basic (Declaration)

Function IGetPCurveParamsSize() As System.Integer

Visual Basic (Usage)



```
Dim instance As ICurve
Dim value As System.Integer

value = instance.IGetPCurveParamsSize()
```

C#

```
System.int IGetPCurveParamsSize()
```

C++/CLI

```
System.int IGetPCurveParamsSize();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Size of the data set

Visual Basic for Applications (VBA) Syntax

See [Curve::IGetCurveParamsSize](#).

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::IGetPCurveParams Method](#)
[ICurve::GetPCurveParams Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSplinePts Method (ICurve)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IGetSplinePts Method (ICurve)

Gets the spline points for this curve.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSplinePts() As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICurve
Dim value As System.Double

value = instance.IGetSplinePts()
```

C#

```
System.double IGetSplinePts()
```

C++/CLI

```
System.double IGetSplinePts();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array containing the spline points
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Example

[Get Curve Spline Points \(C++\)](#)

Remarks

[ICurve::IGetSplinePtsSize](#) defines the spline and determines the size of the array returned.

The array returned contains the x, y, z location of the spline points:

[x1, y1, z1, x2, y2, z2,...]

Data passed into [ICurve::IGetSplinePtsSize](#) must satisfy the following requirements:

- If the curve is periodic, it must not have any repeated knots.
- If the curve is non-periodic, it must only have repeated knots at its ends.
- The curve must be cubic or lower degree, non-rational, and have continuous first and second derivatives.

NOTE: For a linear or quadratic curve to satisfy these continuity requirements, it must consist of a single segment.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::IGetSplinePts Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSplinePtsSize Method (ICurve)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IGetSplinePtsSize Method (ICurve)

Gets the size of the array required by [ICurve::IGetSplinePts](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSplinePtsSize( _  
    ByRef PropArray As System.Integer, _  
    ByRef KnotsArray As System.Double, _  
    ByRef CntrlPntCoordArray As System.Double _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim PropArray As System.Integer  
Dim KnotsArray As System.Double  
Dim CntrlPntCoordArray As System.Double  
Dim value As System.Integer  
  
value = instance.IGetSplinePtsSize(PropArray, KnotsArray, CntrlPntCoordArray)
```

C#

```
System.int IGetSplinePtsSize(  
    ref System.int PropArray,  
    ref System.double KnotsArray,  
    ref System.double CntrlPntCoordArray  
)
```

C++/CLI

```
System.int IGetSplinePtsSize(  
    & System.int% PropArray,  
    & System.double% KnotsArray,  
    & System.double% CntrlPntCoordArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropArray

Array that includes dimension, order, number of control points, and periodicity

KnotsArray

knot1, knot2, ..., knot n

CntrlPntCoordArray

controlpoint1[dimension], controlpoint2[dimension], ..., controlpoint n [dimension]

Return Value

Size of the data set returned by [ICurve::IGetSplinePts](#)

Visual Basic for Applications (VBA) Syntax

See [Curve::IGetSplinePtsSize](#).

Example

[Get Curve Spline Points \(C++\)](#)

Remarks

PropArray contains 4 integers:

- Dimension
- Order
- Number of control points
- Periodicity (True or false)

KnotsArray is an array of doubles with (Number of control points + Order) elements.

The size of the CntrlPntCoordArray array is based on the curve dimension.

- Dimension = 2 then each control point is an array of 2 doubles (u, v)
- Dimension = 3 then each control point is an array of 3 doubles (x, y, z)
- Dimension = 4 then each control point is an array of 4 doubles (x, y, z, w) where w = weight

Data passed into this method must satisfy the following requirements:

- If the curve is periodic, it must not have any repeated knots.
- If the curve is non-periodic, it must only have repeated knots at its ends.
- The curve must be cubic or lower degree, non-rational and have continuous first and second derivatives.

NOTE: For a linear or quadratic curve to satisfy these continuity requirements, it must consist of a single segment.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::IGetSplinePts Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTessPts Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IGetTessPts Method (ICurve)

Gets a set of points that represent the tessellation of this curve.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTessPts( _  
    ByVal ChordTolerance As System.Double, _  
    ByVal LengthTolerance As System.Double, _  
    ByRef StartPoint As System.Double, _  
    ByRef EndPoint As System.Double _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim ChordTolerance As System.Double  
Dim LengthTolerance As System.Double  
Dim StartPoint As System.Double  
Dim EndPoint As System.Double  
Dim value As System.Double
```

```
value = instance.IGetTessPts(ChordTolerance, LengthTolerance, StartPoint, EndPoint)
```

C#

```
System.double IGetTessPts(  
    System.double ChordTolerance,  
    System.double LengthTolerance,  
    ref System.double StartPoint,  
    ref System.double EndPoint  
)
```

C++/CLI

```
System.double IGetTessPts(  
    & System.double ChordTolerance,  
    & System.double LengthTolerance,  
    & System.double% StartPoint,  
    & System.double% EndPoint  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ChordTolerance

Chord tolerance to use in tessellation (meters); this is the maximum permitted distance from a cord to the curve between the cord endpoints; the smallest allowable value for this parameter is 1E-8; if 0.0 or a value smaller than 1E-8 is specified, then 1E-8 is used by default

LengthTolerance

Length tolerance to be used to filter out very short segments (meters); this method does not return tessellated segments shorter than this value

StartPoint

Pointer to an array containing the start point of the curve

EndPoint

Pointer to an array containing the end point of the curve

Return Value

- in-process, unmanaged C++: Pointer to an array containing the tessellation points (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

The array returned contains the x, y, z location of the tessellation points:

[x1, y1, z1, x2, y2, z2, ...]

Before calling this method, call [ICurve::IGetTessPtsSize](#) to determine the size of the array needed to contain the return values of this method.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::GetTessPts Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTessPtsSize Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IGetTessPtsSize Method (ICurve)

Gets the size of the array required by [ICurve::IGetTessPts](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTessPtsSize( _
    ByVal ChordTolerance As System.Double, _
    ByVal LengthTolerance As System.Double, _
    ByRef StartPoint As System.Double, _
    ByRef EndPoint As System.Double _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICurve
Dim ChordTolerance As System.Double
Dim LengthTolerance As System.Double
Dim StartPoint As System.Double
Dim EndPoint As System.Double
Dim value As System.Integer

value = instance.IGetTessPtsSize(ChordTolerance, LengthTolerance, StartPoint, EndPoint)
```

C#

```
System.int IGetTessPtsSize(
    System.double ChordTolerance,
    System.double LengthTolerance,
    ref System.double StartPoint,
    ref System.double EndPoint
)
```

C++/CLI

```
System.int IGetTessPtsSize(
    & System.double ChordTolerance,
    & System.double LengthTolerance,
    & System.double% StartPoint,
    & System.double% EndPoint
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ChordTolerance

Chord tolerance to be used in tessellation (meters); this is the maximum permitted distance from a cord to the curve between the cord endpoints

LengthTolerance

Length tolerance to be used to filter out very short segments (meters); tessellated segments shorter than this value are not returned

StartPoint

Pointer to an array containing the start point of the curve

EndPoint

Pointer to an array containing the end point of the curve

Return Value

Number of doubles returned when [ICurve::IGetTessPts](#) is called

Visual Basic for Applications (VBA) Syntax

See [Curve::IGetTessPtsSize](#).

Remarks

To get the actual tessellation points, use [ICurve::IGetTessPts](#). Arguments passed to [ICurve::IGetTessPts](#) must match the arguments passed to this method.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::GetTessPts Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments on this topic.](#)

IntersectCurve Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IntersectCurve Method (ICurve)

Gets a set of points that represent the intersection of two trimmed curves.

.NET Syntax

Visual Basic (Declaration)

```
Function IIntersectCurve( _  
    ByVal OtherCurve As Curve, _  
    ByRef ThisStartPoint As System.Double, _  
    ByRef ThisEndPoint As System.Double, _  
    ByRef OtherStartPoint As System.Double, _  
    ByRef OtherEndPoint As System.Double _  
    ) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim OtherCurve As Curve  
Dim ThisStartPoint As System.Double  
Dim ThisEndPoint As System.Double  
Dim OtherStartPoint As System.Double  
Dim OtherEndPoint As System.Double  
Dim value As System.Double  
  
value = instance.IIntersectCurve(OtherCurve, ThisStartPoint, ThisEndPoint, OtherStartPoint,  
OtherEndPoint)
```

C#

```
System.double IIntersectCurve(  
    Curve OtherCurve,  
    ref System.double ThisStartPoint,  
    ref System.double ThisEndPoint,  
    ref System.double OtherStartPoint,  
    ref System.double OtherEndPoint  
)
```

C++/CLI

```
System.double IIntersectCurve(  
& Curve^ OtherCurve,  
& System.double% ThisStartPoint,  
& System.double% ThisEndPoint,  
& System.double% OtherStartPoint,  
& System.double% OtherEndPoint  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OtherCurve
Curve to intersect with this [curve](#)

ThisStartPoint
Start point of this curve

ThisEndPoint
End point of this curve

OtherStartPoint
Start point of otherCurve

OtherEndPoint

End point of otherCurve

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles of the intersection points (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [Curve::IntersectCurve](#).

Remarks

The array of doubles returned contains the x, y, z location of the tessellation points and a code for each point that indicates the intersection class

[x1, y1, z1, k1, x2, y2, z2, k2....]

Return codes are defined in [swIntersectionType_e](#).

Before calling this method, call [ICurve::IntersectCurveSize](#) to determine the size of the array needed for the return values from this method.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::IntersectCurve Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1988319

SOLIDWORKS API Help

[Send comments on this topic.](#)

IntersectCurveSize Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IntersectCurveSize Method (ICurve)

Gets the size of the array required by [ICurve::IntersectCurve](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IIntersectCurveSize( _  
    ByVal OtherCurve As Curve, _  
    ByRef ThisStartPoint As System.Double, _  
    ByRef ThisEndPoint As System.Double, _  
    ByRef OtherStartPoint As System.Double, _  
    ByRef OtherEndPoint As System.Double _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim OtherCurve As Curve  
Dim ThisStartPoint As System.Double  
Dim ThisEndPoint As System.Double  
Dim OtherStartPoint As System.Double  
Dim OtherEndPoint As System.Double  
Dim value As System.Integer
```

```
value = instance.IIntersectCurveSize(OtherCurve, ThisStartPoint, ThisEndPoint, OtherStartPoint,  
OtherEndPoint)
```

C#

```
System.int IIntersectCurveSize(  
    Curve OtherCurve,  
    ref System.double ThisStartPoint,
```

```

    ref System.double ThisEndPoint,
    ref System.double OtherStartPoint,
    ref System.double OtherEndPoint
)

```

C++/CLI

```

System.int IIntersectCurveSize(
& Curve^ OtherCurve,
& System.double% ThisStartPoint,
& System.double% ThisEndPoint,
& System.double% OtherStartPoint,
& System.double% OtherEndPoint
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OtherCurve

Curve to intersect with this curve

ThisStartPoint

Start point of this curve

ThisEndPoint

End point of this curve

OtherStartPoint

Start point of otherCurve

OtherEndPoint

End point of otherCurve

Return Value

Size of the array needed to contain the return values of [ICurve::IntersectCurve](#)

Visual Basic for Applications (VBA) Syntax

See [Curve::IntersectCurveSize](#).

Remarks

To get the actual intersection points, call [ICurve::IntersectCurve](#).

See Also

[ICurve Interface](#)

[ICurve Members](#)

[ICurve::IntersectCurve Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments on this topic.](#)

IJoinCurves Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IJoinCurves Method (ICurve)

Joins the specified curves.

.NET Syntax

Visual Basic (Declaration)

```

Function IJoinCurves( _
    ByVal NCurves As System.Integer, _
    ByRef Curves As Curve _
) As Curve

```

Visual Basic (Usage)

```
Dim instance As ICurve
Dim NCurves As System.Integer
Dim Curves As Curve
Dim value As Curve

value = instance.IJoinCurves(NCurves, Curves)
```

C#

```
Curve IJoinCurves(
    System.int NCurves,
    ref Curve Curves
)
```

C++/CLI

```
Curve^ IJoinCurves(
    & System.int NCurves,
    & Curve^% Curves
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NCurves

Number of curves to join

Curves

- in-process, unmanaged C++: Pointer to an array of [curves](#) to join

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

Newly created joined [curve](#)

See Also

[ICurve Interface](#)

[ICurve Members](#)

[ICurve.JoinCurves Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ILineParams Property (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : ILineParams Property (ICurve)

Gets the parameters of a curve that is a line.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ILineParams As System.Double
```

Visual Basic (Usage)

```
Dim instance As ICurve
Dim value As System.Double

value = instance.ILineParams
```

C#

```
System.double ILineParams {get;}
```

```
property System.double ILineParams {
    System.double get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to an array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Curve::ILineParams](#).

Remarks

The return value is an array of 6 double values:

[*rootPoint.x*, *rootPoint.y*, *rootPoint.z*, *direction.x*, *direction.y*, *direction.z*]

SOLIDWORKS stores *rootPoint* in meters.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::LineParams Property](#)
[ICurve::IsLine Method](#)
[ICurve::Identity Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IntersectCurve Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IntersectCurve Method (ICurve)

Gets a set of points that represent the intersection of two trimmed curves.

.NET Syntax

Visual Basic (Declaration)

```
Function IntersectCurve( _
    ByVal OtherCurve As System.Object, _
    ByVal ThisStartPoint As System.Object, _
    ByVal ThisEndPoint As System.Object, _
    ByVal OtherStartPoint As System.Object, _
    ByVal OtherEndPoint As System.Object _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICurve
Dim OtherCurve As System.Object
Dim ThisStartPoint As System.Object
Dim ThisEndPoint As System.Object
Dim OtherStartPoint As System.Object
Dim OtherEndPoint As System.Object
Dim value As System.Object
```

```
value = instance.IntersectCurve(OtherCurve, ThisStartPoint, ThisEndPoint, OtherStartPoint,
OtherEndPoint)
```

C#

```
System.object IntersectCurve(
    System.object OtherCurve,
    System.object ThisStartPoint,
    System.object ThisEndPoint,
    System.object OtherStartPoint,
```

```
System.Object OtherEndPoint
)
```

C++/CLI

```
System.Object^ IntersectCurve(
& System.Object^ OtherCurve,
& System.Object^ ThisStartPoint,
& System.Object^ ThisEndPoint,
& System.Object^ OtherStartPoint,
& System.Object^ OtherEndPoint
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OtherCurve

Curve to intersect with this [curve](#)

ThisStartPoint

Array containing the start point of this curve

ThisEndPoint

Array containing the end point of this curve

OtherStartPoint

Array containing the start point of otherCurve

OtherEndPoint

Array containing the end point of otherCurve

Return Value

Array containing the intersection points (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Curve::IntersectCurve](#).

Remarks

The array of doubles returned contains the x, y, z location of the tessellation points and a code for each point that indicates the intersection class

[x1, y1, z1, k1, x2, y2, z2, k2....]

Return codes are defined in [swIntersectionType_e](#).

See Also

[ICurve Interface](#)

[ICurve Members](#)

[ICurve::IntersectCurve Method](#)

[ICurve::IntersectCurveSize Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments on this topic.](#)

IRReverseCurve Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IRReverseCurve Method (ICurve)

Gets the reversed copy of this curve.

.NET Syntax

Visual Basic (Declaration)

```
Function IRReverseCurve() As Curve
```

Visual Basic (Usage)

```
Dim instance As ICurve
Dim value As Curve
```



Copy Code

```
value = instance.IReverseCurve()
```

C#

```
Curve IReverseCurve()
```

C++/CLI

```
Curve^ IReverseCurve();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the reversed [curve](#)

Visual Basic for Applications (VBA) Syntax

See [Curve::IReverseCurve](#).

Remarks

If this is a trimmed curve, then the underlying curve is reversed and a new trimmed curve is made from the reversed curve. This method returns the new trimmed curve.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::ReverseCurve Method](#)
[ICurve::IsTrimmedCurve Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsBcurve Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IsBcurve Method (ICurve)

Gets whether the curve is a b-spline curve.

.NET Syntax

Visual Basic (Declaration)

```
Function IsBcurve() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim value As System.Boolean  
  
value = instance.IsBcurve()
```

C#

```
System.bool IsBcurve()
```

C++/CLI

```
System.bool IsBcurve();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if curve is a b-spline curve, false if other curve type

Visual Basic for Applications (VBA) Syntax

See [Curve::IsBcurve](#).

Remarks

This method returns True if the curve is an intersection curve, ellipse, trimming curve, or a surface parametric curve. Because intersection and trimming curves can be lines or circles, it is advisable to first determine whether the curve is a circle or line before recognizing it as a b-curve.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::GetBCurveParams Method](#)
[ICurve::GetSplinePts Method](#)
[ICurve::Identity Method](#)
[ICurve::!GetBCurveParams Method](#)
[ICurve::!GetCurveParamsSize2 Method](#)
[ICurve::!GetSplinePts Method](#)
[ICurve::!GetSplinePtsSize Method](#)
[ICurve::IsBcurve Method](#)
[ICurve::MakeBSplineCurve Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsCircle Method (ICurve)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IsCircle Method (ICurve)

Gets whether the curve is a circle.

.NET Syntax

Visual Basic (Declaration)

```
Function IsCircle() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim value As System.Boolean  
  
value = instance.IsCircle()
```

C#

```
System.bool IsCircle()
```

C++/CLI

```
System.bool IsCircle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the curve is a circle, false if other curve type

Visual Basic for Applications (VBA) Syntax

See [Curve.IsCircle](#).

Example

[Get Circular Holes in Face \(C++\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

Remarks

Use [IEdge::GetCurveParams2](#) or [IEdge::!GetCurveParams2](#) to determine if a circular edge is a complete circle or an arc.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::CircleParams Property](#)
[ICurve::ICircleParams Property](#)
[ICurve::Identity Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsEllipse Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IsEllipse Method (ICurve)

Gets whether the curve is an ellipse.

.NET Syntax

Visual Basic (Declaration)

```
Function IsEllipse() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim value As System.Boolean  
  
value = instance.IsEllipse()
```

C#

```
System.bool IsEllipse()
```

C++/CLI

```
System.bool IsEllipse();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if curve is an ellipse, false if other curve type

Visual Basic for Applications (VBA) Syntax

See [Curve::IsEllipse](#).

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::GetEllipseParams Method](#)
[ICurve::ICGetEllipseParams Method](#)
[ICurve::IsBcurve Method](#)
[ICurve::Identity Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1999042

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsLine Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IsLine Method (ICurve)

Gets whether the curve is a line.

.NET Syntax

Visual Basic (Declaration)

```
Function IsLine() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICurve
Dim value As System.Boolean

value = instance.IsLine()
```

C#

```
System.bool IsLine()
```

C++/CLI

```
System.bool IsLine();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this curve is a line, false if other curve type

Visual Basic for Applications (VBA) Syntax

See [Curve::IsLine](#).

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::LineParams Property](#)
[ICurve::LineParams Property](#)
[ICurve::Identity Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsTrimmedCurve Method (ICurve)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : IsTrimmedCurve Method (ICurve)

Gets whether the curve is trimmed.

.NET Syntax

Visual Basic (Declaration)

```
Function IsTrimmedCurve() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICurve
Dim value As System.Boolean

value = instance.IsTrimmedCurve()
```

C#

```
System.bool IsTrimmedCurve()
```

C++/CLI

```
System.bool IsTrimmedCurve();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this curve is a trimmed curve, false if other curve type

Visual Basic for Applications (VBA) Syntax

See [Curve::IsTrimmedCurve](#).

Example

[Create Space Parameter Curve on Surface \(VBA\)](#)
[Get Intersecting Faces \(VBA\)](#)
[Get Sketch Segment and Curve Data \(VBA\)](#)
[Get Whether Sketch Segment is Trimmed \(VBA\)](#)

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::IsBcurve Method](#)
[ICurve::CreateTrimmedCurve2 Method](#)
[ICurve::Identity Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

JoinCurves Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : JoinCurves Method (ICurve)

Joins the specified curves.

.NET Syntax

Visual Basic (Declaration)

```
Function JoinCurves( _  
    ByVal Curves As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim Curves As System.Object  
Dim value As System.Object  
  
value = instance.JoinCurves(Curves)
```

C#

```
System.object JoinCurves(  
    System.object Curves  
)
```

C++/CLI

```
System.Object^ JoinCurves(  
& System.Object^ Curves  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Curves
Curves to join

Return Value

Newly created joined curve

Visual Basic for Applications (VBA) Syntax

See [Curve::JoinCurves](#).

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::IJoinCurves Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LineParams Property (ICurve)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : LineParams Property (ICurve)

Gets the parameters of a curve that is a line.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property LineParams As System.Object

Visual Basic (Usage)



```
Dim instance As ICurve
Dim value As System.Object

value = instance.LineParams
```

C#

```
System.Object LineParams {get;}
```

C++/CLI

```
property System.Object^ LineParams {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Curve::LineParams](#).

Example

[Get Angle Between Plane and Line \(VBA\)](#)
[Get Line Parameters \(VBA\)](#)

Remarks

The return value is an array of 6 double values:

[*rootPoint.x*, *rootPoint.y*, *rootPoint.z*, *direction.x*, *direction.y*, *direction.z*]

SOLIDWORKS stores *rootPoint* in meters.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::ILineParams Property](#)
[ICurve::ISLine Method](#)
[ICurve::Identity Method](#)

MakeBsplineCurve Method (ICurve)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : MakeBsplineCurve Method (ICurve)

Obsolete. Superseded by [ICurve::MakeBsplineCurve2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function MakeBsplineCurve() As Curve
```

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim value As Curve
```

```
value = instance.MakeBsplineCurve()
```

C#

```
Curve MakeBsplineCurve()
```

C++/CLI

```
Curve^ MakeBsplineCurve();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [arc or line](#)

Visual Basic for Applications (VBA) Syntax

See [Curve::MakeBsplineCurve](#).

Remarks

To convert the arc or line to a b-spline curve, use any of these methods:

- [ICurve::ConvertArcToBcurve](#)
- [ICurve::ConvertLineToBcurve](#)
- [ICurve::GetBCurveParams](#) or [ICurve::IGetBCurveParmas](#)

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::IsBcurve Method](#)
[ICurve::SimplifyBCurve Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

MakeBsplineCurve2 Method (ICurve)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : MakeBsplineCurve2 Method (ICurve)

Creates a b-spline curve.

.NET Syntax

Visual Basic (Declaration)

Function MakeBsplineCurve2() As Curve

Visual Basic (Usage)



```
Dim instance As ICurve  
Dim value As Curve  
  
value = instance.MakeBsplineCurve2()
```

C#

```
Curve MakeBsplineCurve2()
```

C++/CLI

```
Curve^ MakeBsplineCurve2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

B-spline [curve](#)

Visual Basic for Applications (VBA) Syntax

See [Curve::MakeBsplineCurve2](#).

Remarks

This method uses the input curve as it is and allows lines and arcs.

To convert the arc or line to a b-spline, use any of these methods:

- [ICurve::ConvertArcToBcurve](#)
- [ICurve::ConvertLineToBcurve](#)
- [ICurve::GetBCurveParams3](#) and [ICurve::!GetBCurveParams3](#)

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::CreateTrimmedCurve2 Method](#)
[ICurve::ExtentCurve Method](#)
[ICurve::!ConvertPcurveToBcurveSize Method](#)
[ICurve::!JoinCurves Method](#)
[ICurve::JoinCurves Method](#)
[ICurve::!ReverseCurve Method](#)
[ICurve::ReverseCurve Method](#)
[ICurve::SimplifyBCurve Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseCurve Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : ReverseCurve Method (ICurve)

Gets the reversed copy of this curve.

.NET Syntax

Visual Basic (Declaration)

```
Function ReverseCurve() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICurve
Dim value As System.Object

value = instance.ReverseCurve()
```

C#

```
System.object ReverseCurve()
```

C++/CLI

```
System.Object^ ReverseCurve();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Reversed curve

Visual Basic for Applications (VBA) Syntax

See [Curve::ReverseCurve](#).

Remarks

If this is a trimmed curve, then the underlying curve is reversed and a new trimmed curve is made from the reversed curve. This method returns the new trimmed curve.

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::ReverseCurve Method](#)
[ICurve::IsTrimmedCurve Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseEvaluate Method (ICurve)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : ReverseEvaluate Method (ICurve)

Gets the U parameter for the given XYZ location on this curve.

.NET Syntax

Visual Basic (Declaration)

```
Function ReverseEvaluate( _
    ByVal PositionX As System.Double, _
    ByVal PositionY As System.Double, _
    ByVal PositionZ As System.Double _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICurve
Dim PositionX As System.Double
Dim PositionY As System.Double
Dim PositionZ As System.Double
Dim value As System.Double

value = instance.ReverseEvaluate(PositionX, PositionY, PositionZ)
```

C#

```
System.double ReverseEvaluate(
    System.double PositionX,
    System.double PositionY,
```

```
System.double PositionZ
)
```

C++/CLI

```
System.double ReverseEvaluate(
& System.double PositionX,
& System.double PositionY,
& System.double PositionZ
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PositionX
X coordinate of this location on the curve
PositionY
Y coordinate of this location on the curve
PositionZ
Z coordinate of this location on the curve

Return Value

U parameter value for this location on the curve

Visual Basic for Applications (VBA) Syntax

See [Curve::ReverseEvaluate](#).

Example

[Get UV Parameters for XYZ Location \(VBA\)](#)
[Get UV Parameters for XYZ Location \(VB.NET\)](#)
[Get UV Parameters for XYZ Location \(C#\)](#)

See Also

[ICurve Interface](#)
[ICurve Members](#)
[IFace2::ReverseEvaluate Method](#)
[IFace2::!ReverseEvaluate Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SimplifyBCurve Method (ICurve)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurve Interface](#) : SimplifyBCurve Method (ICurve)

Simplifies a b-curve.

.NET Syntax

Visual Basic (Declaration)

```
Function SimplifyBCurve( _
    ByVal TolIn As System.Double _
) As Curve
```

Visual Basic (Usage)

```
Dim instance As ICurve
Dim TolIn As System.Double
Dim value As Curve

value = instance.SimplifyBCurve(TolIn)
```

C#



Copy Code

```
Curve SimplifyBCurve(  
    System.double TolIn  
)
```

C++/CLI

```
Curve^ SimplifyBCurve(  
&    System.double TolIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TolIn
Tolerance

Return Value

Pointer to simplified [b-curve](#)

Visual Basic for Applications (VBA) Syntax

See [Curve::SimplifyBCurve](#).

See Also

[ICurve Interface](#)
[ICurve Members](#)
[ICurve::ConvertArcToBcurve Method](#)
[ICurve::ConvertLineToBcurve Method](#)
[ICurve::ExtentCurve Method](#)
[ICurve::GetBCurveParams Method](#)
[ICurve::IConvertArcToBcurveSize Method](#)
[ICurve::IConvertLineToBcurveSize Method](#)
[ICurve::IConvertPcurveToBcurveSize Method](#)
[ICurve::IGetBCurveParams Method](#)
[ICurve::IGetBCurveParamsSize2 Method](#)
[ICurve::IsBcurve Method](#)

Availability

SOLIDWORKS 2006 FCS, revision Number 14.0