

SOLIDWORKS API (.NET VBA C#) — Reference

(109/337): IFamilyTableFeature-IFeatMgrView

SOLIDWORKS API Documentation (converted from CHM)

IFamilyTableFeature (Type)

IFamilyTableFeature Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFamilyTableFeature Interface

Allows access to the family table feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFamilyTableFeature
```

Visual Basic (Usage)

```
Dim instance As IFamilyTableFeature
```

C#

```
public interface IFamilyTableFeature
```

C++/CLI

```
public interface class IFamilyTableFeature
```

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature](#).

Remarks

Family tables display the variations in part and assembly configurations or custom properties in table format.

For more information about family tables, see the **SOLIDWORKS Design user-interface Help > Detailing and Drawings > Tables > Family Tables** topics.

Accessors

[IFamilyTableAnnotation::FamilyTableFeature](#)

Access Diagram

[FamilyTableFeature](#)

See Also

[IFamilyTableFeature Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IFamilyTableFeature Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFamilyTableFeature Interface

The following tables list the members exposed by [IFamilyTableFeature](#).

Public Methods

Name	Description
 GetConfigurations	Gets the configurations to use based on the specified criteria.
GetFeature	Gets the parent feature of this family table feature.

		
	GetFollowConfigTreeOrder	Gets whether the configuration tree order is used in this family table feature.
	GetModelName	Gets the name of the part or assembly whose drawing contains this family table.
	GetSequenceNumberIncrement	Gets the number with which to increment the family table items.
	GetSequenceStartNumber	Gets the item start number for this family table feature.
	GetTableAnnotationCount	Gets the number of table annotations for this family table feature.
	GetTableAnnotations	Gets the annotations for this family table feature.
	GetUseAllConfigurations	Gets whether all configurations are used in this family table feature.
	SetConfigurations	Sets the configurations to use for this family table feature.
	SetFollowConfigTreeOrder	Sets whether the configuration tree order is used in this family table feature.
	SetSequenceNumberIncrement	Sets the number with which to increment the family table items.
	SetSequenceStartNumber	Sets the item start number for this family table feature.
	SetUseAllConfigurations	Sets whether to use all configurations in this family table feature.

[Top](#)

See Also

[IFamilyTableFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IFamilyTableFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFamilyTableFeature Interface

For a list of all members of this type, see [IFamilyTableFeature members](#).

Public Methods

Name	Description
 GetConfigurations	Gets the configurations to use based on the specified criteria.
 GetFeature	Gets the parent feature of this family table feature.
 GetFollowConfigTreeOrder	Gets whether the configuration tree order is used in this family table feature.
 GetModelName	Gets the name of the part or assembly whose drawing contains this family table.
 GetSequenceNumberIncrement	Gets the number with which to increment the family table items.
 GetSequenceStartNumber	Gets the item start number for this family table feature.
 GetTableAnnotationCount	Gets the number of table annotations for this family table feature.
 GetTableAnnotations	Gets the annotations for this family table feature.
 GetUseAllConfigurations	Gets whether all configurations are used in this family table feature.
 SetConfigurations	Sets the configurations to use for this family table feature.
 SetFollowConfigTreeOrder	Sets whether the configuration tree order is used in this family table feature.
 SetSequenceNumberIncrement	Sets the number with which to increment the family table items.
 SetSequenceStartNumber	Sets the item start number for this family table feature.
 SetUseAllConfigurations	Sets whether to use all configurations in this family table feature.

[Top](#)

See Also

[IFamilyTableFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConfigurations Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : GetConfigurations Method (IFamilyTableFeature)

Gets the configurations to use based on the specified criteria.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurations( _  
    ByVal Criteria As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim Criteria As System.Integer  
Dim value As System.Object  
  
value = instance.GetConfigurations(Criteria)
```

C#

```
System.object GetConfigurations(  
    System.int Criteria  
)
```

C++/CLI

```
System.Object^ GetConfigurations(  
& System.int Criteria  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Criteria
Criteria as defined by [swFamilyTableGetConfigurationCriteria_e](#)

Return Value

Array of configurations

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::GetConfigurations](#).

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : GetFeature Method (IFamilyTableFeature)

Gets the parent feature of this family table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim value As System.Object
```

```
value = instance.GetFeature()
```

C#

```
System.object GetFeature()
```

C++/CLI

```
System.Object^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::GetFeature](#).

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFollowConfigTreeOrder Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : GetFollowConfigTreeOrder Method (IFamilyTableFeature)

Gets whether the configuration tree order is used in this family table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFollowConfigTreeOrder() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim value As System.Boolean
```

```
value = instance.GetFollowConfigTreeOrder()
```

C#

```
System.bool GetFollowConfigTreeOrder()
```

C++/CLI

```
System.bool GetFollowConfigTreeOrder();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if uses the configuration tree order, false if not

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::GetFollowConfigTreeOrder](#).

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetModelName Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : GetModelName Method (IFamilyTableFeature)

Gets the name of the part or assembly whose drawing contains this family table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetModelName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim value As System.String  
  
value = instance.GetModelName()
```

C#

```
System.string GetModelName()
```

C++/CLI

```
System.String^ GetModelName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of part or assembly

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::GetModelName](#).

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSequenceNumberIncrement Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : GetSequenceNumberIncrement Method (IFamilyTableFeature)

Gets the number with which to increment the family table items.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSequenceNumberIncrement() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim value As System.Integer  
  
value = instance.GetSequenceNumberIncrement()
```

C#

```
System.int GetSequenceNumberIncrement()
```

C++/CLI

```
System.int GetSequenceNumberIncrement();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Item increment number

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::GetSequenceNumberIncrement](#).

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSequenceStartNumber Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : GetSequenceStartNumber Method (IFamilyTableFeature)

Gets the item start number for this family table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSequenceStartNumber() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim value As System.Integer  
  
value = instance.GetSequenceStartNumber()
```

C#

```
System.int GetSequenceStartNumber()
```

C++/CLI

```
System.int GetSequenceStartNumber();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Table item start number

 Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::GetSequenceStartNumber](#).

 See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

 Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotationCount Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : GetTableAnnotationCount Method (IFamilyTableFeature)

Gets the number of table annotations for this family table feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim value As System.Integer  
  
value = instance.GetTableAnnotationCount()
```

C#

```
System.int GetTableAnnotationCount()
```

C++/CLI

```
System.int GetTableAnnotationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of table annotations

 Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::GetTableAnnotationCount](#).

 See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

 Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotations Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : GetTableAnnotations Method (IFamilyTableFeature)

Gets the annotations for this family table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim value As System.Object  
  
value = instance.GetTableAnnotations()
```

C#

```
System.object GetTableAnnotations()
```

C++/CLI

```
System.Object^ GetTableAnnotations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IFamilyTableAnnotations](#)

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::GetTableAnnotations](#).

Remarks

Use [IFamilyTableFeature::GetTableAnnotationCount](#) to determine the size of the array returned by this method.

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUseAllConfigurations Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : GetUseAllConfigurations Method (IFamilyTableFeature)

Gets whether all configurations are used in this family table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseAllConfigurations() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim value As System.Boolean
```

```
value = instance.GetUseAllConfigurations()
```

C#

```
System.bool GetUseAllConfigurations()
```

C++/CLI

```
System.bool GetUseAllConfigurations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if all configurations are used, false if only some are used.

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::GetUseAllConfigurations](#).

Remarks

Use [IFamilyTableFeature::GetConfigurations](#) to obtain the configurations used in this feature.

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetConfigurations Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : SetConfigurations Method (IFamilyTableFeature)

Sets the configurations to use for this family table feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetConfigurations( _  
    ByVal ConfigArray As System.Object, _  
    ByVal VisibilityArray As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim ConfigArray As System.Object  
Dim VisibilityArray As System.Object
```

```
instance.SetConfigurations(ConfigArray, VisibilityArray)
```

C#

```
void SetConfigurations(  
    System.object ConfigArray,  
    System.object VisibilityArray  
)
```

C++/CLI

```
void SetConfigurations(
& System.Object^ ConfigArray,
& System.Object^ VisibilityArray
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigArray

Array of configurations

VisibilityArray

Array of booleans indicating visibility, in order, of ConfigArray items; null or Nothing to indicate that all configurations are visible

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::SetConfigurations](#).

Remarks

This method is valid only if [IFamilyTableFeature::GetUseAllConfigurations](#) is set to false.

See Also

[IFamilyTableFeature Interface](#)

[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFollowConfigTreeOrder Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : SetFollowConfigTreeOrder Method (IFamilyTableFeature)

Sets whether the configuration tree order is used in this family table feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFollowConfigTreeOrder( _
    ByVal Flag As System.Boolean _
)
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature
```

```
Dim Flag As System.Boolean
```

```
instance.SetFollowConfigTreeOrder(Flag)
```

C#

```
void SetFollowConfigTreeOrder(
    System.bool Flag
)
```

C++/CLI

```
void SetFollowConfigTreeOrder(
& System.bool Flag
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Flag
True if the configuration tree order is used, false if not

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::SetFollowConfigTreeOrder](#).

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSequenceNumberIncrement Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : SetSequenceNumberIncrement Method (IFamilyTableFeature)

Sets the number with which to increment the family table items.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetSequenceNumberIncrement( _  
    ByVal Increment As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim Increment As System.Integer  
  
instance.SetSequenceNumberIncrement(Increment)
```

C#

```
void SetSequenceNumberIncrement(  
    System.int Increment  
)
```

C++/CLI

```
void SetSequenceNumberIncrement(  
& System.int Increment  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Increment
Item increment number

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::SetSequenceNumberIncrement](#).

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SetSequenceStartNumber Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : SetSequenceStartNumber Method (IFamilyTableFeature)

Sets the item start number for this family table feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetSequenceStartNumber( _  
    ByVal Start As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim Start As System.Integer  
  
instance.SetSequenceStartNumber(Start)
```

C#

```
void SetSequenceStartNumber(  
    System.int Start  
)
```

C++/CLI

```
void SetSequenceStartNumber(  
    & System.int Start  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Start
Item start number

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::SetSequenceStartNumber](#).

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

SetUseAllConfigurations Method (IFamilyTableFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFamilyTableFeature Interface](#) : SetUseAllConfigurations Method (IFamilyTableFeature)

Sets whether to use all configurations in this family table feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetUseAllConfigurations( _  
    ByVal UseAllConfigs As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IFamilyTableFeature  
Dim UseAllConfigs As System.Boolean  
  
instance.SetUseAllConfigurations(UseAllConfigs)
```

C#

```
void SetUseAllConfigurations(  
    System.bool UseAllConfigs  
)
```

C++/CLI

```
void SetUseAllConfigurations(  
& System.bool UseAllConfigs  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseAllConfigs
True to use all configurations, false to not

Visual Basic for Applications (VBA) Syntax

See [FamilyTableFeature::SetUseAllConfigurations](#).

See Also

[IFamilyTableFeature Interface](#)
[IFamilyTableFeature Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

IFaultEntity (Type)

IFaultEntity Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFaultEntity Interface

Identifies entities with faults and types of faults.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)
Public Interface IFaultEntity
Visual Basic (Usage)
Dim instance As IFaultEntity
C#
public interface IFaultEntity
C++/CLI
public interface class IFaultEntity

Visual Basic for Applications (VBA) Syntax

See [FaultEntity](#).

Example

[Check Bodies for Faults \(VBA\)](#)
[Get and Fill Gaps in Body \(C#\)](#)
[Get and Fill Gaps in Body \(VB.NET\)](#)
[Get and Fill Gaps in Body \(VBA\)](#)

Accessors

[IBody2::Check3](#)
[IEdge::Check](#)
[IFace2::Check](#)

Access Diagram

[FaultEntity](#)

See Also

[IFaultEntity Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IFaultEntity Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFaultEntity Interface

The following tables list the members exposed by [IFaultEntity](#).

Public Properties

Name	Description
------	-------------

 Count	Gets the number of faults that the entity has.
 Entity	Obsolete. Superseded by IFaultEntity.Entity2 .
 Entity2	Gets the specified entity.
 ErrorCode	Gets the error for the fault for the specified entity.

[Top](#)

 See Also

[IFaultEntity Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IFaultEntity Interface Properties

[See Also](#)

	
SolidWorks.Interop.sldworks Namespace	: IFaultEntity Interface

For a list of all members of this type, see [IFaultEntity members](#).

 Public Properties

Name	Description
 Count	Gets the number of faults that the entity has.
 Entity	Obsolete. Superseded by IFaultEntity.Entity2 .
 Entity2	Gets the specified entity.
 ErrorCode	Gets the error for the fault for the specified entity.

[Top](#)

 See Also

[IFaultEntity Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

Count Property (IFaultEntity)

[See Also](#) [Example](#)

 	
SolidWorks.Interop.sldworks Namespace	> IFaultEntity Interface : Count Property (IFaultEntity)

Gets the number of faults that the entity has.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property Count As System.Integer

Visual Basic (Usage)



```
Dim instance As IFaultEntity
Dim value As System.Integer

value = instance.Count
```

C#

```
System.int Count {get;}
```

C++/CLI

```
property System.int Count {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of faults

Visual Basic for Applications (VBA) Syntax

See [FaultEntity.Count](#).

Example

[Check Edges for Faults \(VBA\)](#)
[Check Faces for Faults \(VBA\)](#)
[Get and Fill Gaps in Body \(C#\)](#)
[Get and Fill Gaps in Body \(VB.NET\)](#)
[Get and Fill Gaps in Body \(VBA\)](#)

Remarks

The return value has a 0-based index.

Call this property before calling [IFaultEntity.Entity2](#) and [IFaultEntity.ErrorCode](#).

See Also

[IFaultEntity Interface](#)
[IFaultEntity Members](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

SOLIDWORKS API Help

[Send comments](#) on this topic.

Entity Property (IFaultEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaultEntity Interface](#) : Entity Property (IFaultEntity)

Obsolete. Superseded by [IFaultEntity.Entity2](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Entity( _  
    ByVal Index As System.Integer _  
) As Entity
```

Visual Basic (Usage)



```
Dim instance As IFaultEntity  
Dim Index As System.Integer  
Dim value As Entity
```

```
value = instance.Entity(Index)
```

C#

```
Entity Entity(  
    System.int Index  
) {get;}
```

C++/CLI

```
property Entity^ Entity {  
    Entity^ get(System.int Index);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [FaultEntity.Entity](#).

See Also

[IFaultEntity Interface](#)
[IFaultEntity Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Entity2 Property (IFaultEntity)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaultEntity Interface](#) : Entity2 Property (IFaultEntity)

Gets the specified entity.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Entity2( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFaultEntity  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.Entity2(Index)
```

C#

```
System.object Entity2(  
    System.int Index  
) {get;}
```

C++/CLI

```
property System.Object^ Entity2 {  
    System.Object^ get(System.int Index);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
0-based index number indicating the entity to get

Property Value

Entity at Index or NULL if the object at Index is not an entity

Visual Basic for Applications (VBA) Syntax

See [FaultEntity.Entity2](#).

Remarks

To determine the value for Index, call [IFaultEntity::Count](#) before calling this property. Call [IFaultEntity::ErrorCode](#) to determine the error code.

This method might return NULL if the entity is absorbed by the fault.

See Also

Availability

SOLIDWORKS 2007 SP2, Revision Number 15.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

ErrorCode Property (IFaultEntity)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFaultEntity Interface](#) : ErrorCode Property (IFaultEntity)

Gets the error for the fault for the specified entity.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ErrorCode( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFaultEntity  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.ErrorCode(Index)
```

C#

```
System.int ErrorCode(  
    System.int Index  
) {get;}
```

C++/CLI

```
property System.int ErrorCode {  
    System.int get(System.int Index);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index number indicating the entity with the fault

Property Value

Error as defined by [swFaultEntityErrorCode_e](#); -1 indicates an unknown error

Visual Basic for Applications (VBA) Syntax

See [FaultEntity.ErrorCode](#).

Example

[Check Bodies for Faults \(VBA\)](#)
[Check Faces for Faults \(VBA\)](#)
[Check Edges for Faults \(C#\)](#)
[Check Edges for Faults \(VB.NET\)](#)
[Check Edges for Faults \(VBA\)](#)

Remarks

To determine the value for index, call [IFaultEntity::Count](#) before calling this property. Call [IFaultEntity::Entity2](#) to get the entity.

See Also

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

IFeatMgrView (Type)

IFeatMgrView Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IFeatMgrView Interface

Allows access to a view (tab) in the FeatureManager design tree.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IFeatMgrView
```

Visual Basic (Usage)



```
Dim instance As IFeatMgrView
```

C#

```
public interface IFeatMgrView
```

C++/CLI

```
public interface class IFeatMgrView
```

Visual Basic for Applications (VBA) Syntax

See [FeatMgrView](#).

Example

[Add ActiveX Tab to FeatureManager Design Tree \(C#\)](#)
[Add ActiveX Tab to FeatureManager Design Tree \(VB.NET\)](#)
[Add ActiveX Tab to FeatureManager Design Tree \(VBA\)](#)
[Add .NET Controls to SOLIDWORKS using an Add-in \(C#\)](#)
[Add .NET Controls to SOLIDWORKS using an Add-in \(VB.NET\)](#)

Remarks

Events are implemented with delegates in the Microsoft .NET Framework. See the [Overview](#) topic for a list of delegates for this interface.

Accessors

[IModelViewManager::CreateFeatureMgrControl](#)
[IModelViewManager::CreateFeatureMgrControl2](#)
[IModelViewManager::CreateFeatureMgrControl3](#)
[IModelViewManager::CreateFeatureMgrView2](#)

Access Diagram

[FeatMgrView](#)

See Also

[IFeatMgrView Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IFeatMgrView Interface Members

[See Also](#) [Methods](#)



The following tables list the members exposed by [IFeatMgrView](#).

Public Methods	
Name	Description
 ActivateView	Activates this view in the FeatureManager design tree.
 DeActivateView	Deactivates this view in the FeatureManager design tree.
 DeleteView	Removes this view from the FeatureManager design tree.
 GetControl	Gets the control associated with this FeatureManager design tree view.
 GetFeatMgrViewWnd	Obsolete. Superseded by IFeatMgrView::GetFeatMgrViewWndx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Gets the FeatureManager design tree view window handle as a CWnd object.
 GetFeatMgrViewWndx64	Gets the FeatureManager design tree view window handle as a CWnd object in 64-bit applications.
 IGetControl	Gets the control associated with this FeatureManager design tree view.

[Top](#)

See Also

[IFeatMgrView Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IFeatMgrView Interface Methods

[See Also](#)

Public Methods	
Name	Description
 ActivateView	Activates this view in the FeatureManager design tree.
 DeActivateView	Deactivates this view in the FeatureManager design tree.
 DeleteView	Removes this view from the FeatureManager design tree.
 GetControl	Gets the control associated with this FeatureManager design tree view.
 GetFeatMgrViewWnd	Obsolete. Superseded by IFeatMgrView::GetFeatMgrViewWndx64. This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016. The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used. Gets the FeatureManager design tree view window handle as a CWnd object.
 GetFeatMgrViewWndx64	Gets the FeatureManager design tree view window handle as a CWnd object in 64-bit applications.
 IGetControl	Gets the control associated with this FeatureManager design tree view.

[Top](#)

See Also

[IFeatMgrView Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

ActivateView Method (IFeatMgrView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatMgrView Interface](#) : ActivateView Method (IFeatMgrView)

Activates this view in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function ActivateView() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeatMgrView
Dim value As System.Integer

value = instance.ActivateView()
```

C#

```
System.int ActivateView()
```

C++/CLI

```
System.int ActivateView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pane on which to activate this tab as defined in [swFeatMgrPane_e](#)

Visual Basic for Applications (VBA) Syntax

See [FeatMgrView::ActivateView](#).

Example

This method is valid only for x86 systems.

Example

[Add ActiveX Tabs to FeatureManager Design Tree \(C#\)](#)
[Add ActiveX Tabs to FeatureManager Design Tree \(VB.NET\)](#)
[Add ActiveX Tabs to FeatureManager Design Tree \(VBA\)](#)
[Add .NET Controls to SOLIDWORKS Using an Add-in \(C#\)](#)
[Add .NET Controls to SOLIDWORKS using an Add-in \(VB.NET\)](#)

See Also

[IFeatMgrView Interface](#)
[IFeatMgrView Members](#)
[IFeatMgrView::DeActivateView Method](#)
[IFeatMgrView::DeleteView Method](#)
[IModelViewManager::AddControl Method](#)
[IModelViewManager::AddControl3 Method](#)
[IModelViewManager::CreateFeatureMgrControl2 Method](#)
[IModelViewManager::CreateFeatureMgrControl3 Method](#)
[IModelDocExtension::ActivateFeatureMgrViewx64 Method \(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeActivateView Method (IFeatMgrView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatMgrView Interface](#) : DeActivateView Method (IFeatMgrView)

Deactivates this view in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function DeActivateView() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeatMgrView  
Dim value As System.Boolean  
  
value = instance.DeActivateView()
```

C#

```
System.bool DeActivateView()
```

C++/CLI

```
System.bool DeActivateView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the tab is deactivated, false if not

Visual Basic for Applications (VBA) Syntax

See [FeatMgrView::DeActivateView](#).

See Also

[IFeatMgrView Interface](#)
[IFeatMgrView Members](#)
[IFeatMgrView::ActivateView Method](#)
[IFeatMgrView::DeleteView Method](#)
[IModelDocExtension::DeActivateFeatureMgrViewx64 Method \(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteView Method (IFeatMgrView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatMgrView Interface](#) : DeleteView Method (IFeatMgrView)

Removes this view from the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteView() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IFeatMgrView  
Dim value As System.Boolean  
  
value = instance.DeleteView()
```

C#

```
System.bool DeleteView()
```

C++/CLI

```
System.bool DeleteView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the tab is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [FeatMgrView::DeleteView](#).

Remarks

Use this method to delete a tab created by [IModelViewManager::AddControl](#).

See Also

[IFeatMgrView Interface](#)
[IFeatMgrView Members](#)
[IFeatMgrView::ActivateView Method](#)
[IFeatMgrView::DeActivateView Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetControl Method (IFeatMgrView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatMgrView Interface](#) : GetControl Method (IFeatMgrView)

Gets the control associated with this FeatureManager design tree view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetControl() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeatMgrView  
Dim value As System.Object
```

```
value = instance.GetControl()
```

C#

```
System.object GetControl()
```

C++/CLI

```
System.Object^ GetControl();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Control object

Visual Basic for Applications (VBA) Syntax

See [FeatMgrView::GetControl](#).

Example

[Add ActiveX Tabs to FeatureManager Design Tree \(C#\)](#)
[Add ActiveX Tabs to FeatureManager Design Tree \(VB.NET\)](#)
[Add ActiveX Tabs to FeatureManager Design Tree \(VBA\)](#)

See Also

[IFeatMgrView Interface](#)
[IFeatMgrView Members](#)
[IFeatMgrView::IGetControl Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeatMgrViewWnd Method (IFeatMgrView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatMgrView Interface](#) : GetFeatMgrViewWnd Method (IFeatMgrView)

Obsolete. Superseded by [IFeatMgrView::GetFeatMgrViewWndx64](#).

This method is unsafe to use with 64-bit SOLIDWORKS, i.e. all versions since SOLIDWORKS 2016.

The 32-bit integer returned may be too small to contain the 64-bit window handle/pointer, and will be truncated silently. A critical exception will occur sometime later, when the truncated handle/pointer is used.

Gets the FeatureManager design tree view window handle as a CWnd object.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatMgrViewWnd() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IFeatMgrView
Dim value As System.Integer

value = instance.GetFeatMgrViewWnd()
```

C#

```
System.int GetFeatMgrViewWnd()
```

C++/CLI

```
System.int GetFeatMgrViewWnd();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

CWnd handle of the FeatureManager design tree view

Visual Basic for Applications (VBA) Syntax

See [FeatMgrView::GetFeatMgrViewWnd](#).

Remarks

If your application must be x64 compatible, then use [IFeatMgrView::GetFeatMgrViewWndx64](#).

You can use this CWnd in combination with standard MFC calls to draw into this view.

Call this method when the FeatureManager design tree is created with [IModelViewManager::CreateFeatureMgrView2](#). You do not need to call this method with [IModelDoc2::AddFeatureMgrView3](#), because you created the view and already have its handle.

See Also

GetFeatMgrViewWndx64 Method (IFeatMgrView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatMgrView Interface](#) : GetFeatMgrViewWndx64 Method (IFeatMgrView)

Gets the FeatureManager design tree view window handle as a CWnd object in 64-bit applications.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatMgrViewWndx64() As System.Long
```

Visual Basic (Usage)



```
Dim instance As IFeatMgrView
Dim value As System.Long

value = instance.GetFeatMgrViewWndx64()
```

C#

```
System.long GetFeatMgrViewWndx64()
```

C++/CLI

```
System.int64 GetFeatMgrViewWndx64();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Window handle for this FeatureManager design tree view

Visual Basic for Applications (VBA) Syntax

See [FeatMgrView::GetFeatMgrViewWndx64](#).

Remarks

This method is only available through early binding and with 64-bit versions of the SOLIDWORKS Design software.

See Also

[IFeatMgrView Interface](#)
[IFeatMgrView Members](#)
[IFeatMgrView::GetFeatMgrViewWnd Method](#)
[IModelViewManager::GetFeatureMgrViewHWndx64 Method](#)

Availability

SOLIDWORKS 2006 SP3, Revision Number 14.3

IGetControl Method (IFeatMgrView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IFeatMgrView Interface](#) : IGetControl Method (IFeatMgrView)

Gets the control associated with this FeatureManager design tree view.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetControl() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IFeatMgrView  
Dim value As System.Object  
  
value = instance.IGetControl()
```

C#

```
System.object IGetControl()
```

C++/CLI

```
System.Object^ IGetControl();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the associated control

Visual Basic for Applications (VBA) Syntax

See [FeatMgrView::IGetControl](#).

See Also

[IFeatMgrView Interface](#)
[IFeatMgrView Members](#)
[IFeatMgrView::GetControl Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0