

SOLIDWORKS API (.NET VBA C#) — Reference

(212/337): INote (part 1 of 3)

SOLIDWORKS API Documentation (converted from CHM)

I^{INote} (part 1 of 3) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

I^{INote} Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : I^{INote} Interface

Allows you to get standard note information.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface I^{INote}

Visual Basic (Usage)



Dim instance As [I^{INote}](#)

C#

public interface I^{INote}

C++/CLI

public interface class I^{INote}

Visual Basic for Applications (VBA) Syntax

See [Note](#).

Example

[Get Notes from New or Existing Title Block \(C#\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(VBA\)](#)
[Anchor a Note \(VBA\)](#)
[Anchor a Note \(VB.NET\)](#)
[Anchor a Note \(C#\)](#)

Remarks

Important: [Compound notes](#) are no longer creatable through the SOLIDWORKS Design user interface. As such, they are a legacy annotation type. SOLIDWORKS APIs that work on compound notes should only be used with legacy SOLIDWORKS files. [ISketchBlockDefinition](#) and [ISketchBlockInstance](#) can be used to mimic the functionality of compound notes. See [Block Definitions and Block Instances](#).

Accessors

[IAnnotation::GetSpecificAnnotation](#) and [IAnnotation::IGetSpecificAnnotation](#)
[IBalloonStack::AddTo](#)
[IBalloonStack::IGetStack](#)
[IBalloonStack::Master](#)
[IBalloonStack::Stack](#)
[ICThread::ThreadCallout](#)
[IDrawingDoc::AutoBalloon5](#)
[IDrawingDoc::CreateText2](#) and [IDrawingDoc::ICreateText2](#)
[IDrawingDoc::InsertRevisionSymbol](#)
[IFeatureManager::InsertSecurityNote](#)
[IModelDoc2::InsertNote](#) and [IModelDoc2::IInsertNote](#)
[IModelDocExtension::EditBalloonProperties2](#)
[IModelDocExtension::InsertBomBalloon2](#)

[IModelDocExtension::InsertStackedBalloon2](#)
[INote::GetNext](#) and [INote::!GetNext](#)
[IPartDoc::InsertBendNotes](#)
[IRevisionTableAnnotation::GetRevisionSymbols](#) and [RevisionTableAnnotation::!GetRevisionSymbols](#)
[ISketchBlockDefinition::GetNotes](#) and [ISketchBlockDefinition::!GetNotes](#)
[ISketchBlockInstance::GetAttributes](#) and [ISketchBlockInstance::!GetAttributes](#)
[IView::GetFirstNote](#) and [IView::!GetFirstNote](#)
[IView::GetNotes](#)

 Access Diagram

[Note](#)

 See Also

[INote Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertNewNote3 Method](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

INote Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : INote Interface

For a list of all members of this type, see [INote members](#).

 Public Methods

Name	Description
 AddText	Obsolete for documents created in SOLIDWORKS 2016 and later. Adds text to the selected compound note.
 BeginSketchEdit	Obsolete for documents created in SOLIDWORKS 2016 and later. Activates the sketch of the compound note.
 EndSketchEdit	Obsolete for documents created in SOLIDWORKS 2016 and later. Finishes accessing this compound note's sketch.
 GetAnnotation	Gets the annotation for this specific note.
 GetArcAtIndex	Gets information for the specified arc in this note.
 GetArcCount	Gets the number of arcs in the note.
 GetArrowHeadAtIndex	Gets information on the specified arrowhead in this note.
 GetArrowHeadCount	Gets the number of arrowheads in the note.
 GetArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
 GetAttachPos	Gets the attachment point of this note.
 GetBalloonInfo	Gets information describing the geometry of the balloon, if any, that encloses the note text.
 GetBalloonOptions	Gets the balloon options for this note.
 GetBalloonPadding	Gets the balloon padding of this note.
 GetBalloonSize	Gets the balloon size or fit of this note.
 GetBalloonStack	Gets the balloon stack for this balloon note.
 GetBalloonStyle	Gets the balloon style of this note.
 GetBendLineValues	Obsolete. Superseded by INote::GetBendLineValues2 .
 GetBendLineValues2	Gets the values of a bend line note.
 GetBomBalloonText	Gets the text for this BOM balloon note.
 GetBomBalloonTextStyle	Gets the text style of this BOM balloon note.
 GetCompoundTextAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the text item corresponding to the specified index from a compound note.
 GetCompoundTextCount	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the number of text items in a compound note.

	GetExtent	Gets the extents of a note in sheet space.
	GetExtentAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the extents of the specified piece of text within a compound note.
	GetFontInfo	Gets with the note's font information.
	GetHeight	Get the note's height.
	GetHeightAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the specified text item's height in a compound note.
	GetHeightInPoints	Gets the height of this note in points (for example, 8, 10, 12, and so on).
	GetHyperlinkText	Gets the hyperlink in a note.
	GetLeaderAtIndex	Gets information about the specified leader on this note.
	GetLeaderCount	Gets the number of leaders on this note.
	GetLeaderInfo	Gets information describing the layout of the note leader lines.
	GetLeaderNumPointsAt	Gets the number of points in the specified leader of this note.
	GetLineAtIndex	Gets information for the specified line.
	GetLineCount	Gets the number of line segments in this note.
	GetName	Gets the name of this note.
	GetNext	Gets the next note in drawing view .
	GetSketch	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the sketch for the current compound note.
	GetText	Gets this note's text.
	GetTextAngleAtIndex	Gets the text angle for the specified piece of text in this note.
	GetTextAtIndex	Gets the specified text in this note.
	GetTextCount	Gets the number of text items in this note.
	GetTextFontAtIndex	Gets the font used by the specified text item in this note.
	GetTextFormat	Obsolete. Superseded by IAnnotation::GetTextFormat and IAnnotation::IGetTextFormat.
	GetTextFormatAtIndex	Obsolete. Superseded by IAnnotation::GetTextFormat and IAnnotation::IGetTextFormat.
	GetTextHeightAtIndex	Gets the text height for the specified piece of text in this note.
	GetTextInvertAtIndex	Gets the specified text item's invert flag.
	GetTextJustification	Gets the text justification of a standard note.
	GetTextJustificationAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the text justification for the specified text item in a compound note.
	GetTextLineSpacingAtIndex	Gets the line spacing for this note.
	GetTextOffsetAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the text item's offset relative to note's text point in a compound note.
	GetTextPoint	Obsolete. Superseded by INote::GetTextPoint2 or INote::IGetTextPoint2.
	GetTextPoint2	Gets the note's text reference point (i.e., note origin).
	GetTextPositionAtIndex	Gets the text item's offset relative to the document origin.
	GetTextRefPositionAtIndex	Gets the specified text item's reference position in this note; for example, the upper left, lower left, or center.
	GetTextVerticalJustification	Gets the vertical justification of a standard note.
	GetTriangleAtIndex	Gets the triangle at the specified index.
	GetTriangleCount	Gets the number of triangles in this note.
	GetUpperRight	Gets the note's upper-right text point.
	GetUseDocTextFormat	Obsolete. Superseded by IAnnotation::GetUseDocTextFormat
	HasBalloon	Gets whether this note has a balloon.
	HasExtraLeader	Gets whether this note has a bent or straight leaderline.
	IGetAnnotation	Gets the annotation for this specific note.
	IGetArcAtIndex	Gets information for the specified arc in this note.
	IGetArrowHeadAtIndex	Gets information on the specified arrowhead in this note.

		
	IGetArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
	IGetAttachPos	Gets the attachment point of this note.
	IGetBalloonInfo	Gets information describing the geometry of the balloon, if any, that encloses the note text.
	IGetExtent	Gets the extents of a note in sheet space.
	IGetExtentAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the extents of the specified piece of text within a compound note.
	IGetFontInfo	Gets with the note's font information.
	IGetLeaderAtIndex	Gets information about the specified leader on this note.
	IGetLeaderInfo	Gets information describing the layout of the note leader lines.
	IGetLineAtIndex	Gets information for the specified line.
	IGetNext	Gets the next note in drawing view .
	IGetSketch	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the sketch for the current compound note.
	IGetTextFormat	Obsolete. Superseded by IAnnotation::GetTextFormat and IAnnotation::IGetTextFormat .
	IGetTextFormatAtIndex	Obsolete. Superseded by IAnnotation::GetTextFormat and IAnnotation::GetTextFormat .
	IGetTextOffsetAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets whether the text item's offset relative to note's text point in a compound note.
	IGetTextPoint	Obsolete. Superseded by INote::IGetTextPoint .
	IGetTextPoint2	Gets the note's text reference point (i.e., note origin).
	IGetTextPositionAtIndex	Gets the text item's offset relative to the document origin.
	IGetTriangleAtIndex	Gets the triangle at the specified index.
	IGetUpperRight	Gets the note's upper-right text point.
	IsAttached	Gets whether the note is attached.
	IsAttribute	Obsolete. Not superseded.
	IsBomBalloon	Gets whether this note has a BOM balloon.
	IsCompoundNote	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets whether the current note is a compound note.
	ISetTextFormat	Obsolete. Superseded by IAnnotation::SetTextFormat and IAnnotation::ISetTextFormat .
	ISetTextFormatAtIndex	Obsolete. Superseded by IAnnotation::SetTextFormat and IAnnotation::ISetTextFormat .
	IsStackedBalloon	Gets whether this note is part of a stacked balloon.
	IsStackedBalloonMaster	Gets whether this note is the master note of a balloon stack.
	MakeStackedBalloon	Converts this balloon to a stacked balloon.
	SetBalloon	Sets the balloon style, size, and fit for this note.
	SetBalloonPadding	Sets the padding for this balloon note.
	SetBomBalloonText	Sets the text for this BOM balloon note.
	SetHeight	Sets the height of this note in meters.
	SetHeightInPoints	Sets the height of this note in points (for example, 8, 10, 12, and so on).
	SetHyperlinkText	Sets the hyperlink in a note.
	SetName	Sets the name for this note.
	SetText	Sets the text of the note.
	SetTextAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Sets the text value at the specified index within the compound note.
	SetTextFormat	Obsolete. Superseded by IAnnotation::SetTextFormat and IAnnotation::ISetTextFormat .
	SetTextFormatAtIndex	Obsolete. Superseded by IAnnotation::SetTextFormat and IAnnotation::ISetTextFormat .
	SetTextJustification	Sets the text justification of a standard note.
	SetTextJustificationAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Sets the text justification for the specified text item in a compound note.
	SetTextOffsetAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Relocates the offset (origin) of the specified piece of text in a compound note.

		
	SetTextPoint	Relocates the note origin to the specified location.
	SetTextVerticalJustification	Sets the vertical justification of a standard note.
	SetZeroLengthLeader	Obsolete for documents created in SOLIDWORKS 2016 and later. Sets a 0-length leader for a compound note.

[Top](#)

See Also

[INote Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertNewNote3 Method](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

INote Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : INote Interface

The following tables list the members exposed by [INote](#).

Public Properties

Name	Description
 AllUpperCase	Gets or sets whether the text of this note is all uppercase.
 Angle	Controls the rotation angle of this note.
 BehindSheet	Places this note, located on the sheet format in a drawing, behind the drawing sheet.
 HasMultipleFonts	Gets whether a note contains multiple fonts.
 IncludeDimPrefixSuffixTolerance	Gets or sets whether to include the dimension prefix, suffix, and tolerance in this dimension note.
 IsBendLineNote	Gets whether this note is a bendline note.
 LockPosition	Gets and sets whether to anchor this note.
 PromptText	Gets and sets the message prompt text.
 PropertyLinkedText	Gets or sets the text for the note using the values of the properties linked to the note.
 ReadOnly	Gets or sets the read-only state of a note.
 TagName	Gets or sets the tag name for this note.
 TextRightToLeft	Gets or sets whether notes are displayed right to left.
 ToBoundingBox	Gets and sets whether to select the To bounding box option for leaders in this note's PropertyManager page.
 Visible	Gets and sets the visibility state of a note during the creation of a block.
 WatermarkBehindGeometry	Gets or sets whether to place this note, specified to be a watermark, behind the geometry in a part or assembly.
 WatermarkNote	Gets or sets whether the note is a watermark in a part or assembly.
 WatermarkTransparencyLevel	Gets or sets the transparency level of a note specified to be a watermark.

[Top](#)

Public Methods

Name	Description
 AddText	Obsolete for documents created in SOLIDWORKS 2016 and later. Adds text to the selected compound note.
 BeginSketchEdit	Obsolete for documents created in SOLIDWORKS 2016 and later. Activates the sketch of the compound note.
 EndSketchEdit	Obsolete for documents created in SOLIDWORKS 2016 and later. Finishes accessing this compound note's sketch.
 GetAnnotation	Gets the annotation for this specific note.
 GetArcAtIndex	Gets information for the specified arc in this note.
 GetArcCount	Gets the number of arcs in the note.
 GetArrowHeadAtIndex	Gets information on the specified arrowhead in this note.

		
	GetArrowHeadCount	Gets the number of arrowheads in the note.
	GetArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
	GetAttachPos	Gets the attachment point of this note.
	GetBalloonInfo	Gets information describing the geometry of the balloon, if any, that encloses the note text.
	GetBalloonOptions	Gets the balloon options for this note.
	GetBalloonPadding	Gets the balloon padding of this note.
	GetBalloonSize	Gets the balloon size or fit of this note.
	GetBalloonStack	Gets the balloon stack for this balloon note.
	GetBalloonStyle	Gets the balloon style of this note.
	GetBendLineValues	Obsolete. Superseded by INote::GetBendLineValues2 .
	GetBendLineValues2	Gets the values of a bend line note.
	GetBomBalloonText	Gets the text for this BOM balloon note.
	GetBomBalloonTextStyle	Gets the text style of this BOM balloon note.
	GetCompoundTextAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the text item corresponding to the specified index from a compound note.
	GetCompoundTextCount	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the number of text items in a compound note.
	GetExtent	Gets the extents of a note in sheet space.
	GetExtentAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the extents of the specified piece of text within a compound note.
	GetFontInfo	Gets with the note's font information.
	GetHeight	Get the note's height.
	GetHeightAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the specified text item's height in a compound note.
	GetHeightInPoints	Gets the height of this note in points (for example, 8, 10, 12, and so on).
	GetHyperlinkText	Gets the hyperlink in a note.
	GetLeaderAtIndex	Gets information about the specified leader on this note.
	GetLeaderCount	Gets the number of leaders on this note.
	GetLeaderInfo	Gets information describing the layout of the note leader lines.
	GetLeaderNumPointsAt	Gets the number of points in the specified leader of this note.
	GetLineAtIndex	Gets information for the specified line.
	GetLineCount	Gets the number of line segments in this note.
	GetName	Gets the name of this note.
	GetNext	Gets the next note in drawing view .
	GetSketch	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the sketch for the current compound note.
	GetText	Gets this note's text.
	GetTextAngleAtIndex	Gets the text angle for the specified piece of text in this note.
	GetTextAtIndex	Gets the specified text in this note.
	GetTextCount	Gets the number of text items in this note.
	GetTextFontAtIndex	Gets the font used by the specified text item in this note.
	GetTextFormat	Obsolete. Superseded by IAnnotation::GetTextFormat and IAnnotation::IGetTextFormat .
	GetTextFormatAtIndex	Obsolete. Superseded by IAnnotation::GetTextFormat and IAnnotation::IGetTextFormat .
	GetTextHeightAtIndex	Gets the text height for the specified piece of text in this note.
	GetTextInvertAtIndex	Gets the specified text item's invert flag.
	GetTextJustification	Gets the text justification of a standard note.
	GetTextJustificationAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the text justification for the specified text item in a compound note.

		
	GetTextLineSpacingAtIndex	Gets the line spacing for this note.
	GetTextOffsetAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the text item's offset relative to note's text point in a compound note.
	GetTextPoint	Obsolete. Superseded by INote::GetTextPoint2 or INote::IGetTextPoint2
	GetTextPoint2	Gets the note's text reference point (i.e., note origin).
	GetTextPositionAtIndex	Gets the text item's offset relative to the document origin.
	GetTextRefPositionAtIndex	Gets the specified text item's reference position in this note, for example, the upper left, lower left, or center.
	GetTextVerticalJustification	Gets the vertical justification of a standard note.
	GetTriangleAtIndex	Gets the triangle at the specified index.
	GetTriangleCount	Gets the number of triangles in this note.
	GetUpperRight	Gets the note's upper-right text point.
	GetUseDocTextFormat	Obsolete. Superseded by IAnnotation::GetUseDocTextFormat
	HasBalloon	Gets whether this note has a balloon.
	HasExtraLeader	Gets whether this note has a bent or straight leaderline.
	IGetAnnotation	Gets the annotation for this specific note.
	IGetArcAtIndex	Gets information for the specified arc in this note.
	IGetArrowHeadAtIndex	Gets information on the specified arrowhead in this note.
	IGetArrowHeadInfo	Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.
	IGetAttachPos	Gets the attachment point of this note.
	IGetBalloonInfo	Gets information describing the geometry of the balloon, if any, that encloses the note text.
	IGetExtent	Gets the extents of a note in sheet space.
	IGetExtentAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the extents of the specified piece of text within a compound note.
	IGetFontInfo	Gets with the note's font information.
	IGetLeaderAtIndex	Gets information about the specified leader on this note.
	IGetLeaderInfo	Gets information describing the layout of the note leader lines.
	IGetLineAtIndex	Gets information for the specified line.
	IGetNext	Gets the next note in drawing view .
	IGetSketch	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the sketch for the current compound note.
	IGetTextFormat	Obsolete. Superseded by IAnnotation::GetTextFormat and IAnnotation::IGetTextFormat
	IGetTextFormatAtIndex	Obsolete. Superseded by IAnnotation::GetTextFormat and IAnnotation::IGetTextFormat
	IGetTextOffsetAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets whether the text item's offset relative to note's text point in a compound note.
	IGetTextPoint	Obsolete. Superseded by INote::IGetTextPoint
	IGetTextPoint2	Gets the note's text reference point (i.e., note origin).
	IGetTextPositionAtIndex	Gets the text item's offset relative to the document origin.
	IGetTriangleAtIndex	Gets the triangle at the specified index.
	IGetUpperRight	Gets the note's upper-right text point.
	IsAttached	Gets whether the note is attached.
	IsAttribute	Obsolete. Not superseded.
	IsBomBalloon	Gets whether this note has a BOM balloon.
	IsCompoundNote	Obsolete for documents created in SOLIDWORKS 2016 and later. Gets whether the current note is a compound note.
	ISetTextFormat	Obsolete. Superseded by IAnnotation::SetTextFormat and IAnnotation::ISetTextFormat
	ISetTextFormatAtIndex	Obsolete. Superseded by IAnnotation::SetTextFormat and IAnnotation::ISetTextFormat
	IsStackedBalloon	Gets whether this note is part of a stacked balloon.

		
	IsStackedBalloonMaster	Gets whether this note is the master note of a balloon stack.
	MakeStackedBalloon	Converts this balloon to a stacked balloon.
	SetBalloon	Sets the balloon style, size, and fit for this note.
	SetBalloonPadding	Sets the padding for this balloon note.
	SetBomBalloonText	Sets the text for this BOM balloon note.
	SetHeight	Sets the height of this note in meters.
	SetHeightInPoints	Sets the height of this note in points (for example, 8, 10, 12, and so on).
	SetHyperlinkText	Sets the hyperlink in a note.
	SetName	Sets the name for this note.
	SetText	Sets the text of the note.
	SetTextAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Sets the text value at the specified index within the compound note.
	SetTextFormat	Obsolete. Superseded by IAnnotation.SetTextFormat and IAnnotation.ISetTextFormat .
	SetTextFormatAtIndex	Obsolete. Superseded by IAnnotation.SetTextFormat and IAnnotation.ISetTextFormat .
	SetTextJustification	Sets the text justification of a standard note.
	SetTextJustificationAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Sets the text justification for the specified text item in a compound note.
	SetTextOffsetAtIndex	Obsolete for documents created in SOLIDWORKS 2016 and later. Relocates the offset (origin) of the specified piece of text in a compound note.
	SetTextPoint	Relocates the note origin to the specified location.
	SetTextVerticalJustification	Sets the vertical justification of a standard note.
	SetZeroLengthLeader	Obsolete for documents created in SOLIDWORKS 2016 and later. Sets a 0-length leader for a compound note.

[Top](#)

See Also

[INote Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2.InsertNewNote3 Method](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

INote Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : INote Interface

For a list of all members of this type, see [INote members](#).

Public Properties

Name	Description
 AllUpperCase	Gets or sets whether the text of this note is all uppercase.
 Angle	Controls the rotation angle of this note.
 BehindSheet	Places this note, located on the sheet format in a drawing, behind the drawing sheet.
 HasMultipleFonts	Gets whether a note contains multiple fonts.
 IncludeDimPrefixSuffixTolerance	Gets or sets whether to include the dimension prefix, suffix, and tolerance in this dimension note.
 IsBendLineNote	Gets whether this note is a bendline note.
 LockPosition	Gets and sets whether to anchor this note.
 PromptText	Gets and sets the message prompt text.
 PropertyLinkedText	Gets or sets the text for the note using the values of the properties linked to the note.
 ReadOnly	Gets or sets the read-only state of a note.
 TagName	Gets or sets the tag name for this note.

 TextRightToLeft	Gets or sets whether notes are displayed right to left.
 ToBoundingBox	Gets and sets whether to select the To bounding box option for leaders in this note's PropertyManager page.
 Visible	Gets and sets the visibility state of a note during the creation of a block.
 WatermarkBehindGeometry	Gets or sets whether to place this note, specified to be a watermark, behind the geometry in a part or assembly.
 WatermarkNote	Gets or sets whether the note is a watermark in a part or assembly.
 WatermarkTransparencyLevel	Gets or sets the transparency level of a note specified to be a watermark.

[Top](#)

See Also

[INote Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertNewNote3 Method](#)
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddText Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : AddText Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Adds text to the selected compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function AddText( _
    ByVal Txt As System.String, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote
Dim Txt As System.String
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim value As System.Boolean

value = instance.AddText(Txt, X, Y, Z)
```

C#

```
System.bool AddText(
    System.string Txt,
    System.double X,
    System.double Y,
    System.double Z
)
```

C++/CLI

```
System.bool AddText(
    & System.String^ Txt,
    & System.double X,
    & System.double Y,
    & System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Txt

Text string for the note
X
x location of note in meters
Y
y location of note in meters
Z
z location of note in meters

Return Value

True if successfully added, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::AddText](#).

Example

[Create Compound Note \(VBA\)](#)

Remarks

Because a compound note can have multiple pieces of text, many of the compound-note methods require you to specify the index value of the desired text. For example, the first piece of text added to the compound note using `INote::AddText` has an index number of 1, the second text added has an index number of 2, and so on.

See Also

[INote Interface](#)
[INote Members](#)
[INote::SetTextAtIndex Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::IsCompoundNote Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::GetHeightAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AllUpperCase Property (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : AllUpperCase Property (INote)

Gets or sets whether the text of this note is all uppercase.

.NET Syntax

Visual Basic (Declaration)

Property AllUpperCase As System.Boolean

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
instance.AllUpperCase = value  
  
value = instance.AllUpperCase
```

C#

```
System.bool AllUpperCase {get; set;}
```

C++/CLI

```
property System.bool AllUpperCase {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the text of this note is all uppercase, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::AllUpperCase](#).

Example

[Anchor a Note \(VBA\)](#)
[Anchor a Note \(VB.NET\)](#)
[Anchor a Note \(C#\)](#)

See Also

[INote Interface](#)
[INote Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : Angle Property (INote)

Controls the rotation angle of this note.

.NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Double  
  
instance.Angle = value  
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Rotation angle, in radians, of this note

Visual Basic for Applications (VBA) Syntax

See [Note::Angle](#).

Example

[Get Corresponding Objects in Assembly Component \(C#\)](#)
[Get Corresponding Objects in Assembly Component \(VB.NET\)](#)
[Get Corresponding Objects in Assembly Component \(VBA\)](#)

Remarks

The rotation angle of a note must be in the -360 to +360 range. If a value is specified that is outside of the range, the angle wraps around to be mapped back into range. For example, attempting to set this property to a value of 365 would result in the angle being set to 5.

See Also

[INote Interface](#)
[INote Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BeginSketchEdit Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : BeginSketchEdit Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Activates the sketch of the compound note.

.NET Syntax

Visual Basic (Declaration)

```
Sub BeginSketchEdit()
```

Visual Basic (Usage)



```
Dim instance As INote
```

```
instance.BeginSketchEdit()
```

C#

```
void BeginSketchEdit()
```

C++/CLI

```
void BeginSketchEdit();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Note::BeginSketchEdit](#).

Example

[Create Compound Note \(VBA\)](#)

Remarks

Subsequent calls for creation of sketch segment geometry (for example, [IModelDoc2::CreateLine2](#) or [IModelDoc2::ICreateLine2](#), [IModelDoc2::CreateArc2](#) or [IModelDoc2::ICreateArc2](#), and so on) place the geometry into the sketch of the compound note.

To extract information about existing compound note sketch geometry, use [INote::GetSketch](#) or [INote::IGetSketch](#).

Because a compound note can have multiple pieces of text, many of the compound note methods require you to specify the index value of the desired text. For example, the first piece of text added to the compound note using [INote::AddText](#) has an index number of 1, the second text added has an index number of 2, and so on.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::GetHeightAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

BehindSheet Property (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : BehindSheet Property (INote)

Places this note, located on the sheet format in a drawing, behind the drawing sheet.

.NET Syntax

Visual Basic (Declaration)

Property BehindSheet As System.Boolean

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Boolean  
  
instance.BehindSheet = value  
  
value = instance.BehindSheet
```

C#

```
System.bool BehindSheet {get; set;}
```

C++/CLI

```
property System.bool BehindSheet {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to place this note, located on the sheet format in a drawing, behind the drawing sheet; false to not

Visual Basic for Applications (VBA) Syntax

See [Note::BehindSheet](#).

Example

[Place Note Behind Drawing Sheet \(C#\)](#)
[Place Note Behind Drawing Sheet \(VB.NET\)](#)
[Place Note Behind Drawing Sheet \(VBA\)](#)

Remarks

This property places a note on the sheet format behind a drawing sheet, which allows you to display the note as watermark in a drawing. Before calling this property, you must call [IDrawingDoc::EditTemplate](#) and [IDrawingDoc::EditSheet](#).

Use these properties to modify watermarks in parts and assemblies:

- [INote::WatermarkNote](#)
- [INote::WatermarkBehindGeometry](#)
- [INote::WatermarkTransparencyLevel](#)

See Also

[INote Interface](#)
[INote Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndSketchEdit Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : EndSketchEdit Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Finishes accessing this compound note's sketch.

.NET Syntax

Visual Basic (Declaration)

```
Sub EndSketchEdit()
```

Visual Basic (Usage)



```
Dim instance As INote
```

```
instance.EndSketchEdit()
```

C#

```
void EndSketchEdit()
```

C++/CLI

```
void EndSketchEdit();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Note::EndSketchEdit](#).

Example

[Create Compound Note \(VBA\)](#)

Remarks

Because a compound note can have multiple pieces of text, many of the compound note methods require you to specify the index value of the desired text. For example, the first piece of text added to the compound note using [INote::AddText](#) has an index number of 1, the second text added has an index number of 2, and so on.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)

[INote::GetExtentAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::GetHeightAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotation Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetAnnotation Method (INote)

Gets the annotation for this specific note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Object  
  
value = instance.GetAnnotation()
```

C#

```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [Note::GetAnnotation](#).

Example

[Get All Notes in Drawing Template \(VBA\)](#)
[Insert Note \(VBA\)](#)
[Insert Autoballoons \(VBA\)](#)
[Set BOM Balloon Text \(VBA\)](#)
[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)
[Get Annotation Object \(C#\)](#)

Remarks

This method obtains the owning [IAnnotation](#) object for this [INote](#) object. The IAnnotation object is a higher-level object that contains methods that are general to all types of annotations.

See Also

[INote Interface](#)
[INote Members](#)
[INote::IGetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArcAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetArcAtIndex Method (INote)

Gets information for the specified arc in this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetArcAtIndex(Index)
```

C#

```
System.object GetArcAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetArcAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired arc where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetArcAtIndex](#).

Remarks

Return value is an array of doubles:

[*LineType*, *StartPt*[3], *EndPt*[3], *CenterPt*[3], *RotDir*]

where :

<i>LineType</i>	Line type. Valid returns are defined in swLineTypes_e . A LineType is a combination of a line style and line weight.
<i>StartPt</i> [3]	Array of 3 doubles (X,Y,Z) describing the start point.
<i>EndPt</i> [3]	Array of 3 doubles (X,Y,Z) describing the end point. If the arc is closed, then this is the same point as the <i>StartPt</i> .
<i>CenterPt</i> [3]	Array of 3 doubles (X,Y,Z) describing the center point.

RotDir	Rotational direction (CW = -1, CCW = 1)
--------	---

The data returned from this method is in terms of document apace.

If the document containing this note is...	Then the coordinates returned are based on the...
Drawing	Sheet origin
Part or assembly	Model origin

See Also

[INote Interface](#)
[INote Members](#)
[INote::IGetArcAtIndex Method](#)
[INote::GetArcCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArcCount Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetArcCount Method (INote)

Gets the number of arcs in the note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Integer  
  
value = instance.GetArcCount()
```

C#

```
System.int GetArcCount()
```

C++/CLI

```
System.int GetArcCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arcs in the note

Visual Basic for Applications (VBA) Syntax

See [Note::GetArcCount](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetArcAtIndex Method](#)
[INote::IGetArcAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetArrowHeadAtIndex Method (INote)

Gets information on the specified arrowhead in this note.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetArrowHeadAtIndex(Index)
```

C#

```
System.object GetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetArrowHeadAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the desired arrowhead where the index begins at 0

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetArrowHeadAtIndex](#).

Remarks

This method returns an array of doubles that describe the geometry of the arrowhead on the far end of the leader line. This information is independent of whether this note actually has an arrowhead.

Format of return information is the following array of doubles:

- return value[0] = arrow length (i.e. leader into arrowhead)
- return value[1] = arrowhead length
- return value[2] = arrowhead width

See Also

[INote Interface](#)
[INote Members](#)
[INote::IGetArrowHeadAtIndex Method](#)
[INote::IGetArrowHeadInfo Method](#)
[INote::GetArrowHeadCount Method](#)
[INote::GetArrowHeadInfo Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArrowHeadCount Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetArrowHeadCount Method (INote)

Gets the number of arrowheads in the note.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Integer

value = instance.GetArrowHeadCount()
```

C#

```
System.int GetArrowHeadCount()
```

C++/CLI

```
System.int GetArrowHeadCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arrowheads

Visual Basic for Applications (VBA) Syntax

See [Note::GetArrowHeadCount](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetArrowHeadAtIndex Method](#)
[INote::GetArrowHeadInfo Method](#)
[INote::!GetArrowHeadAtIndex Method](#)
[INote::!GetArrowHeadInfo Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArrowHeadInfo Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetArrowHeadInfo Method (INote)

Gets an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Object

value = instance.GetArrowHeadInfo()
```

C#

```
System.object GetArrowHeadInfo()
```

C++/CLI

```
System.Object^ GetArrowHeadInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetArrowHeadInfo](#).

Remarks

This information is independent of whether this note actually has an arrowhead.

This method returns an array of doubles that describe the geometry of the arrowhead on the far end of the leader line.

Format of return information is the following array of doubles:

- return value[0] = arrow length (i.e. leader into arrowhead)
- return value[1] = arrowhead length
- return value[2] = arrowhead width
- return value[3] = arrowhead style as defined in [swArrowStyle_e](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetArrowHeadAtIndex Method](#)
[INote::GetArrowHeadCount Method](#)
[INote::IGetArrowHeadAtIndex Method](#)
[INote::IGetArrowHeadInfo Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAttachPos Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetAttachPos Method (INote)

Gets the attachment point of this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAttachPos() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Object  
  
value = instance.GetAttachPos()
```

C#

```
System.object GetAttachPos()
```

C++/CLI

```
System.Object^ GetAttachPos();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetAttachPos](#).

Example

[Insert Autoballoons \(VBA\)](#)

Remarks

This is only meaningful if the note is attached.

Format of return information is the following array of doubles:

- *return value*[0] = x-coord of attachment point
- *return value*[1] = y-coord of attachment point
- *return value*[2] = z-coord of attachment point

See Also

[INote Interface](#)
[INote Members](#)
[INote::IGetAttachPos Method](#)
[INote::IsAttached Method](#)
[INote::LockPosition Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBalloonInfo Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetBalloonInfo Method (INote)

Gets information describing the geometry of the balloon, if any, that encloses the note text.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBalloonInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Object
```

```
value = instance.GetBalloonInfo()
```

C#

```
System.object GetBalloonInfo()
```

C++/CLI

```
System.Object^ GetBalloonInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetBalloonInfo](#).

Remarks

This consists of two points: center point and a point on the balloon circle.

Format of return information is the following array of doubles:

- *return value*[0] = x coordinate of balloon center point
- *return value*[1] = y coordinate of balloon center point
- *return value*[2] = z coordinate of balloon center point
- *return value*[3] = x coordinate of balloon arc point
- *return value*[4] = y coordinate of balloon arc point
- *return value*[5] = z coordinate of balloon arc point
- *return value*[6] = radius

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IBalloonInfo Method](#)
[INote::SetBalloon Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBomBalloonText Method](#)
[INote::GetBalloonOptions Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBalloonOptions Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetBalloonOptions Method (INote)

Gets the balloon options for this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBalloonOptions() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Object  
  
value = instance.GetBalloonOptions()
```

C#

```
System.object GetBalloonOptions()
```

C++/CLI

```
System.Object^ GetBalloonOptions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IBalloonOptions](#)

Visual Basic for Applications (VBA) Syntax

See [Note::GetBalloonOptions](#).

Example

See the [IBalloonOptions](#) examples.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method \(\)](#)
[INote::GetBalloonPadding Method \(\)](#)
[INote::GetBalloonSize Method \(\)](#)
[INote::GetBalloonStyle Method \(\)](#)
[INote::GetBalloonStack Method \(\)](#)
[INote::GetBomBalloonText Method \(\)](#)
[INote::GetBomBalloonTextStyle Method \(\)](#)
[INote::IsBomBalloon Method \(\)](#)
[INote::MakeStackedBalloon Method \(\)](#)
[INote::SetBalloon Method \(\)](#)
[IModelDocExtension::InsertBOMBalloon2 Method \(\)](#)
[INote::HasBalloon Method \(\)](#)
[INote::IsStackedBalloon Method \(\)](#)

Availability

SOLIDWORKS 2023 SP02, Revision Number 31.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBalloonPadding Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetBalloonPadding Method (INote)

Gets the balloon padding of this note.

INET Syntax

Visual Basic (Declaration)

```
Function GetBalloonPadding() As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Double
```

```
value = instance.GetBalloonPadding()
```

C#

```
System.double GetBalloonPadding()
```

C++/CLI

```
System.double GetBalloonPadding();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Balloon padding

Visual Basic for Applications (VBA) Syntax

See [Note::GetBalloonPadding](#).

Example

[Get BOM Balloon Properties \(VBA\)](#)
[Get BOM Balloon Properties \(VB.NET\)](#)
[Get BOM Balloon Properties \(C#\)](#)

Remarks

This method is valid only if [INote::GetBalloonSize](#) is set to [swBalloonFit_e.swBF_Tightest](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::SetBalloonPadding Method \(\)](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBalloonSize Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetBalloonSize Method (INote)

Gets the balloon size or fit of this note.

Visual Basic (Declaration)

```
Function GetBalloonSize() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Integer  
  
value = instance.GetBalloonSize()
```

C#

```
System.int GetBalloonSize()
```

C++/CLI

```
System.int GetBalloonSize();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Balloon size or fit as defined in [swBalloonFit_e](#)

Visual Basic for Applications (VBA) Syntax

See [Note::GetBalloonSize](#).

Example

[Get BOM Balloon Properties \(C#\)](#)
[Get BOM Balloon Properties \(VB.NET\)](#)
[Get BOM Balloon Properties \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStyle Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBalloon Method](#)
[INote::SetBomBalloonText Method](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBalloonStack Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetBalloonStack Method (INote)

Gets the balloon stack for this balloon note.

Visual Basic (Declaration)

Function GetBalloonStack() As BalloonStack

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As BalloonStack  
  
value = instance.GetBalloonStack()
```

C#

```
BalloonStack GetBalloonStack()
```

C++/CLI

```
BalloonStack^ GetBalloonStack();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Balloon stack](#) for this balloon note

Visual Basic for Applications (VBA) Syntax

See [Note::GetBalloonStack](#).

Example

[Add Balloon to Stacked Balloon \(C#\)](#)
[Add Balloon to Stacked Balloon \(VB.NET\)](#)
[Add Balloon to Stacked Balloon \(VBA\)](#)

Remarks

If this note is not part of a balloon stack, then this method returns null or nothing. To determine if a note is part of a balloon stack, use [INote::IsStackedBalloon](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStyle Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::SetBalloon Method](#)
[INote::SetBomBalloonText Method](#)
[INote::MakeStackedBalloon Method \(\)](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBalloonStyle Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetBalloonStyle Method (INote)

Gets the balloon style of this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBalloonStyle() As System.Integer
```

```
Dim instance As INote
Dim value As System.Integer

value = instance.GetBalloonStyle()
```

C#

```
System.int GetBalloonStyle()
```

C++/CLI

```
System.int GetBalloonStyle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Balloon style as defined in [swBalloonStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [Note::GetBalloonStyle](#).

Example

[Get BOM Balloon Properties \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBomBalloonText Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBalloon Method](#)
[INote::SetBomBalloonText Method](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBendLineValues Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetBendLineValues Method (INote)

Obsolete. Superseded by [INote::GetBendLineValues2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBendLineValues( _
    ByRef Up As System.Boolean, _
    ByRef Angle As System.Double, _
    ByRef Radius As System.Double, _
    ByRef StartPt As MathPoint, _
    ByRef EndPt As MathPoint _
) As System.Boolean
```

Visual Basic (Usage)

```

Dim instance As INote
Dim Up As System.Boolean
Dim Angle As System.Double
Dim Radius As System.Double
Dim StartPt As MathPoint
Dim EndPt As MathPoint
Dim value As System.Boolean

value = instance.GetBendLineValues(Up, Angle, Radius, StartPt, EndPt)

```

C#

```

System.bool GetBendLineValues(
    out System.bool Up,
    out System.double Angle,
    out System.double Radius,
    out MathPoint StartPt,
    out MathPoint EndPt
)

```

C++/CLI

```

System.bool GetBendLineValues(
    & [Out] System.bool Up,
    & [Out] System.double Angle,
    & [Out] System.double Radius,
    & [Out] MathPoint^ StartPt,
    & [Out] MathPoint^ EndPt
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Up
True if the bend is up, false if the bend is down

Angle
Angle of the bend

Radius
Radius of the bend

StartPt
Start [point](#) of the bend line

EndPt
End [point](#) of the bend line

Return Value

True if the note is a bend note, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::GetBendLineValues](#).

Example

[Get Bend Line Note Values \(VBA\)](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::IsBendLineNote Property](#)

Availability

SolidWorisk 2007 SP2, Revision Number 15.2

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetBendLineValues2 Method (INote)

Gets the values of a bend line note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBendLineValues2( _  
    ByRef Up As System.Boolean, _  
    ByRef Angle As System.Double, _  
    ByRef Radius As System.Double, _  
    ByRef Points As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Up As System.Boolean  
Dim Angle As System.Double  
Dim Radius As System.Double  
Dim Points As System.Object  
Dim value As System.Boolean  
  
value = instance.GetBendLineValues2(Up, Angle, Radius, Points)
```

C#

```
System.bool GetBendLineValues2(  
    out System.bool Up,  
    out System.double Angle,  
    out System.double Radius,  
    out System.object Points  
)
```

C++/CLI

```
System.bool GetBendLineValues2(  
& [Out] System.bool Up,  
& [Out] System.double Angle,  
& [Out] System.double Radius,  
& [Out] System.Object^ Points  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Up
True if the bend is up, false if the bend is down
Angle
Angle of the bend

Radius
Radius of the bend
Points

Array of doubles (see **Remarks**)

Return Value

True if the note is a bend note, false if not

Visual Basic for Applications (VBA) Syntax

See [Note::GetBendLineValues2](#).

Remarks

Points will contain six (6) doubles (three (3) each for the start point and endpoint), one set for each segment in the bend line:

[*x*, *y*, *z*, *x*, *y*, *z*]

See Also

[INote Interface](#)
[INote Members](#)
[IMathPoint Interface](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBomBalloonText Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetBomBalloonText Method (INote)

Gets the text for this BOM balloon note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBomBalloonText( _  
    ByVal WhichOne As System.Boolean _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim WhichOne As System.Boolean  
Dim value As System.String  
  
value = instance.GetBomBalloonText(WhichOne)
```

C#

```
System.string GetBomBalloonText(  
    System.bool WhichOne  
)
```

C++/CLI

```
System.String^ GetBomBalloonText(  
& System.bool WhichOne  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

True for the upper text, false for the lower text

Return Value

Balloon text

Visual Basic for Applications (VBA) Syntax

See [Note::GetBomBalloonText](#).

Example

[Set BOM Balloon Text \(VBA\)](#)
[Get BOM Balloon Properties \(C#\)](#)
[Get BOM Balloon Properties \(VB.NET\)](#)
[Get BOM Balloon Properties \(VBA\)](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStyle Method](#)
[INote::GetBomBalloonTextStyle Method](#)
[INote::HasBalloon Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBalloon Method](#)
[INote::SetBomBalloonText Method](#)
[IModelDocExtension::InsertBOMBalloon Method](#)
[INote::GetBalloonOptions Method \(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBomBalloonTextStyle Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetBomBalloonTextStyle Method (INote)

Gets the text style of this BOM balloon note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBomBalloonTextStyle( _  
    ByVal WhichOne As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim WhichOne As System.Boolean  
Dim value As System.Integer  
  
value = instance.GetBomBalloonTextStyle(WhichOne)
```

C#

```
System.int GetBomBalloonTextStyle(  
    System.bool WhichOne  
)
```

C++/CLI

```
System.int GetBomBalloonTextStyle(  
&    System.bool WhichOne  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichOne

True for the upper text, false for the lower text

Return Value

Balloon text style as defined in [swDetailingNoteTextContent_e](#)

Visual Basic for Applications (VBA) Syntax

See [Note::GetBomBalloonTextStyle](#).

Example

[Set BOM Balloon Text \(VBA\)](#)
[Get BOM Balloon Properties \(C#\)](#)
[Get BOM Balloon Properties \(VB.NET\)](#)
[Get BOM Balloon Properties \(VBA\)](#)

Remarks

SOLIDWORKS 2001 FCS, Revision Number 9.0

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetBalloonInfo Method](#)
[INote::GetBalloonSize Method](#)
[INote::GetBalloonStack Method](#)
[INote::GetBalloonStyle Method](#)
[INote::GetBomBalloonText Method](#)
[INote::HasBalloon Method](#)
[INote::IGetBalloonInfo Method](#)
[INote::IsBomBalloon Method](#)
[INote::IsStackedBalloon Method](#)
[INote::IsStackedBalloonMaster Method](#)
[INote::SetBalloon Method](#)
[INote::SetBomBalloonText Method](#)
[IModelDocExtension::InsertBOMBalloon Method](#)
[INote::GetBalloonOptions Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCompoundTextAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetCompoundTextAtIndex Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the text item corresponding to the specified index from a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCompoundTextAtIndex( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetCompoundTextAtIndex(Index)
```

C#

```
System.string GetCompoundTextAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetCompoundTextAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of the text item in the compound note; index is 1-based

Return Value

Text corresponding to specified index

Visual Basic for Applications (VBA) Syntax

See [Note::GetCompoundTextAtIndex](#).

Remarks

Before calling this method, call [INote::GetCompoundTextCount](#) to get the number of text items.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::GetHeight Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCompoundTextCount Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetCompoundTextCount Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the number of text items in a compound note.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetCompoundTextCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Integer  
  
value = instance.GetCompoundTextCount()
```

C#

```
System.int GetCompoundTextCount()
```

C++/CLI

```
System.int GetCompoundTextCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of text items in a compound note

Visual Basic for Applications (VBA) Syntax

See [Note::GetCompoundTextCount](#).

Remarks

Use this method before using any of the following methods:

- [INote::GetCompoundTextAtIndex](#)

- [INote::GetTextOffsetAtIndex](#) and [INote::IGetTextOffsetAtIndex](#)
- [INote::GetTextJustificationAtIndex](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::GetHeightAtIndex Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExtent Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetExtent Method (INote)

Gets the extents of a note in sheet space.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExtent() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Object

value = instance.GetExtent()
```

C#

```
System.object GetExtent()
```

C++/CLI

```
System.Object^ GetExtent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetExtent](#).

Remarks

This method is not valid for invisible documents.

The data returned is an array of 6 doubles that describe the lower-left and upper-right box extents of the note. The values (X,Y,Z) are in sheet space. In other words, the X,Y,Z values are in relation to the origin of the drawing document, which is in the lower-left hand corner of the drawing

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::GetHeightAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetExtentAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetExtentAtIndex Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the extents of the specified piece of text within a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExtentAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetExtentAtIndex(Index)
```

C#

```
System.Object GetExtentAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetExtentAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index number of the text

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetExtentAtIndex](#).

Remarks

This method is not valid for invisible documents.

The data returned is an array of 6 doubles that describe the lower-left and upper-right box extents of the text string. The values (X,Y,Z) are in sheet space. In other words, they are in relation to the origin of the drawing document which is in the lower-left corner of the drawing.

In a compound note, this method determines the text item's offset relative to note's text point.

Because a compound note can have multiple pieces of text, many of the compound note methods require you to specify the index value of the desired text. For example, the first piece of text added to the compound note using [INote::AddText](#) has an index number of 1, the second text added has an index number 2, and so on.

If you use this method on a standard note (not a compound note), then the index value should be set to 1.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetSketch Method](#)
[INote::IGetExtent Method](#)
[INote::IGetLeaderAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::GetHeightAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFontInfo Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetFontInfo Method (INote)

Gets with the note's font information.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFontInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Object  
  
value = instance.GetFontInfo()
```

C#

```
System.object GetFontInfo()
```

C++/CLI

```
System.Object^ GetFontInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles containing the font information (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetFontInfo](#).

Remarks

Currently this method returns only a line type index. See [swLineTypes_e](#) for line type index information.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetFontInfo Method](#)
[INote::HasMultipleFonts Property](#)
[INote::GetTextFontAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetHeight Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetHeight Method (INote)

Get the note's height.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHeight() As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Double  
  
value = instance.GetHeight()
```

C#

```
System.double GetHeight()
```

C++/CLI

```
System.double GetHeight();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Text height for the note

Visual Basic for Applications (VBA) Syntax

See [Note::GetHeight](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetHeightInPoints Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetHeightInPoints Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetHeightAtIndex Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetHeightAtIndex Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the specified text item's height in a compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHeightAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As INote
Dim Index As System.Integer
Dim value As System.Double

value = instance.GetHeightAtIndex(Index)
```

C#

```
System.double GetHeightAtIndex(
    System.int Index
)
```

C++/CLI

```
System.double GetHeightAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index position of the text

Return Value

Text height

Visual Basic for Applications (VBA) Syntax

See [Note::GetHeightAtIndex](#).

Example

[Create Compound Note \(VBA\)](#)

Remarks

Because a compound note can have multiple pieces of text, many of the compound note methods require you to specify the index value of the desired text. For example, the first piece of text added to the compound note using [INote::AddText](#) has an index number of 1, the second text added has index number of 2, and so on.

If you use this method on a standard note (not a compound note), then the index value must be set to 1.

To set the specified text's height, use [IAnnotation::SetTextFormat](#) or [IAnnotation::!SetTextFormat](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::BeginSketchEdit Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetSketch Method](#)
[INote::!GetExtent Method](#)
[INote::!GetExtentAtIndex Method](#)
[INote::!GetSketch Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::SetHeightInPoints Method](#)
[INote::SetHeight Method](#)
[INote::GetHeightInPoints Method](#)
[INote::GetHeight Method](#)

Gets the height of this note in points (for example, 8, 10, 12, and so on).

.NET Syntax

Visual Basic (Declaration)

```
Function GetHeightInPoints() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Integer  
  
value = instance.GetHeightInPoints()
```

C#

```
System.int GetHeightInPoints()
```

C++/CLI

```
System.int GetHeightInPoints();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Height of the note in points

Visual Basic for Applications (VBA) Syntax

See [Note::GetHeightInPoints](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetHeight Method](#)
[INote::GetHeightInPoints Method](#)
[INote::SetHeight Method](#)
[INote::SetHeightInPoints Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetHyperlinkText Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetHyperlinkText Method (INote)

Gets the hyperlink in a note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHyperlinkText() As System.String
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.String  
  
value = instance.GetHyperlinkText()
```

C#

```
System.string GetHyperlinkText()
```

C++/CLI

```
System.String^ GetHyperlinkText();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Hyperlink text

Visual Basic for Applications (VBA) Syntax

See [Note::GetHyperlinkText](#).

Example

[Remove Hyperlink From Note in Drawing \(VBA\)](#)

Remarks

You can create an embedded hyperlink on a note by using [INote::SetHyperlinkText](#) or by using the hyperlink button on the note creation dialog.

This command first looks for an embedded hyperlink on the note and returns the text used to take the user to that document, which can be on the internet (a URL address is returned) or on your local network or hard drive (a pathname is returned). If the pathname was specified as a relative pathname, then the full pathname is returned.

If an embedded hyperlink does not exist, the note's text is searched for a hyperlink explicitly entered as part of the note text. This could be a URI address (a text string beginning with **http://**) or a file address (a text string beginning with **file://**).

If no hyperlink is found, either embedded or explicitly entered within the note text, an empty string is returned.

See Also

[INote Interface](#)
[INote Members](#)
[INote::SetHyperlinkText Method](#)

Availability

SOLIDWORKS 98Plus, datecode 1998319

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLeaderAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetLeaderAtIndex Method (INote)

Gets information about the specified leader on this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetLeaderAtIndex(Index)
```

C#

```
System.object GetLeaderAtIndex(  
    System.int Index  
)
```

```
System.Object^ GetLeaderAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of leader

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetLeaderAtIndex](#).

Remarks

There can be 0, 1, or 2 lines used with the leader line. In other words, if the note is not attached, then there are 0 lines; otherwise, you can have a straight leaderline (1 line) or a bent leaderline (2 lines). You must infer the number of leader lines based on `IsAttached()` and `HasExtraLeader()`

- `IsAttached() == false` implies no leaderline and no leaderline points (`PointCount=0`).
- `HasExtraLeader() == false` implies that this is a straight leaderline and 1 line (`PointCount=2`)
- `HasExtraLeader() == True` means that this is a bent leaderline and 2 lines (`PointCount=3`)

Format of return information is the following array of doubles:

- *return value*[0] = x coordinate of first leader point
- *return value*[1] = y coordinate of first leader point
- *return value*[2] = z coordinate of first leader point
- *return value*[3] = x coordinate of second leader point
- *return value*[4] = y coordinate of second leader point
- *return value*[5] = z coordinate of second leader point
- *return value*[6] = x coordinate of third leader point
- *return value*[7] = y coordinate of third leader point
- *return value*[8] = z coordinate of third leader point

Use [INote::GetLeaderCount](#) to see how many leaders there are on the note.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetLeaderInfo Method](#)
[INote::HasExtraLeader Method](#)
[INote::IGetLeaderAtIndex Method](#)
[INote::IGetLeaderInfo Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::HasExtraLeader Method](#)
[INote::IsAttached Method](#)
[INote::GetLeaderNumPointsAt Method \(\)](#)

GetLeaderCount Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetLeaderCount Method (INote)

Gets the number of leaders on this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderCount() As System.Integer
```

```
Dim instance As INote
Dim value As System.Integer

value = instance.GetLeaderCount()
```

C#

```
System.int GetLeaderCount()
```

C++/CLI

```
System.int GetLeaderCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of leaders on the note

Visual Basic for Applications (VBA) Syntax

See [Note::GetLeaderCount](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetLeaderAtIndex Method](#)
[INote::GetLeaderInfo Method](#)
[INote::IGetLeaderAtIndex Method](#)
[INote::IGetLeaderInfo Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::HasExtraLeader Method](#)
[INote::IsAttached Method](#)
[INote::GetLeaderNumPointsAt Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)**GetLeaderInfo Method (INote)**[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetLeaderInfo Method (INote)

Gets information describing the layout of the note leader lines.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderInfo() As System.Object
```

Visual Basic (Usage)

```
Dim instance As INote
Dim value As System.Object

value = instance.GetLeaderInfo()
```

C#

```
System.object GetLeaderInfo()
```

C++/CLI

```
System.Object^ GetLeaderInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetLeaderInfo](#).

Remarks

There can be 0, 1, or 2 lines used with the leader line. If the note is not attached, then there are 0 lines; otherwise, you have a straight leaderline (1 line) or a bent leaderline (2 lines). You must infer the number of leader lines based on `IsAttached()` and `HasExtraLeader()`.

- `IsAttached() == false` implies no leaderline and no leaderline points (`PointCount=0`).
- `HasExtraLeader() == false` implies a straight leaderline and 1 line (`PointCount=2`)
- `HasExtraLeader() == True` implies a bent leaderline and 2 lines (`PointCount=3`)

Format of return information is the following array of doubles:

- `return value[0]` = x coordinate of first leader point
- `return value[1]` = y coordinate of first leader point
- `return value[2]` = z coordinate of first leader point
- `return value[3]` = x coordinate of second leader point
- `return value[4]` = y coordinate of second leader point
- `return value[5]` = z coordinate of second leader point
- `return value[6]` = x coordinate of third leader point
- `return value[7]` = y coordinate of third leader point
- `return value[8]` = z coordinate of third leader point

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetLeaderAtIndex Method](#)
[INote::GetLeaderCount Method](#)
[INote::IGetLeaderAtIndex Method](#)
[INote::IGetLeaderInfo Method](#)
[INote::HasExtraLeader Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::IsAttached Method](#)
[INote::GetLeaderNumPointsAt Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLeaderNumPointsAt Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetLeaderNumPointsAt Method (INote)

Gets the number of points in the specified leader of this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderNumPointsAt( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetLeaderNumPointsAt(Index)
```

C#

```
System.int GetLeaderNumPointsAt(  
    System.int Index  
)
```

C++/CLI

```
System.int GetLeaderNumPointsAt(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of leader on this note

Return Value

Number of points in the leader

Visual Basic for Applications (VBA) Syntax

See [Note::GetLeaderNumPointsAt](#).

Remarks

Use [INote::GetLeaderCount](#) to see how many leaders are on the note.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetLeaderAtIndex Method \(\)](#)
[INote::GetLeaderInfo Method \(\)](#)
[INote::SetZeroLengthLeader Method \(\)](#)
[INote::HasExtraLeader Method \(\)](#)
[INote::IsAttached Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineAtIndex Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetLineAtIndex Method (INote)

Gets information for the specified line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineAtIndex(  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetLineAtIndex(Index)
```

C#

```
System.Object GetLineAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetLineAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Zero-based index of the desired line

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Note::GetLineAtIndex](#).

Remarks

The return value is the following array of doubles :

[*lineType*, *startPt*[3], *endPt*[3]

where:

<i>lineType</i>	= the line type. Refer to the swLineTypes_e enumeration.
<i>startPt</i> [3]	= the XYZ line start point
<i>endPt</i> [3]	= the XYZ line end point

The data returned from this method is in terms of document space. If the document containing this note is a drawing, then the coordinates returned are based on the sheet origin. If the document is a part or assembly, then the coordinates are based on the model origin.

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetLineCount Method](#)
[INote::IGetLineAtIndex Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLineCount Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetLineCount Method (INote)

Gets the number of line segments in this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Integer  
  
value = instance.GetLineCount()
```

C#

```
System.int GetLineCount()
```

C++/CLI

```
System.int GetLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of line segments

Visual Basic for Applications (VBA) Syntax

See [Note::GetLineCount](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetLineAtIndex Method](#)
[INote::!GetLineAtIndex Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetName Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetName Method (INote)

Gets the name of this note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetName() As System.String
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.String  
  
value = instance.GetName()
```

C#

```
System.string GetName()
```

C++/CLI

```
System.String^ GetName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the note

Visual Basic for Applications (VBA) Syntax

See [Note::GetName](#).

Example

[Get All Notes in Drawing Template \(VBA\)](#)
[Get Note By Name \(VBA\)](#)
[Remove Hyperlink From Note in Drawing \(VBA\)](#)
[Set Note Name \(VBA\)](#)
[Get Notes from New or Existing Title Block \(C#\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block \(VBA\)](#)

Remarks

This method returns an empty string if the note is part of a block.

See Also

[INote Interface](#)
[INote Members](#)
[INote::SetName Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetNext Method (INote)

Gets the next note in [drawing view](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [note](#)

Visual Basic for Applications (VBA) Syntax

See [Note::GetNext](#).

Example

[Change Note Text \(VBA\)](#)
[Get All Notes in Drawing Template \(VBA\)](#)

Remarks

The sheet must be visible. See [ISheet::SheetFormatVisible](#).

See Also

[INote Interface](#)
[INote Members](#)
[INote::IGetNext Method](#)
[IView::GetFirstNote Method](#)
[IView::IGetFirstNote Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketch Method (INote)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetSketch Method (INote)

Obsolete for documents created in SOLIDWORKS 2016 and later. Gets the sketch for the current compound note.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketch() As System.Object
```

Visual Basic (Usage)



```
Dim instance As INote
Dim value As System.Object

value = instance.GetSketch()
```

C#

```
System.object GetSketch()
```

C++/CLI

```
System.Object^ GetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Sketch](#) for this compound note

Visual Basic for Applications (VBA) Syntax

See [Note::GetSketch](#).

Remarks

If the current note is not a compound note, then a NULL value is returned.

For adding or modifying actual sketch geometry in a compound note, use [INote::BeginSketchEdit](#), which activates the sketch of the compound note for modification.

See Also

[INote Interface](#)
[INote Members](#)
[INote::AddText Method](#)
[INote::EndSketchEdit Method](#)
[INote::GetCompoundTextAtIndex Method](#)
[INote::GetCompoundTextCount Method](#)
[INote::GetExtent Method](#)
[INote::GetExtentAtIndex Method](#)
[INote::GetHeightAtIndex Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::IGetExtent Method](#)
[INote::IGetExtentAtIndex Method](#)
[INote::IGetSketch Method](#)
[INote::IsCompoundNote Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::SetZeroLengthLeader Method](#)
[INote::BeginSketchEdit Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetText Method (INote)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [INote Interface](#) : GetText Method (INote)

Gets this note's text.

.NET Syntax

Visual Basic (Declaration)

```
Function GetText() As System.String
```

Visual Basic (Usage)



```
Dim instance As INote  
Dim value As System.String  
  
value = instance.GetText()
```

C#

```
System.string GetText()
```

C++/CLI

```
System.String^ GetText();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Text

Visual Basic for Applications (VBA) Syntax

See [Note::GetText](#).

Example

[Change Note Text \(VBA\)](#)
[Get All Notes in Drawing Template \(VBA\)](#)
[Get Block Information \(VBA\)](#)
[Get Corresponding Note in Assembly \(VBA\)](#)
[Get Corresponding Note in Part \(VBA\)](#)
[Insert Autoballoons \(VBA\)](#)
[Get Notes from New or Existing Title Block \(VBA\)](#)
[Get Notes from New or Existing Title Block \(VB.NET\)](#)
[Get Notes from New or Existing Title Block C#](#)

See Also

[INote Interface](#)
[INote Members](#)
[INote::GetTextAngleAtIndex Method](#)
[INote::GetTextAtIndex Method](#)
[INote::GetTextCount Method](#)
[INote::GetTextFontAtIndex Method](#)
[INote::GetTextHeightAtIndex Method](#)
[INote::GetTextInvertAtIndex Method](#)
[INote::GetTextJustification Method](#)
[INote::GetTextJustificationAtIndex Method](#)
[INote::GetTextLineSpacingAtIndex Method](#)
[INote::GetTextOffsetAtIndex Method](#)
[INote::GetTextPoint2 Method](#)
[INote::GetTextPositionAtIndex Method](#)
[INote::GetTextRefPositionAtIndex Method](#)
[INote::IGetTextOffsetAtIndex Method](#)
[INote::IGetTextPoint2 Method](#)
[INote::IGetTextPositionAtIndex Method](#)
[INote::SetText Method](#)
[INote::SetTextAtIndex Method](#)
[INote::SetTextJustification Method](#)
[INote::SetTextJustificationAtIndex Method](#)
[INote::SetTextOffsetAtIndex Method](#)
[INote::SetTextPoint Method](#)
[INote::PropertyLinkedText Property](#)
[INote::TextRightToLeft Property](#)
[INote::AddText Method](#)
[INote::SetTextVerticalJustification Method](#)
[INote::GetTextVerticalJustification Method](#)