

Computers Lynx 48/96K Mark I Jumper Settings
@grandoldian 09/2025 v1.1 (Board Folk v1n Board)

LK1

RAM Bank 1 Pin 1
Voltage Selection

1

2

3

4116 RAM
1-2 -5V

1

2

3

4164/8118
RAM
NF

LK2

RAM Bank 1 Pin 8 and 9
Mode Selection

1

2

3

4164 RAM
1-2 5V
4-5 A7

1

2

3

4

5

6

4116 RAM
2-3 12V
5-6 5V

1

2

3

4

5

6

8118 RAM
1-2 5V
4-6 NF

LK3

Video RAM
Mode Selection

1

2

3

48K Mode
1-4
2-3
5-6

1

2

3

4

5

6

96K Mode
1-2
4-5
3-6

LK4

VCLK Selection
(Not Fitted / Preconfigured)

3

2

1

12MHz
(Default)

3

2

1

24Mhz

LK5

RAM Bank 2 Pin 9
Mode Selection

3

2

1

4116 RAM
2-3 +5V

3

2

1

4164
RAM
1-2 A7

3

2

1

8118
RAM
NF

LK6

I/CASII Select
Use 1-2 (South)

3

2

1

Unknown
(?)

3

2

1

Default
(?)

LK7

Baud Rate Select
TBD

1

3

5

7

2

4

6

8

1-2 ? Baud
3-4 ? Baud
5-6 ? Baud
7-8 ? Baud

LK8

RAM Bank 2 Pin 1
Voltage Selection

1

2

4116
1-2 -5V

1

2

4164/8118
NF

LK9

RAM Bank 2 Pin 8
Voltage Selection

1

2

3

4116 RAM
1-2 12V

1

2

3

4164/8118
RAM
2-3 5V

LK10

Modulator Additional Ground
(Not Fitted / Preconfigured On)

1

2

Ground

LK11

RGB Voltage
(Not Fitted / Preconfigured RoW)

3

2

1

Ground
RoW (Default)

3

2

1

+12V
France