# 高溫提醒

資管碩一 M10509102 韓承志

資管碩一 M10509109 陸建綱

四資管四 B10130344 廖仁靖

### GATT 服務實作方式

- 周邊(Peripheral): Nordic nRF52 DK
- 中心(Central): android BLE GATT

```
void scanDevice(final boolean enable) {
if (enable) {
    mHandler.postDelayed(() → {
            mScanning = false;
            mBluetoothLeScanner.stopScan(mScanCallback);
            getActivity().invalidateOptionsMenu();
    }, SCAN PERIOD);
    mScanning = true;
    mBluetoothLeScanner.startScan(mScanCallback);
} else {
    mScanning = false;
    mBluetoothLeScanner.stopScan(mScanCallback);
getActivity().invalidateOptionsMenu();
```


### Android 模擬BLE周邊

• 發出廣播

• 傳送資料

• 停止廣播

mBluetoothLeAdvertiser.stopAdvertising(mAdvertiseCallback);



### GATT 服務提供

- nRF5 溫度測量
- 每秒確認是否更新數據
- 每傳六次把溫度加上120
- 測試提醒功能

```
nt32_t old temperature = -1;
nt32 t i = 0;
nt32 t test = 3;
tatic void timer timeout handler(void * p context)
   // OUR JOB: Step 3.F, Update temperature and characteristic value.
   int32 \bar{t} temperature = 0;
   sd_temp_get(&temperature);
   i++;
   if(i>=6){
     temperature+=30*4;
     i=0:
   if(old temperature != temperature) {
     //temperature=temperature/4;
     SEGGER RTT printf(0, "temperature value: %d\n", temperature);
     our termperature characteristic update (&m our service, &temperature)
     nrf gpio pin toggle(LED 4);
     old temperature = temperature;
```

### 周邊與手機認證

### • 板子上用just work做bonding

#### Just Works bonding:

```
sec_param.bond = true;
sec_param.mitm = false;
sec_param.lesc = 0;
sec_param.keypress = 0;
sec_param.io_caps = BLE_GAP_IO_CAPS_NONE;
sec_param.oob = false;
sec_param.min_key_size = 7;
sec_param.max_key_size = 16;
sec_param.kdist_own.enc = 1;
sec_param.kdist_own.id = 1;
sec_param.kdist_peer.enc = 1;
sec_param.kdist_peer.enc = 1;
```

```
static void peer manager init(bool erase bonds)
   ble gap sec params t sec param;
   ret code t err code;
   err code = pm init();
   APP ERROR CHECK (err code);
   if (erase bonds)
       err code = pm peers delete();
       APP ERROR CHECK (err code);
   memset(&sec param, 0, sizeof(ble gap sec params t));
   //http://infocenter.nordicsemi.com/index.jsp?topic=%2Fc
   // Security parameters to be used for all security proc
   sec param.bond
                               = SEC PARAM BOND;
   sec param.mitm
                               = SEC PARAM MITM;
     sec param.lesc
                               = SEC PARAM LESC;
     sec param.keypress
                              = SEC PARAM KEYPRESS;
   sec param.io caps
                               = SEC PARAM IO CAPABILITIES
   sec param.oob
                               = SEC PARAM OOB;
                               = SEC PARAM MIN KEY SIZE;
   sec param.min key size
   sec param.max key size
                               = SEC PARAM MAX KEY SIZE;
   sec param.kdist own.enc
                               = 1;
   sec param.kdist own.id
                               = 1;
   sec param.kdist peer.enc
                               = 1:
   sec param.kdist peer.id
                               = 1;
   err code = pm sec params set(&sec param);
   APP ERROR CHECK (err code);
   err code = pm register(pm evt handler);
   APP ERROR CHECK(err code);
   SEGGER RTT WriteString(0, "Bonding-Just Work Bonding\n")
```

## 手機與周邊認證(cont.)

• 手機上用createBond

```
static public boolean createBond(Class btClass, BluetoothDevice btDevice) throws Exception {
    Method createBondMethod = btClass.getMethod("createBond");
    Boolean returnValue = (Boolean) createBondMethod.invoke(btDevice);
    return returnValue.booleanValue();
}
```

- 第一次bond的時候需要先把版子上的pair先註解掉
- bond一次後,之後connect就會使用bond過的資訊,不用再重新
- bond如果在手機上解除與板子的bond,需要重新燒錄softdevice

## MITM(men-in-the-middle)

#### Nordic nRF52

```
Attr用防止MITM
 BLE GAP CONN SEC MODE SET ENC NO MITM(&attr md.read perm);
 BLE GAP CONN SEC MODE SET ENC NO MITM(&attr md.write perm);
 cccd用防止MITM時,無法成功……?
ble gatts attr md t cccd md;
memset(&cccd_md, 0, sizeof(cccd_md));
cccd md.vloc = BLE GATTS VLOC STACK;
char_md.p_cccd_md = &cccd_md;
char_md.char_props.notify = 1;//Enable notification by setting the notify property bit.
BLE GAP CONN SEC MODE SET OPEN (&cccd md.read perm);
BLE GAP CONN SEC MODE SET OPEN (&cccd md.write perm);
//BLE GAP CONN SEC MODE SET ENC NO MITM(&cccd md.read perm);
//BLE GAP CONN SEC MODE SET ENC NO MITM(&cccd md.write perm);
```

### 自訂的服務

### • 温度服務

```
public
public
static String BASE_UUID="-1212-efde-1523-785fef13d123";
public
public static String Temperature_Service_uuid="abcd";
public static String Temperature_Characteristic_uuid="beef";
public static String cccd_uuid="2902";
public static String Temperature_Service=Padding+Temperature_Service_uuid+BASE_UUID;
public static String Temperature_Characteristic=Padding+Temperature_Characteristic_uuid+BASE_UUID;
public static String cccd=Padding+cccd_uuid+BASE_UUID;
```

