VATSIM R.O.C. | Pilot Briefing - RCTP

Taipei / Taiwan Taoyuan International Airport

This pilot briefing contains information that you will need to know when flying in/out of Taiwan Taoyuan International Airport (RCTP). Based on the current eAIP for VATSIM flight simulation use only.

Frequency List

This section contains frequencies for the primary positions at each level:

Text Callsign	Voice Callsign	Frequency	Remark
RCTP_DEL	Taipei Delivery (台北許可頒發)	121.800	Datalink PDC: available at controller's discretion.
RCTP_N_GND RCTP_S_GND	Taipei Ground (台北地面管制)	121.700 121.600	When DEL is offline and both GNDs are staffed, all aircraft shall contact S_GND for IFR clearance, regardless of parking stand.
RCTP_TWR	Taipei Tower (台北塔臺)	118.700	
RCTP_S_APP RCTP_N_APP RCTP_A_APP	Taipei Approach (台北近場)	125.100 128.500 125.600	S_APP is the primary APP position; N_APP and A_APP (Final approach) are opened as a split position during high traffic.
TPE_W_CTR	Taipei Control (台北管制)	126.700	
RCTP_ATIS	Taipei ATIS	127.600	

VATROC
VATSIM R.O.C. Division

Departure Procedures

ATC Clearance, Start-Up and Pushback

- **DEL (Freq: 121.800MHz)**
  - Airport Collaborative Decision Making (ACDM) is in progress at RCTP.
  - Submit your TOBT at https://vats.im/vdgs
  - Call Taipei Delivery for your IFR clearance **15 minutes before your TOBT**.
  - Give your **callsign**, **parking bay**, **proposed flight level**, **ATIS code** when requesting clearance.
- **GND (Freq: 121.700 or 121.600MHz)**
  - Confirm that the pushback tug is connected before requesting pushback.
  - Pilots shall select transponder Mode C prior to requesting pushback
  - Unless otherwise approved, all engines should be started and the aircraft ready to taxi by the end of pushback.
  - Aircraft using Terminal B, C and Remote Parking (601-615) contact Taipei Ground on 121.600; all other aprons use 121.700.
- **TWR (Freq: 118.700MHz)**
  - A minimum departure separation interval of 2 minutes shall be applied between successive departures.

Initial Altitude for Departures

All departing traffic should anticipate an initial altitude of 3000FT before being assigned a proper level by Taipei Approach and Taipei Control.

Transition altitude

The transition altitude is 11,000FT.

Arrival Procedures

Runway and STAR Assignment

1. For approach, always expect:
   JAMMY Transition for RWY05, and **AUGUR Transition for RWY 23**
2. In **downwind** of arrival, expect to level at **9000 ft when abeam airpor**t
3. Arrival routing depends on **your FIR entry pointt** and the **runway-in-use**, per the RNAV STAR table below:

Entry point	RWY 05 for landing		RWY 23 for landing	
	STAR	Descent planning	STAR	Descent planning
SALMI SULEM KASKA	BAKER 1A	Cross COPRA at FL200	BAKER 1B	Cross COPRA at FL140
BULAN	DRAKE 1A	Cross DRAKE at FL200	DRAKE 1B	Cross DRAKE at FL140
SEDKU	GRACE 1A	Cross GRACE at FL200	GRACE 1B	Cross GRACE at FL140
ENVAR OLDID	TONGA 1A	Cross BOCCA at FL290	TONGA 1B	Cross BOCCA at FL290
KAPLI POTIB	TNN 1A	Cross MENON/ARLEN/ ABSOL at FL290	TNN 1B	Cross MENON/ARLEN/ ABSOL at FL290

4. Actual descent clearances are issued by ATC; the above are planning guidance only
5. The landing runway-in-use is broadcast on ATIS (127.600 MHz).

Arrival Speed Control

This applies to all arrivals via STARs, under radar vectoring, or on weather deviation, unless otherwise instructed by ATC or entering a holding pattern.

- **At or below FL250** and **at or above FL130**: maintain 280KT IAS.
- **Below FL130** and **at or above 10,000FT**: **MAX** 280KT IAS.

Transition level

The transition level is FL130

Approach speed control

Speed	ILS 05L	ILS 05R	ILS 23L	ILS 23R
200–180 KT	Cross KARAN	Cross HUKOU	Cross FLASH	Cross FRANK
180 KT	Cross ANKLE	Cross TULIP	Cross DINKY	Cross EMILY
160–150 KT	Cross ITIA D5.0	Cross ICKS D5.0	Cross ICJN D6.2	Cross ITYA D6.3

Charts

Charts for Taiwan Taoyuan International Airport (RCTP), including the Aerodrome Chart, SID/STAR charts and precision approach terrain charts, can be found on the Taiwan eAIP.

Link: https://ais.caa.gov.tw/eaip/

Additional Note

- **A380 Restrictions**
  - For Airbus A380, taxiways E, Q4, Q6, Q7, W, R (between Q2 and Q4) are prohibited.
  - Only stands C2, C3, D6, 522, 523, 524, 607 and 615 are available for A380.
- **B748 Restrictions**
  - For Boeing 748, taxiways W are prohibited .
  - Only stands A5-A8, C2-C3, D6, 507, 513, 515-525 are available for B748.
- **Hot Spots (Runway Crossing Points)**
  - TWY N11 and L2 crossing RWY 05L/23R, to/from cargo apron (bays 516-525).
  - TWY N9 and L1 crossing RWY 05L/23R, to/from cargo apron (bays 516-525).
  - Service road and TWY S8 crossing RWY 05R/23L, to/from the south fire station.
- **Traffic Pattern**
  - West circuit